



AS 1600

Swing loader



FIN: Valid from W09S15001GBA08812...

Service manual

Status: 28.04.2016

Product	Swing loader AS 1600
FIN	as from W09S15001GBA08812
Publisher	<p>MECALAC Baumaschinen GmbH Am Friedrichsbrunnen 2 D-24782 Büdelsdorf</p> <p>Tel: +49 (0)4331 351 325 Fax: +49 (0)4331 351 491 E-Mail: info@mecalac.com www: www.mecalac.com</p> <p>This document is protected by copyright. All rights reserved. The document may not, in whole or in part, be copied, reproduced, translated or reduced to an electronic medium of machine-readable form without the express permission of MECALAC Baumaschinen GmbH .</p> <p>Subject to change without notice.</p>
Foreword	This service manual contains all the information and instructions required for the correct execution of service tasks required for the wheel loader. Read this service manual before commencing the tasks and always keep it to hand for reference.
Validity	This Service manual applies together with the operator's manual of the Swing loader AS 1600.
Suggestions and comments	...regarding this documentation or the wheel loader can be sent to the above-mentioned address.
Most recent amendment	28.04.2016

Contents

1 Notes for the Reader	5
1.1 Validity	5
1.2 Illustrations	5
1.3 Accentuated text	5
1.3.1 Pictograms	5
1.3.2 Safety Note	6
1.3.3 Safety instructions	6
1.3.4 Warning notes	7
1.3.5 Guideline	7
2 Description	9
2.1 Parts of the wheel loader	9
2.2 Front section	10
2.2.1 Overview	10
2.2.2 Hydraulic hoses	10
2.3 Cab - interior	11
2.3.1 Multi-function panel	11
2.3.2 Display	11
2.3.3 Central electrical system	19
2.3.4 Diagnostic unit	20
2.3.5 Error messages	20
3 Service tasks	23
3.1 Checks	23
3.1.1 Checking the front axle oil level	23
3.1.2 Checking the rear axle oil level	26
3.1.3 Checking the planetary gear oil level	29
3.1.4 Checking the transfer case oil level	31
3.1.5 Checking the electrical functions and connections	35
3.1.6 Checking the hydraulic hoses	35
3.2 Repair work	36
3.2.1 Changing a wheel	36
3.2.2 Changing the air-conditioner V-belt	40
3.2.3 Changing the alternator/water pump V-belt	47
3.2.4 Changing the fuel pre-filter	55
3.2.5 Changing the fuel filter	58
3.2.6 Changing the hydraulic fluid filter	60
3.2.7 Changing the engine oil filter	64
3.2.8 Changing the air filter	66
3.3 Changing the consumables	71
3.3.1 Changing the engine oil	71
3.3.2 Changing the gearbox oil of the front axle	74
3.3.3 Changing the gearbox oil of the rear axle	79
3.3.4 Changing the gearbox oil of the planetary gear	84
3.3.5 Changing the gearbox oil of the reduction gear	87
3.3.6 Topping up the hydraulic fluid	90
3.3.7 Refilling with diesel fuel	91

3.4 Lubrication	93
3.4.1 Lubrication plan	93
3.4.2 Lubrication points - front and rear axles	93
3.4.3 Lubrication points - interior of engine compartment	94
3.4.4 Lubricating the turntable chain	94
3.4.5 Return	96
3.4.6 Support valve	96
4 Circuit diagrams	97
5 Annex	99
5.1 Spare Parts	99
5.1.1 Filter	99
5.1.2 Consumables	101
5.2 Deutz error messages	101

1 Notes for the Reader

In this chapter you will find information regarding the use of the Service manual:

- Validity (Page 5)
- Illustrations (Page 5)
- Accentuated text (Page 5)

1.1 Validity

This service manual contains information and codes of behaviour for service tasks on the Swing loader AS 1600. Read this service manual carefully before the first service. Always use the service manual when performing service tasks. Store the service manual at a central point and to hand for the responsible technical personnel. In accordance with current usage in the industry, the term wheel loader is used in this service manual.

This Service manual applies together with the operator's manual of the Swing loader AS 1600. This service manual applies to technical personnel.

1.2 Illustrations




The illustrations in this service manual show the wheel loader in partially simplified form.

1.3 Accentuated text

In this service manual, important information is highlighted by symbols or special formatting. The following examples illustrate the most important types of highlighting.

1.3.1 Pictograms

Pictograms used

Pictogram	Meaning
	Further useful information.
	Conditions that must be fulfilled in order to perform an action
	Tools or material required in order to perform an action.

1.3.2 Safety Note

Safety instruction: Special note for an informative section

Explanation of the note.

- The dot identifies measures that relate to the note.

1.3.3 Safety instructions

Safety Instruction

To ensure the safe implementation, ensure compliance with the following steps:

1. First step of a safety instruction
! Important note regarding a safety instruction
 2. Second step of a safety instruction.
→ The result of this step.
- ✓ The safety instruction is complete, the goal of the of a safety instruction has been achieved.

1.3.4 Warning notes



DANGER

Warning of injuries leading to fatality

Failure to observe the safety instruction will result in serious damage to health, including death.

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.



WARNING

Warning: Serious Injuries.

Failure to observe the warning can cause serious damage to health, or even death.

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.



CAUTION

Warning: Injuries.

Failure to observe the warning can result in serious damage to health.

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.

NOTICE

Warning: Damage to property.

Ignoring the warning instructions can result in serious damage to the wheel loader or in its surroundings

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.

1.3.5 Guideline

Carry out the following steps: = Start of a set of instructions.

1. First step in a sequence of operations.

Required settings **Setting values**

2. Second step in a sequence of operations.

↪ The result of this step.


✓ The operation is complete, the goal has been achieved.

2 Description

In this chapter you will find additional information regarding the parts of the wheel loader that are not described in the operator's manual.

- Parts of the wheel loader (Page 9)
- Front section (Page 10)
- Cab - interior (Page 11)

2.1 Parts of the wheel loader




Overview - Parts of the wheel loader

Key

No.	Designation	Function
1	Front section	See Chapter "Front section" (Page 10).
2	Cab - interior	See Chapter "Cab - interior" (Page 11).

2.2 Front section

2.2.1 Overview



Overview - Front section | Hydraulic hoses

Key

No.	Designation	Function
1	Hydraulic hoses	See section "Hydraulic hoses" (Page 10).

2.2.2 Hydraulic hoses

Hydraulic lines must be checked within the framework of the service intervals. Detailed instructions in this regard are to be found in BGR 237.

A recommendation as to the replacement intervals has been compiled on the basis of DIN 20066.


Depending on the demands made on the hoses, the specified replacement intervals can be extended. The replacement interval remains the responsibility of the operator.

Description of the replacement intervals of the hydraulic hoses

Demands on the hydraulic hose	Recommended replacement interval
Normal use	6 years (operating life, including a maximum of 2 years' storage)
Enhanced demands: <ul style="list-style-type: none"> Increased time in use; for example multi-shift operation or brief cycle times of the machine or pressure impulses Severe external and internal influences (via the medium) that markedly reduce the period of use of the hydraulic hose. manually-operated hydraulic tools, for example portable shears in scrap yards. 	2 years (operating life)

2.3 Cab - interior

2.3.1 Multi-function panel



Multi-function panel

Key


No.	Designation	Function
1	Display	See Chapter "Display" (Page 11).

2.3.2 Display

2.3.2.1 Overview

The function of the display is expanded in the new AS 1600 series. In the new component, CAN bus messages are displayed in addition to the familiar operating parameters. As a rule, these are error messages from the vehicle control system. The actual meaning of the error messages is described in Chapter "Error messages". An error message appears in the display for only as long as the cause remains active.


2.3.2.2 Start



Display – Start

Key

No.	Figure	Description
1		Engine speed control by M-Drive or accelerator.
2		Rear window is activated.
3		Unlocking of the quick-change device.
4		Boom suspension is activated.
5		A fault is present on the engine or wheel loader.




Display – Main menu

Key


No.	Description
1	Proceeds to the SETTINGS – DISPLAY (See page 14: Settings - Display) sub-menu.
2	Proceeds to the ENGINE AND VEHICLE MESSAGES (See page 15: Engine and vehicle messages) sub-menu.
3	Proceeds to the INFORMATION (See page 16: Information) sub-menu.
4	Proceeds to the SETTINGS – HYDRAULICS (See page 18: Settings - Hydraulics) sub-menu.

2.3.2.3 Settings - Display




Settings - Display

2.3.2.4 Engine and vehicle messages










Engine and vehicle messages

2.3.2.5 Information




Information

Figures – Information

Figure	Description	Unit
	Coolant temperature	degrees Celsius [°C]
	Engine oil pressure	bar
	Air filter differential pressure	bar
	Engine revolutions	Revolutions per minute [rpm]
	On-board voltage	Volt [V]
	Ash loading - diesel particulate filter	Percent [%]
	Fuel consumption	Litres per hour [l/h]


2.3.2.6 Settings - Hydraulics



Settings - Hydraulics

2.3.3 Central electrical system

With the implementation of the currently required emission directives, a new generation of vehicle control system has been introduced in the AS product segment. Electronic control of the power unit that is taken for granted in today's automotive industry in order to achieve the required emission values, has been enhanced in this stage of development to include electronic control of the hydraulic movement function. Furthermore, communication of the control signals has been optimised by the implementation of a CAN bus system between the control units in the vehicle.



Diagnosis interface - Overview

Key

No.	Designation	Function
1	Diagnosis interface - engine control system	The diagnostic unit is connected to the engine control system diagnosis interface. Further information regarding the diagnostic unit can be found in Section: "Diagnostic unit" (Page 20).
2	Diagnosis interface - vehicle control system	The diagnostic unit is connected to the vehicle control system diagnosis interface. Further information regarding the diagnostic unit can be found in Section: "Diagnostic unit" (Page 20).

2.3.4 Diagnostic unit

2.3.4.1 Overview

The stand-alone diagnostic unit (TKZ 23115585) serves as a reader to read and display engine and vehicle data from the CANbus system. In addition, stored error messages can be read and reset. The list of the error messages are to be found in Section Error messages (Page 20).

Active errors are displayed in the display. In addition, this error is stored in the main memory of the controller. The error memory is read and analysed within the framework of the recurring service.

Once the error has been processed, the error memory is deleted (reset).

The engine control diagnosis interface and the vehicle control diagnosis interface permit various diagnostic units to be used.



Diagnostic unit

2.3.5 Error messages

The controller messages that are shown in the display are listed in the following table. By using this information and a standard multimeter, the causes of the error can be identified and the function of the electrical components can be checked with tools available on the wheel-loader.

Errors from the engine control system are based on the mandatory SAE j1939 protocol. This is used internationally by various manufacturers.

The list of all messages from the "U05" engine controller are to be found in the annex of this service manual (See page 99: Annex).

Messages from the vehicle control system are generated as "M-messages (Mecalac)". As is the case with engine messages, they are shown in the display (only if active).

Error messages from the driving control system

Error	Meaning	Remedy
M002	Differential lock valve error	Check Valve Y55, check Circuit 1010
M003	Oil temperature sensor error	Check Sensor P06, check Circuit 1015 and GND_S2_U01
M004	Quick-change device error	Check Valve Y16/Y16A, check Circuit 1003
M005	Direction of travel valve error	Check Valves Y33 and Y34, check Circuits 1006, 1011
M006	Valve, burst pipe detection system, boom suspension error	Check Valves Y52, Y53; check Circuits 1004, 1005
M007	Inching pedal signal error	Check Sensor P05, check Circuit 1027
M008	Hand throttle signal error	Check Potentiometer JS05, check Circuit 1026
M009	Accelerator pedal signal error	Check Accelerator pedal P11, check Circuits 1016, 1017
M010	Engine communication error	Check Circuits CAN3-H, CAN3-L, check contact on Controller U01 and Engine Controller U05
M011	Controller communication error	Check Circuits CAN1-H, CAN1-L, check contact on Instrument U06 and Controller U01
M012	Option 1 control error	Check Relay K02, check Circuit 6003
M013	Option 3 control error	Check Relay K01, check Circuit 6015
M014	Option 4 control error	Check Relay K05, check Circuit 6016
M015	Control relay K14 (Kl.50) error	Check Relay K14, check Circuit 6009
M016	Traction pump valve error	Check Valve Y37, check Circuit 1024
M017	Parking brake valve error	Check Valve Y18, check Circuit 1040
M018	Steering valve error	Check Valves Y17, Y22 and Y29; check Circuits 1039, 1038 and 1037
M019	Clutch switch error	Check Switch SW42, check Circuit 1058
M020	Traction motor 1 error	Check Valve Y01A, check Circuit 1009
M021	Traction motor 2 error	Check Valve Y01B, check Circuit 1036
M022	Cluth valve error	Check Valve Y05, check Circuit 1044


3 Service tasks

In this chapter you will find information regarding service tasks for technical personnel:

- Checks (Page 23)
- Repair work (Page 36)
- Changing the consumables (Page 71)
- Lubrication (Page 93)

3.1 Checks

3.1.1 Checking the front axle oil level



Location of the bolts on the front axle

Key

No.	Designation
1	Filler plug
2	Oil level plug
3	Drain plug
4	Drain plug
5	Drain plug

**Requirement**

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.

**Tools required:**

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary
- New copper ring for sealing

**WARNING****Health hazard posed by gearbox oil!**

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE**Environmental hazard posed by gearbox oil!**


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:


1. Place an oil drip tray beneath the front axle.
 - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.

2. Using an Allen key, unscrew the oil level plug.



3. Catch any escaping gearbox oil in the oil drip tray immediately.
4. Check the oil level of the front axle.

! The oil level must reach precisely below the lower edge of the inspection port .




5. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .

! In order to top up, the filler plug must be unscrewed, see Chapter "Changing the gearbox oil of the front axle" (Page 74).

6. Fit a new copper ring.
7. Using an Allen key, secure the oil level plug.
8. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

✓ Done.

3.1.2 Checking the rear axle oil level



Location of the bolts on the rear axle

Key

No.	Designation
1	Filler plug
2	Oil level plug
3	Drain plug
4	Drain plug
5	Drain plug



Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary
- New copper ring for sealing



WARNING

Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by gearbox oil!


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the rear axle.
 - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.


2. Using an Allen key, unscrew the oil level plug.



3. Catch any escaping gearbox oil in the oil drip tray immediately.

4. Check the oil level of the rear axle.

! The oil level must reach precisely below the lower edge of the inspection port .



5. If required, top up with fresh gearbox oil up to the lower edge of the inspection port, see Chapter "Changing the gearbox oil of the rear axle" (Page 79).
6. Fit a new copper ring.
7. Using an Allen key, secure the oil level plug.
8. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

✓ Done.

3.1.3 Checking the planetary gear oil level



Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary



WARNING

Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE


Environmental hazard posed by gearbox oil!

The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:


1. Move the wheel loader so that the **Oil Level** fill level line of the planetary gear is horizontal.




2. Place an oil drip tray in the tyre rim.
→ The oil drip tray prevents the gearbox oil from penetrating the subsoil.
 3. Using an Allen key, unscrew the oil level plug.
 4. Catch any escaping gearbox oil in the oil drip tray immediately.
 5. Check the oil level of the planetary gear.
! The oil level must reach precisely below the lower edge of the inspection port .
 6. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .
 7. Using an Allen key, secure the oil level plug.
 8. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,
- ✓ Done.

3.1.4 Checking the transfer case oil level

The transfer case has two oil level plugs. One at the front (in the direction of travel) and one at the rear (in the direction of travel).



Location of the inspection and oil filler plug - at the front, in the direction of travel.



Location of the inspection and oil filler plug - at the rear, in the direction of travel.

**Requirement**

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.

**Tools required:**

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary

Oil level check - at
the front, in the
direction of travel

**WARNING****Health hazard posed by gearbox oil!**

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.


NOTICE**Environmental hazard posed by gearbox oil!**

The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Using an Allen key, unscrew the oil level plug.



2. Check the oil level of the transfer case.
! The oil level must reach precisely below the lower edge of the inspection port .
3. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .
4. Using an Allen key, secure the oil level plug.
5. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,


Done.

Oil level check - at
the rear, in the
direction of travel



Carry out the following steps:

1. Using an Allen key, unscrew the oil level plug.



2. Check the oil level of the transfer case.
! The oil level must reach precisely below the lower edge of the inspection port .
3. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .
4. Using an Allen key, secure the oil level plug.
5. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

Done.

✓ Done.

3.1.5 Checking the electrical functions and connections

Carry out the following steps:

1. Test all electrical functions
 2. Check that the electrical plugs and sockets are securely seated.
 - ↳ Fuses
 - ↳ Relays
 3. Perform a visual inspection of the cable harnesses.
 - ! Check that they are seated securely.
 4. Measure the battery voltage.
 5. Measure and check the functioning of the alternator.
 6. Check that the main battery switch functions correctly.
 7. Check that the bodywork is electrically isolated.
- ✓ Done.

3.1.6 Checking the hydraulic hoses

Carry out the following steps:

1. Check all hydraulic hoses for leaks and mechanical damage.
 - ! Detailed instructions are to be found in BGR 237.
 2. Exchange damaged hydraulic hoses immediately.
- ✓ Done.



Info

The recommended replacement intervals for the hydraulic hoses to be found in Chapter: "Description" > "Hydraulic hoses" (Page 10).

3.2 Repair work

3.2.1 Changing a wheel



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The direction of travel toggle switch must be in the neutral position.
- The ignition key has been removed.



Tools required:

- Two persons
- One jack suitable for the mass of the wheel loader
- A suitable base for the jack
- Safety block
- Protective gloves
- Wheel-brace
- A torque wrench
- A new wheel

Dismount the
wheel



CAUTION


Hazard of crush injuries to limbs!

The tyre of the wheel loader is large and heavy. You can be crushed if it tips over!


- ➔ Always wear protective gloves!
- ➔ Always wear safety shoes!
- ➔ Always work carefully!
- ➔ Always carry out a wheel change with two persons!

Carry out the following steps:

1. Using the wheel-brace loosen all ten wheel nuts by approximately half a turn.




2. Position a suitable base beneath the jack below the jacking points of the axle of the wheel to be changed.



3. Place the safety blocks centrally on the upper end of the jack.


4. Using the jack lift up the wheel loader.

! The wheel must be lifted approximately one centimetre off the ground.



→ The wheel has been lifted.

5. Using the wheel-brace remove all ten wheel nuts.



6. With two persons, carefully lift the wheel off the axle .

The wheel has been dismounted.

Mounting the
wheel.



Carry out the following steps:

1. With two persons, carefully lift the new wheel onto the axle .
2. Screw in the ten wheel nuts on the wheel loader.
! Only fasten the wheel nuts finger-tight.
3. Loosen the jack.
4. Remove the jack, the base and the safety blocks.

5. Tighten all ten wheel nuts to 550 Nm .
! For fastening, use a suitable torque wrench.



The wheel has been mounted.

✓ Done.




Info


After approximately ten hours of operation, re-tighten the wheel nuts of the wheel that has been changed.

3.2.2 Changing the air-conditioner V-belt

3.2.2.1 Fixing and tensioning screws



Location of the fixing and tensioning screws - view of the installation cover



Location of the fixing screws - view of the engine compartment

3.2.2.2 Removing the air-conditioner V-belt



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Protective gloves
- Suitable working platform
- New V-belt
- Ratchet with extension and SW 16 socket
- Wrench SW 16
- Allen key SW 6



CAUTION


Hazard of injuries to limbs by crushing and cutting!

The engine bay of the wheel loader is very cramped. You can be cut and crushed when performing maintenance tasks!


- ➔ Always wear protective gloves!
- ➔ Always work carefully!

Carry out the following steps:


1. Using the ratchet, loosen the four fixing screws of the installation cover.




2. Loosen the tensioning screw with the aid of an Allen key.



3. Loosen the belt tensioning screw with the aid of a ratchet.



4. Loosen the tensioning screw with the aid of an Allen key.



5. Remove the air-conditioner V-belt.



✓ Done.

3.2.2.3 Installing the air-conditioner V-belt



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The ignition key has been removed.
- The air-conditioner V-belt is installed (See "Removing the air-conditioner V-belt" (Page 41))



Tools required:

- Protective gloves
- Suitable working platform
- New V-belt
- Ratchet with extension and SW 16 socket
- Wrench SW 16
- Allen key SW 6



CAUTION

Hazard of injuries to limbs by crushing and cutting!

The engine bay of the wheel loader is very cramped. You can be cut and crushed when performing maintenance tasks!


- Always wear protective gloves!
- Always work carefully!

Carry out the following steps:


1. Fit the air-conditioner V-belt.




2. Tighten the tensioning screw with the aid of an Allen key.




3. Tension the V-belt by means of the belt tensioning screw.




4. Tighten the fixing screw with the aid of an Allen key.



5. Tighten the fixing screw with the aid of an Allen key.




6. Install the installation cover with the aid of the four fixing screws.




✓ Done.

3.2.3 Changing the alternator/water pump V-belt


3.2.3.1 Fixing and tensioning screws




Location of the fixing screw - view of the engine compartment



Location of the fixing screw - view of the engine compartment



Location of the fixing screw - view of the engine compartment



Location of the belt tensioning screw - view of the engine compartment

3.2.3.2 Removing the alternator/water pump V-belt



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The ignition key has been removed.
- The air-conditioner V-belt has been removed (See "Removing the air-conditioner V-belt" (Page 41))



Tools required:

- Protective gloves
- Suitable working platform
- New V-belt
- Ratchet with extension and SW 10 socket
- Ratchet with extension and SW 13 socket
- Wrench SW 10
- Wrench SW 13



CAUTION


Hazard of injuries to limbs by crushing and cutting!

The engine bay of the wheel loader is very cramped. You can be cut and crushed when performing maintenance tasks!


- ➔ Always wear protective gloves!
- ➔ Always work carefully!

Carry out the following steps:


1. Loosen the tensioning screw with the aid of an Allen key.




2. Loosen the tensioning screw with the aid of an Allen key.




3. Loosen the tensioning screw with the aid of an Allen key.



4. Loosen the belt tensioning screw with the aid of a ratchet.



5. Remove the alternator/water pump V-belt.

✓ Done.

3.2.3.3 Installing the alternator/water pump V-belt



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The ignition key has been removed.
- The alternator/water pump V-belt has been removed (See "Removing the alternator/water pump V-belt" (Page 49))



Tools required:

- Protective gloves
- Suitable working platform
- New V-belt
- Ratchet with extension and SW 10 socket
- Ratchet with extension and SW 13 socket
- Wrench SW 10
- Wrench SW 13



CAUTION


Hazard of injuries to limbs by crushing and cutting!

The engine bay of the wheel loader is very cramped. You can be cut and crushed when performing maintenance tasks!

- ➔ Always wear protective gloves!
- ➔ Always work carefully!

Carry out the following steps:


1. Install the alternator/water pump V-belt.




2. Tension the V-belt by means of the belt tensioning screw.




3. Tighten the tensioning screw with the aid of an Allen key.



4. Tighten the tensioning screw with the aid of an Allen key.



5. Tighten the tensioning screw with the aid of an Allen key.



✓ Done.

3.2.4 Changing the fuel pre-filter



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



Tools required:

- Strap wrench
- Protective gloves
- A new fuel pre-filter

Changing the fuel
pre-filter



WARNING

Fire hazard due to ignition of the diesel fuel!

Burns may result. In addition, the wheel loader will be damaged by the fire!

- ➔ Smoking is prohibited when working on the fuel filter of the wheel loader!
- ➔ Immediately clean up any diesel fuel that has spilled.



WARNING

Health hazard posed by diesel fuel!

The diesel fuel is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the diesel fuel.
- ➔ Always wear gloves when carrying out this job.

NOTICE


Environmental hazard posed by diesel fuel!

The diesel fuel used by the wheel loader is hazardous to the environment!


- ➔ Dispose of the diesel fuel according to the local statutory provisions,
- ➔ Catch the draining diesel fuel in a suitable container.
- ➔ Prevent the diesel fuel from entering the soil.

Carry out the following steps:

1. Carefully detach the connection cable for the water level sensor .




2. Place the strap of the strap wrench around the fuel pre-filter.
3. Loosen the fuel pre-filter with the aid of the strap wrench.



4. Carefully pull the fuel pre-filter from the mounting.

5. Unscrew the water separator valve from the fuel pre-filter .



6. Fasten the water separator valve onto the new fuel pre-filter .
7. Screw the new fuel pre-filter into the mounting.
8. Install the connection cable for the water level sensor.

The fuel pre-filter has been changed.

Bleeding the fuel system



Carry out the following steps:

1. Insert the ignition key of the wheel loader into the ignition lock.
2. Turn the ignition key clockwise to Position **I**.
 - ↪ The ignition system of the wheel loader is switched on.
 - ↪ The fuel feed pump is switched on.
3. Wait 20 seconds.
4. Turn the ignition key anti-clockwise to Position **0**.
 - ↪ The ignition system of the wheel loader is switched off.
5. Repeat steps <1 TO 4> twice.
 - ↪ The fuel system is bled piece by piece.
 - ↪ The fuel pressure required for operation is built up.

The fuel system has been bled.

✓ Done.

3.2.5 Changing the fuel filter



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



Tools required:

- Strap wrench
- Protective gloves
- two new fuel filters



WARNING

Fire hazard due to ignition of the diesel fuel!

Burns may result. In addition, the wheel loader will be damaged by the fire!

- Smoking is prohibited when working on the fuel filter of the wheel loader!
- Immediately clean up any diesel fuel that has spilled.



WARNING

Health hazard posed by diesel fuel!

The diesel fuel is hazardous to health. Frequent skin contact can be carcinogenic.

- Avoid continuous skin contact with the diesel fuel.
- Always wear gloves when carrying out this job.

NOTICE


Environmental hazard posed by diesel fuel!

The diesel fuel used by the wheel loader is hazardous to the environment!

- Dispose of the diesel fuel according to the local statutory provisions,
- Catch the draining diesel fuel in a suitable container.
- Prevent the diesel fuel from entering the soil.

Carry out the following steps:

1. Place the strap of the strap wrench around the first fuel filter.
2. Loosen the fuel filter with the aid of the strap wrench.



3. Carefully pull the fuel filter from both the mounting.
 4. Screw the new fuel filter into the mounting.
- ✓ Done.

3.2.6 Changing the hydraulic fluid filter



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



Tools required:

- Protective gloves
- Oil-absorbent mat
- Oil drip tray
- Drainage hose with Bochumer socket
- A new hydraulic fluid filter
- A suitable tool for the cap of the hydraulic fluid reservoir

Drain the excess
hydraulic fluid



WARNING

Health hazard posed by hydraulic fluid!

The hydraulic fluid is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the hydraulic fluid.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by hydraulic fluid!


The used hydraulic fluid of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used hydraulic fluid according to the local statutory provisions,
- ➔ Catch the draining hydraulic fluid in a suitable container.
- ➔ Prevent the hydraulic fluid from entering the soil.


Carry out the following steps:

1. Place the oil-absorbent mats around the hydraulic fluid reservoir.
 - ➔ The oil-absorbent mat protect the interior of the engine bay from contamination.

2. Loosen the protective cap of the hydraulic fluid reservoir drain valve.



3. Screw the drainage hose onto the drain valve of the hydraulic fluid reservoir.
! Catch the draining hydraulic fluid in a suitable container.



- ↪ The excess hydraulic fluid begins draining.
4. Wait until the excess hydraulic fluid has drained completely.
 5. Unscrew the drainage hose from the drain valve of the hydraulic fluid reservoir.
 6. Fasten the protective cap of the hydraulic fluid reservoir drain valve.

The excess hydraulic fluid has been drained.

Remove the
hydraulic fluid filter



WARNING

Health hazard posed by hydraulic fluid!

The hydraulic fluid is hazardous to health. Frequent skin contact can be carcinogenic.

- Avoid continuous skin contact with the hydraulic fluid.
- Always wear gloves when carrying out this job.

NOTICE


Environmental hazard posed by hydraulic fluid!

The used hydraulic fluid of the wheel loader is hazardous to the environment!


- Dispose of the used hydraulic fluid according to the local statutory provisions,
- Catch the draining hydraulic fluid in a suitable container.
- Prevent the hydraulic fluid from entering the soil.

Carry out the following steps:


1. Using a suitable tool, loosen the cap of the hydraulic fluid reservoir.



2. Unscrew the cap by hand.



3. Withdraw the hydraulic fluid filter by the handle .



4. Allow the surplus hydraulic fluid to run into the hydraulic fluid reservoir .



5. Place the hydraulic fluid filter in the oil drip tray.
! The oil drip tray must be held by a second person.

The hydraulic fluid filter is dismantled.

Install the
hydraulic fluid filter



Carry out the following steps:

1. Insert the new hydraulic fluid filter into the hydraulic fluid reservoir .
! The hydraulic fluid filter must engage.
2. Screw the lid back onto the hydraulic fluid reservoir by hand.
3. Using a suitable tool, tighten the cap on the hydraulic fluid reservoir.
4. Remove the oil-absorbent mats.

5. Dispose of the hydraulic fluid that has been collected, according to the local statutory provisions,

The hydraulic fluid filter is installed.

✓ Done.

3.2.7 Changing the engine oil filter



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



Tools required:

- Strap wrench
- Protective gloves
- A new engine oil filter
- Oil drip tray

Dismounting the
engine oil filter



WARNING

Health hazard posed by engine oil!

The engine oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the engine oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by engine oil!


The used engine oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used engine oil according to the local statutory provisions,
- ➔ Catch the draining engine oil in a suitable container.
- ➔ Prevent the engine oil from entering the soil.

Carry out the following steps:

1. Place the oil drip tray beneath the engine oil filter.
 - ➔ The oil drip tray prevents the engine oil from penetrating the subsoil or entering the interior of the engine bay.
2. Place the strap of the strap wrench around the engine oil filter.

3. Loosen the engine oil filter with the aid of the strap wrench.



4. Carefully pull the engine oil filter from both the hose ends .

The engine oil filter has been removed.

Install the new
engine oil filter



Carry out the following steps:

1. Coat the sealing surfaces of the new engine oil filter with fresh lubricating oil.
2. Screw the new engine oil filter into the mounting.
3. Tighten the engine oil filter by hand.
4. Check the oil level of the engine.
5. Dispose of the engine oil that has been collected, according to the local statutory provisions,

The new engine oil filter has been installed.

✓ Done.

3.2.8 Changing the air filter



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



Tools required:

- A new air filter cartridge
- A new safety cartridge

Remove the air
filter cartridge




Carry out the following steps:

1. Open the cladding closure.



2. Remove the cladding.




3. Open the three locking mechanisms of the lid.



4. Remove the air filter cartridge.

! Loosen the air filter cartridge with gentle rotating movements left and right.



The air filter cartridge has been removed.


Exchanging the
safety cartridge.



Carry out the following steps:


1. Remove the safety cartridge.

! Loosen the safety cartridge with gentle rotating movements left and right.




2. Check the interior of the filter housing for dust and dirt.

! If necessary, carefully clean the interior of the filter housing with a cloth.



3. Slide the new safety cartridge carefully into the filter housing.



The safety cartridge has been exchanged.

Re-install the air
filter cartridge




Carry out the following steps:

1. Slide the new air filter cartridge into the holder.



2. Re-install the lid.

! When re-installing, take care that the dust ejection valve faces downwards .

3. Secure the three locking mechanisms of the lid.**4.** Install the cladding.

The air filter cartridge has been installed.

✓ Done.

3.3 Changing the consumables

3.3.1 Changing the engine oil



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The ignition key has been removed.
- The engine must be warm.



Tools required:

- A sufficiently large oil collection container
- a drainage hose with Bochumer socket
- Wrench SW 13
- Protective gloves

Draining the
engine oil



WARNING

Health hazard posed by engine oil!

The engine oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the engine oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by engine oil!


The used engine oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used engine oil according to the local statutory provisions,
- ➔ Catch the draining engine oil in a suitable container.
- ➔ Prevent the engine oil from entering the soil.

Carry out the following steps:

1. Loosen the two mounting screws of the sump guard.
2. Remove the sump guard.
3. Place the oil drip tray next to the wheel loader.

4. Unscrew the protective cap from the engine oil drain valve.



5. Screw the drainage hose onto the engine oil drain valve.
! Catch the draining engine oil in a suitable container.



→ The engine oil begins draining.

6. Wait until the engine oil has drained completely.
7. Unscrew the drainage hose from the engine oil drain valve.
8. Screw the protective cap onto the engine oil drain valve.


The engine oil has been drained.

Topping up the engine oil



Carry out the following steps:

1. Open the cap of the engine oil filler nozzle.



2. Using a suitable funnel pour the engine oil into the open engine oil filler nozzle.
3. Close the cap of the engine oil filler nozzle.
4. Wipe off any spilled engine oil with a cloth .

The engine oil has been changed.

Performing the check




Carry out the following steps:

1. Switch on the diesel engine.
2. Allow the diesel engine to idle for a short while.
3. Switch off the diesel engine.
4. Inspect the sump and the oil drain plug for leaks.
5. Remove the oil collection container.
6. Re-install the sump guard on the wheel loader using the two mounting screws.
7. Dispose of the engine oil that has been collected according to the local statutory provisions.
8. Using the engine oil dipstick, check the engine oil level.
9. Top up the engine oil as required.

The check is complete.

✓ Done.

3.3.2 Changing the gearbox oil of the front axle



Location of the bolts on the front axle

Key

No.	Designation
1	Filler plug
2	Oil level plug
3	Drain plug
4	Drain plug
5	Drain plug



Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Allen key SW 12
- new copper sealing ring
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

Draining the
gearbox oil



WARNING

Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by gearbox oil!


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.


Carry out the following steps:

1. Place an oil drip tray beneath the front axle.
 - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.

2. Using an Allen key, unscrew the oil level plug.



3. Using an Allen key, unscrew the three oil drain plugs.



↪ The gearbox oil drains immediately.

4. Wait until the gearbox oil has drained completely.
5. Using an Allen key, screw the three drain plugs back into the front axle.


The gearbox oil has been drained.

Refilling the gearbox oil




Carry out the following steps:

1. Using an Allen key, unscrew the oil drain plug.



2. Pour fresh gearbox oil into the filler gallery until the oil level reaches the lower edge of the inspection port.



3. Fit a new copper ring in the inspection port.
4. Using an Allen key, secure the oil level plug.
5. Using an Allen key, secure the oil filler plug.
6. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.


Performing the
check



Carry out the following steps:

1. Check that the axle vent valve is free of contamination.

! If necessary, clean the axle vent valve .




2. Inspect the rear axle and the oil drain bolt for leaks.

The check is complete.

✓ Done.

3.3.3 Changing the gearbox oil of the rear axle



Location of the bolts on the front axle

Key

No.	Designation
1	Filler plug
2	Oil level plug
3	Drain plug
4	Drain plug
5	Drain plug



Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil
- new copper ring for sealing the inspection port

Draining the
gearbox oil



WARNING

Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by gearbox oil!


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.


Carry out the following steps:

1. Place an oil drip tray beneath the rear axle.
 - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.

2. Using an Allen key, unscrew the oil level plug.



3. Using an Allen key, unscrew the three oil drain plugs.



↪ The gearbox oil drains immediately.


4. Wait until the gearbox oil has drained completely.
5. Using an Allen key, screw the three drain plugs back into the rear axle.

The gearbox oil has been drained.


Refilling the
gearbox oil

Carry out the following steps:

1. Using an Allen key, unscrew the oil drain plug.



2. Pour fresh gearbox oil into the filler gallery until the oil level reaches the lower edge of the inspection port.



3. Fit a new copper ring in the inspection port.
4. Using an Allen key, secure the oil level plug.
5. Using an Allen key, secure the oil filler plug.
6. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,


The gearbox oil has been refilled.

Performing the
check



Carry out the following steps:

1. Check that the axle vent valve is free of contamination.
! If necessary, clean the axle vent valve .



2. Inspect the rear axle and the oil drain bolt for leaks.

The check is complete.

✓ Done.

3.3.4 Changing the gearbox oil of the planetary gear



Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

Draining the
gearbox oil



WARNING

Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by gearbox oil!

The used gearbox oil of the wheel loader is hazardous to the environment!


- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Move the wheel loader so that the oil level plug of the planetary gear is at the lowest position.



2. Place an oil drip tray in the tyre rim.
↳ The oil drip tray prevents the gearbox oil from penetrating the subsoil.
3. Using an Allen key, unscrew the oil level plug.




- ↳ The gearbox oil drains immediately.
4. Wait until the gearbox oil has drained completely.
5. Using an Allen key, fasten the oil level plug in teplanetary gear.

The gearbox oil has been drained.


Refilling the
gearbox oil

Carry out the following steps:

1. Move the wheel loader so that the inspection plug of the planetary gear is horizontal .



2. Using an Allen key, unscrew the oil level plug.




3. Pour fresh gearbox oil into the inspection port.
! The oil level must reach precisely below the lower edge of the inspection port .
4. Using an Allen key, secure the oil level plug.
5. Wipe off any escaping gearbox oil with a cloth .
6. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.

✓ Done.


3.3.5 Changing the gearbox oil of the reduction gear



Location of the bolts on the the of the reduction gear

Key

No.	Designation
1	Filler and inspection plug
2	Drain plug



Location of the bolts on the of the reduction gear

Key

No.	Designation
1	Filler and inspection plug



Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

Draining the
gearbox oil



WARNING

Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- Avoid continuous skin contact with the gearbox oil.
- Always wear gloves when carrying out this job.

NOTICE


Environmental hazard posed by gearbox oil!

The used gearbox oil of the wheel loader is hazardous to the environment!


- Dispose of the used gearbox oil according to the local statutory provisions,
- Catch the draining gearbox oil in a suitable container.
- Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the reduction gear.
 - The oil drip tray prevents the gearbox oil from penetrating the subsoil.
2. Using an Allen key, unscrew the filler and inspection plug.



3. Using an Allen key, unscrew the oil drain plug.



↪ The gearbox oil drains immediately.

4. Wait until the gearbox oil has drained completely.
5. Using an Allen key, secure the oil drain plug.

The gearbox oil has been drained.

Refilling the
gearbox oil



Carry out the following steps:

1. Pour fresh gearbox oil into the reduction gear.
! The oil level must reach precisely below the lower edge of the inspection port .
2. Using an Allen key, screw in the filler and inspection plug until tight.
3. Remove the oil collection container.
4. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.

✓ Done.

3.3.6 Topping up the hydraulic fluid



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The ignition key has been removed.
- The parking brake is applied.



Tools required:

- Cloths
- Protective gloves
- Wrench SW 30
- Suitable, fresh gearbox oil

Carry out the following steps:

1. Using a ratchet, unscrew the screw plug for topping up the hydraulic fluid.
2. Pour in the hydraulic fluid.
3. Using a ratchet, screw in the screw plug for topping up the hydraulic fluid until tight.
4. Wipe off any spilled hydraulic fluid with a cloth .

✓ Done.

3.3.7 Refilling with diesel fuel



Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The ignition key has been removed.
- The parking brake is applied.



Tools required:

- Cloths
- Ignition key
- Protective gloves
- Allen key SW 6
- Diesel fuel collection container
- suitable fresh diesel fuel

Drain the diesel
fuel



WARNING

Fire hazard due to ignition of the diesel fuel!

Burns may result. In addition, the wheel loader will be damaged by the fire!

- ➔ Refuel the wheel loader only once it has cooled down.
- ➔ Smoking is **strictly prohibited** when refuelling the wheel-loader!
- ➔ Immediately clean up any diesel fuel that has spilled.



WARNING

Health hazard posed by diesel fuel!

The diesel fuel is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the diesel fuel.
- ➔ Always wear gloves when carrying out this job.

NOTICE

Environmental hazard posed by diesel fuel!

The diesel fuel used by the wheel loader is hazardous to the environment!

- ➔ Dispose of the diesel fuel according to the local statutory provisions,
- ➔ Catch the draining diesel fuel in a suitable container.
- ➔ Prevent the diesel fuel from entering the soil.

Carry out the following steps:

1. Place a diesel fuel collection container beneath the diesel fuel tank.
 - ➔ The diesel fuel collection container prevents the diesel fuel from penetrating the subsoil.

2. Using an Allen key, unscrew the oil drain plug.



→ The diesel fuel drains immediately.

3. Wait until the diesel fuel has drained completely.
4. Using an Allen key, secure the oil drain plug.

The diesel fuel has been drained.

Refilling diesel fuel Carry out the following steps:



1. Open the tank cap of the diesel fuel filling nozzle.
2. Carefully pour the diesel fuel into the tank.
3. Close the tank cap of the diesel fuel filling nozzle.
4. Wipe off any spilled diesel fuel with a cloth .

The diesel fuel has been topped up.

✓ Done.

3.4 Lubrication

In this chapter you will find information regarding the lubrication of the wheel loader.


3.4.1 Lubrication plan

In this chapter you will find information regarding the greasing of the wheel loader. In addition, you may find further lubrication points on the installed attachments.

Swing loader lubrication plan AS 1600


Lubrication intervals	Part on wheel loader	Number of lubrication points
after 50 hours of operation	Front and rear axles	8 lubrication points, see Section "Lubrication points - front and rear axles" (Page 93).
	Interior of engine compartment	2 lubrication points, see Section "Lubrication points - interior of engine compartment" (Page 94).
after 500 hours of operation	Turntable chain	See Section "Lubricating the turntable chain" (Page 94)
	Return	See Section "Return" (Page 96)
	Support valve	See Section "Support valve" (Page 96)

3.4.2 Lubrication points - front and rear axles



Front and rear axles | 2 kingpin lubrication points per wheel

3.4.3 Lubrication points - interior of engine compartment



Interior of engine compartment | 2 lubrication points

3.4.4 Lubricating the turntable chain



Requirement

- The wheel loader is standing on a horizontal surface.
- The parking brake is applied.



Tools required:

- A second person who operates the wheel loader.
- Protective gloves
- Suitable working platform
- Grease brush
- Multi-purpose grease
- Wrench SW 13



CAUTION

Hazard of injuries to limbs by crushing and cutting!


The engine bay of the wheel loader is very cramped. You can be cut and crushed when performing maintenance tasks!

- ➔ Always wear protective gloves!
- ➔ Always work carefully!


Carry out the following steps:

1. Lift the lift arm
2. Secure the lift arm support.

- 3.** Using an Allen key, loosen the protective plate of the turntable chain.




- 4.** Slowly move the lift arm completely to the right and to the left once.
! While moving, lubricate the turntable chain by means of a grease brush.




- ✓ The turntable chain has been lubricated.

3.4.5 Return



Lubricate fork, return and roller

3.4.6 Support valve



Support valve

4 Circuit diagrams


Circuit diagrams can be obtained from Mecalac on request.

5 Annex

5.1 Spare Parts

5.1.1 Filter

5.1.1.1 Filter set after 500 operating hours




Filter set after 500 operating hours – Overview

Key

No.	Designation	Mecalac TKZ
1	Filter set after 500 operating hours	23133676
2	Engine oil filter	23110650
3	Fuel filter	23133679
4	Air filter insert	4110553A
5	Safety cartridge	4110552A
6	Hydraulic fluid filter	23133680
7	O-ring	4197692A

5.1.1.2 Filter set after 1000 operating hours



Filter set after 1000 operating hours – Overview

Key

No.	Designation	Mecalac TKZ
1	Filter set after 1000 operating hours	23133677
2	Engine oil filter	23110650
3	Fuel filter	23133679
4	Fuel pre-filter	23133338
5	Round sealing ring	23124774
6	Air filter insert	4110553A
7	Safety cartridge	4110552A
8	Hydraulic fluid filter	23133680
9	O-ring	4197692A
10	Breather filter	6050206

5.1.2 Consumables

Key

Designation	Quantity	Mecalac TKZ
Engine oil	8,0 Litre	2320062
Gearbox oil	35,8 Litre	23104578
Hydraulic fluid	140,0 Litre	6761056
Lubricating grease cartridge	1	4117807
Coolant	19,0 Litre	23129554
Gearbox oil/transfer box oil	3,4 Litre	2320066

5.2 Deutz error messages

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



Deutz-Code / SPN / Fehlername	Seite
11 / 107 / AirFitSysReac	3
12 / 91 / APP1	3
14 / 91 / APPWm	3
15 / 91 / APPWmPer	4
16 / 108 / APSCD	4
17 / 729 / ArH1	4
18 / 730 / ArH2	5
19 / 676 / ArHCD_NoLd	5
20 / 676 / ArHCD_RlyErr	5
22 / 168 / BattCD	6
23 / 168 / BattCDSysReac	6
24 / 523561 / BIPCy1	6
25 / 523562 / BIPCy2	7
26 / 523563 / BIPCy3	7
27 / 523564 / BIPCy4	7
28 / 523565 / BIPCy5	8
29 / 523566 / BIPCy6	8
30 / 523567 / BIPCy7	8
31 / 523568 / BIPCy8	9
32 / 102 / BPSCD	9
33 / 102 / BPSCDSysReac	9
37 / 111 / CLSCDSysReac	10
38 / 1323 / CmbChbMisfire1	10
39 / 1324 / CmbChbMisfire2	10
40 / 1325 / CmbChbMisfire3	11
41 / 1326 / CmbChbMisfire4	11
42 / 1327 / CmbChbMisfire5	11
43 / 1328 / CmbChbMisfire6	12
44 / 1450 / CmbChbMisfire7	12
45 / 1451 / CmbChbMisfire8	12
46 / 1322 / CmbChbMisfireMul	13
47 / 1346 / CmbChbSysReac	13
48 / 1109 / CoEngShOffDemlgr	13
52 / 1072 / CRERCD	14
53 / 1081 / CSLpCD	14
54 / 704 / CTLpCD	14
55 / 110 / CTSCD	15

Deutz-Code / SPN / Fehlername	Seite
56 / 110 / CTSCDSysReac	15
57 / 701 / Dummy1CD_Max	15
58 / 701 / Dummy1CD_Min	16
59 / 701 / Dummy1CD_SigNpl	16
60 / 702 / Dummy2CD_Max	16
61 / 702 / Dummy2CD_Min	17
62 / 702 / Dummy2CD_SigNpl	17
69 / 2791 / EGRCD_Max	17
70 / 2791 / EGRCD_Min	18
71 / 2791 / EGRCD_SigNpl	18
72 / 2791 / EGRCDIntEGR	18
74 / 923 / EngCDTrqCalcOut	19
75 / 190 / EngMBackUp	19
76 / 190 / EngMCaS1	19
77 / 190 / EngMCrS1	20
78 / 190 / EngMOfsCaSCrS	20
79 / 190 / EngPrtSysReacFOC	20
80 / 190 / EngPrtSysReacORC	21
81 / 703 / ESLpCD	21
82 / 1074 / EXFICD	21
83 / 975 / FanCD	22
85 / 1639 / FanCDEval	22
86 / 523602 / FanCDSysReac	22
87 / 97 / FIFCD	23
89 / 97 / FIFCD_WtLVl	23
90 / 94 / FIPSCD	23
91 / 94 / FIPSCDSysReac	24
94 / 523239 / FrmMngDecv1	24
95 / 523240 / FrmMngFunModOil	24
106 / 523212 / FrmMngTOEngPrt	25
110 / 523216 / FrmMngTOPrHtEnCmd	25
112 / 523218 / FrmMngTORxCCVS	25
113 / 523604 / FrmMngTORxEngTemp	26
117 / 523238 / FrmMngTOSwtOut	26
118 / 523222 / FrmMngTOTCO1	26
120 / 523605 / FrmMngTOTSC1AE	27
121 / 523606 / FrmMngTOTSC1AR	27

Deutz-Code / SPN / Fehlername	Seite
122 / 523607 / FrmMngTOTSC1DE	27
123 / 523608 / FrmMngTOTSC1DR	28
124 / 523609 / FrmMngTOTSC1PE	28
125 / 898 / FrmMngTOTSC1TE	28
126 / 520 / FrmMngTOTSC1TR	29
127 / 523610 / FrmMngTOTSC1VE	29
128 / 523611 / FrmMngTOTSC1VR	29
131 / 523500 / FrmMngTxTO	30
133 / 174 / FTSCD	30
134 / 174 / FTSCDSysReac	30
136 / 523618 / GOTSCD	31
137 / 523619 / GOTSCDSysReac	31
138 / 29 / HdThrt	31
139 / 1638 / HOTSCD	32
140 / 1638 / HOTSCDSysReac	32
141 / 523617 / HWEMonCom	32
142 / 630 / HWEMonEEPROM	33
143 / 523612 / HWEMonRcyLocked	33
144 / 523612 / HWEMonRcySuppressed	33
145 / 523612 / HWEMonRcyVisible	34
146 / 523612 / HWEMonUMaxSupply	34
147 / 523612 / HWEMonUMinSupply	34
149 / 105 / IATSCD	35
150 / 105 / IATSCDSysReac	35
153 / 523350 / InjVlvBnk1A	35
154 / 523351 / InjVlvBnk1B	36
155 / 523352 / InjVlvBnk2A	36
156 / 523353 / InjVlvBnk2B	36
157 / 523354 / InjVlvChipA	37
158 / 523355 / InjVlvChipB	37
159 / 651 / InjVlvCyl1A	37
160 / 651 / InjVlvCyl1B	38
161 / 652 / InjVlvCyl2A	38
162 / 652 / InjVlvCyl2B	38
163 / 653 / InjVlvCyl3A	39
164 / 653 / InjVlvCyl3B	39
165 / 654 / InjVlvCyl4A	39

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software

P490_ : 220, 310, 501

P491_ : 220, 310, 400, 501

P492_ : 213

P513_ : 214, 300



Deutz-Code / SPN / Fehlername	Seite
166 / 654 / InjVlvCyl4B	40
167 / 655 / InjVlvCyl5A	40
168 / 655 / InjVlvCyl5B	40
169 / 656 / InjVlvCyl6A	41
170 / 656 / InjVlvCyl6B	41
171 / 657 / InjVlvCyl7A	41
172 / 657 / InjVlvCyl7B	42
173 / 658 / InjVlvCyl8A	42
174 / 658 / InjVlvCyl8B	42
175 / 523370 / InjVlvErrDet	43
176 / 523615 / MeUnCD_ADC	43
177 / 523615 / MeUnCDNoLoad	43
178 / 523615 / MeUnCDSCBat	44
179 / 523615 / MeUnCDSCGnd	44
182 / 2634 / MnRly1_SCB	44
183 / 2634 / MnRly1_SCG	45
184 / 523420 / Montir	45
186 / 2634 / MRlyCD	45
187 / 563 / MRlyCDMnRly2	46
188 / 2634 / MRlyCDMnRly3	46
189 / 523450 / MSSCD1	46
190 / 523451 / MSSCD2	47
191 / 523452 / MSSCD3	47
192 / 639 / NetMngCANAOff	47
193 / 1231 / NetMngCANBOff	48
194 / 1235 / NetMngCANCOff	48
195 / 705 / OPLpCD	48
196 / 100 / OPSCD	49
197 / 100 / OPSCD1	49
198 / 100 / OPSCDSysReachHi	49
199 / 100 / OPSCDSysReacLo	50
200 / 1237 / OSwCD	50
201 / 175 / OTSCD	50
203 / 175 / OTSCDSysReac	51
208 / 523470 / PRVMon	51
209 / 157 / RailCD	51
210 / 157 / RailCDOfsTst	52

Deutz-Code / SPN / Fehlername	Seite
211 / 523613 / RailMeUn0	52
212 / 523613 / RailMeUn1	52
213 / 523613 / RailMeUn2	53
214 / 523613 / RailMeUn3	53
215 / 523613 / RailMeUn4	53
216 / 523613 / RailMeUn7	54
218 / 523490 / SOPTst	54
219 / 1079 / SSpMon1	54
221 / 1080 / SSpMon2	55
222 / 523601 / SSpMon3	55
223 / 677 / StrtCDHS	55
224 / 677 / StrtCDLS	56
225 / 624 / SysLamp	56
226 / 158 / T15CD	56
227 / 523550 / T50CD	57
228 / 523550 / TPUMon	57
232 / 84 / VSSCD1	57
235 / 523600 / WdCom	58
236 / 523470 / PRVMonSysReac	58
237 / 523006 / APPCDSwtnSel	58
238 / 523007 / FrmMng_TORxEngPress	59
239 / 523008 / MplClt	59
240 / 98 / OLSCD	59
241 / 98 / OLSCDSysReachHi	60
242 / 107 / ADPSCDAna	60
243 / 98 / OLSCDSysReacLo	60
244 / 523009 / PrvMonWear	61
245 / 523010 / RailMeUn8	61
246 / 523650 / FISys_FLPFMSysReac	61
247 / 523651 / FISys_FTSFMSysReac	62
248 / 523652 / FISys_FlushStateEngineOff	62
249 / 523653 / FISys_RapeOilHeatEx	62
250 / 523654 / FrmMngDieselLv	63
251 / 523655 / FrmMngFuelTemp	63
252 / 523656 / FrmMngLowPressureDiesel	63
253 / 523657 / FrmMngRapeOilIn	64
254 / 523658 / FrmMngRapeOilLv	64

Deutz-Code / SPN / Fehlername	Seite
255 / 523659 / FrmMngRapeOilVlv1	64
256 / 523660 / FrmMngRapeOilVlv2	65
257 / 523661 / FrmMngRapeOilVlv3	65
258 / 523662 / FrmMngRapeOilVlv4	65
259 / 523663 / FrmMngRapeOilVlv5	66
260 / 523664 / FrmMngSTIN1RX	66

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



11 / 107 / AirFitSysReac

Error description AIR FILTER COND.

Air filter differential pressure: the pressure difference of the intake air between the filter inlet and outlet calculated by ECU is above the target range and the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 11

BlinkCode (short-long-short): 1 - 3 - 6

SPN: 107

possible FMI:

- 0: data valid, but above normal working area
- 12: Errorcode not identifiable
- 12: Errorcode not identifiable
- 12: Errorcode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Pressure loss above target range with system reaction, air filter clogged or defective, sensor not working, connection cable damaged

Take actions for error repair

Check airfilter and if necessary clean or renew it, check cabling, check air filter and if necessary replace the filter component, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning or Warning and power reduction

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: actual value

12 / 91 / APP1

Error description THROTTLE 1

Analog accelerator pedal sensor 1 or double accelerator pedal sensor: the voltage measured by ECU is out of the target range or the calculated pedal position is implausible compared with the position of the second pedal

Error codes

DEUTZ-Errorcode: 12

BlinkCode (short-long-short): 2 - 2 - 6

SPN: 91

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errorcode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Voltage outside target range, signal implausible compared to signal of redundant pedal (analog pedal 1), sensor defective, connection cable damaged

Take actions for error repair

Check cabling, check accelerator pedal sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, switching to substitute value

Behaviour error lamp: Priority-Chain or Limp Home

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

14 / 91 / APPWm

Error description THROTTLE 1

Digital accelerator pedal sensor (PWM): the signal received by ECU is defective or implausible or the pulse-duty factor is out of the target range

Error codes

DEUTZ-Errorcode: 14

BlinkCode (short-long-short): 2 - 2 - 2

SPN: 91

possible FMI:

- 8: unusual frequency, pulse or period.
- 8: unusual frequency, pulse or period.
- 2: data stream is defective
- 8: unusual frequency, pulse or period.

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Duty cycle outside target range, signal erroneous or implausible (pedal 1), sensor defective, connection cable damaged

Take actions for error repair

Check cabling, check accelerator pedal sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, switching to substitute value

correspond to Priority-Chain or Limp Home

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



15 / 91 / APPWmPer

Error description THROTTLE 1

digital accelerator pedal sensor (PWM): the frequency of the signal received by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 15

BlinkCode (short-long-short): 2 - 2 - 2

SPN: 91

possible FMI:

- 8: unusual frequency, pulse or period.
- 8: unusual frequency, pulse or period.
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Pulse frequency outside target range (pedal 1), sensor defective, connection cable damaged

Take actions for error repair

Check cabling, check accelerator pedal sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, switching to substitute value correspond to Priority-Chain or Limp Home

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

16 / 108 / APSCD

Error description BAROMETRIC PRESS.

Ambient air pressure sensor (in ECU): the voltage measured by ECU is out of the target range or the calculated ambient air pressure is implausible compared with the charge air pressure

Error codes

DEUTZ-Errorcode: 16

BlinkCode (short-long-short): 2 - 9 - 2

SPN: 108

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Ambient air pressure sensor defective, ECU defective

Take actions for error repair

Change ECU

other error properties

System reaction: Warning, substitute value (0.85bar)

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

17 / 729 / ArHt1

Error description AIR HEATER RELAY

Air heater relay: the current drain measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 17

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 729

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit at EDC output, relay defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check relay and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: shut off value

18 / 730 / ArHt2**Error description AIR HEATER VALVE**

Air heater magnet valve: the current drain measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 18

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 730

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

Take actions for error repair

Check valve and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: shut off value

19 / 676 / ArHtCD_NoLd**Error description AIR HEATER**

Air heater relay: the ECU detects no switching operation at the input of a readback process

Error codes

DEUTZ-Errorcode: 19

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 676

possible FMI:

- 12: Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Relay energized, but no feedback on sense line, relay defective or wrong wired, preheat component defective, connection cable damaged

Take actions for error repair

Check cabling of preheat component, if relay not working check relay and if necessary replace it, check preheat component and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: setpoint for output status

20 / 676 / ArHtCD_RlyErr**Error description AIR HEATER**

Air heater relay: the ECU detects an implausible signal at the input of a readback process

Error codes

DEUTZ-Errorcode: 20

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 676

possible FMI:

- 5: current to low or broken wire
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Relay not energized, but working voltage on sense line, relay defective (can not disconnect or switch off), preheat component defective, connection cable damaged

Take actions for error repair

Check cabling of preheat component, if relay not working check relay and if necessary replace it, check preheat component and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: setpoint for output status

22 / 168 / BattCD**Error description BATTERY VOLTAGE**

Battery voltage: the voltage measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 22

BlinkCode (short-long-short): 3 - 1 - 8

SPN: 168

possible FMI:

- 0: data valid, but above normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Voltage below target range, battery defective, too high power supply voltage, too high contact resistance, wiring damaged, energie system overloaded, parametering inaccurate, ECU defective

Take actions for error repair

Check LIMA?. ECU, cabling, contact resistance, safety fuses, too high load in energy system, check battery and if necessary replace it, check battery pole and if necessary clean it, check connection cable and if necessary repair or replace it, check volta

other error properties

System reaction: Warning, substitute value, dependent upon supply voltage (12V, 24V)

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

23 / 168 / BattCDSysReac**Error description BATTERY VOLTAGE**

Battery voltage: the voltage measured by ECU is out of the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 23

BlinkCode (short-long-short): 3 - 1 - 8

SPN: 168

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Above target range with system reaction, too high power supply voltage, parametering inaccurate, ECU defective

Take actions for error repair

Check dataset of calibration of working voltage for application, check LIMA? Check voltage of generator, check the parameters and if necessary correct them, replace ECU

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

24 / 523561 / BIPCyl1**Error description INJECT. PERIOD ZYL.1**

Begin of injection of cylinder 1: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 24

BlinkCode (short-long-short): 5 - 3 - 1

SPN: 523561

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 1), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



25 / 523562 / BIPCyl2

Error description INJECT. PERIOD ZYL.2

Begin of injection of cylinder 2: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 25

BlinkCode (short-long-short): 5 - 3 - 2

SPN: 523562

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 2), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

26 / 523563 / BIPCyl3

Error description INJECT. PERIOD ZYL.3

Begin of injection of cylinder 3: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 26

BlinkCode (short-long-short): 5 - 3 - 3

SPN: 523563

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 3), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

27 / 523564 / BIPCyl4

Error description INJECT. PERIOD ZYL.4

Begin of injection of cylinder 4: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 27

BlinkCode (short-long-short): 5 - 3 - 4

SPN: 523564

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 4), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

28 / 523565 / BIPCyl5**Error description INJECT. PERIOD ZYL.5**

Begin of injection of cylinder 5: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 28

BlinkCode (short-long-short): 5 - 3 - 5

SPN: 523565

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 5), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

29 / 523566 / BIPCyl6**Error description INJECT. PERIOD ZYL.6**

Begin of injection of cylinder 6: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 29

BlinkCode (short-long-short): 5 - 3 - 6

SPN: 523566

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 6), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

30 / 523567 / BIPCyl7**Error description INJECT. PERIOD ZYL.7**

Begin of injection of cylinder 7: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 30

BlinkCode (short-long-short): 5 - 3 - 7

SPN: 523567

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 7), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



31 / 523568 / BIPCyl8

Error description INJECT. PERIOD ZYL.8

Begin of injection of cylinder 8: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

Error codes

DEUTZ-Errorcode: 31

BlinkCode (short-long-short): 5 - 3 - 8

SPN: 523568

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Value outside target range or missing (cylinder 8), magnet valve or injection pump defective

Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

32 / 102 / BPSCD

Error description CHARGE AIR PRESS.

Charge air pressure sensor: the measured voltage of sensor by ECU is out of the target range; the calculated charge air pressure is implausible or the received value via CAN is defective

Error codes

DEUTZ-Errorcode: 32

BlinkCode (short-long-short): 2 - 2 - 3

SPN: 102

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit; sensor defective, onnection cable damaged

Take actions for error repair

Check cabling, if LDF6T sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

33 / 102 / BPSCDSysReac

Error description CHARGE AIR PRESS.

Charge air pressure: the charge air pressure calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 33

BlinkCode (short-long-short): 2 - 2 - 3

SPN: 102

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light oder blinking. Entry in errormemory.

Possible reason for error

Outside target range with system reaction, air system damaged, sensor defective, onnection cable damaged

Take actions for error repair

Check air system, inspect air system and if necessary repair it, check sensor and if necessary replace it; check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: BPSCD_stSysReacReq

Behaviour error lamp: permanent light oder blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



37 / 111 / CLSCDSysReac

Error description ENG COOLANT LEVEL

Coolant level: the coolant level calculated by ECU is underneath the allowed minimum

Error codes

DEUTZ-Errorcode: 37

BlinkCode (short-long-short): 2 - 3 - 5

SPN: 111

possible FMI:

- 1: data valid, but below normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light oder blinking. Entry in errormemory.

Possible reason for error

Outside target range with system reaction, cooling system unlight, sensor defective, onnection cable damaged

Take actions for error repair

Check coolant level, check cabling, inspect cooling system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: CLSCD_stSysReacReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

38 / 1323 / CmbChbMisfire1

Error description MISFIRE CYL. 1

Misfire at cylinder 1: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 38

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1323

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 1), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

39 / 1324 / CmbChbMisfire2

Error description MISFIRE CYL. 2

Misfire at cylinder 2: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 39

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1324

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 2), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



40 / 1325 / CmbChbMisfire3

Error description MISFIRE CYL. 3

Misfire at cylinder 3: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 40

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1325

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 3), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

41 / 1326 / CmbChbMisfire4

Error description MISFIRE CYL. 4

Misfire at cylinder 4: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 41

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1326

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 4), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

42 / 1327 / CmbChbMisfire5

Error description MISFIRE CYL. 5

Misfire at cylinder 5: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 42

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1327

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 5), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

43 / 1328 / CmbChbMisfire6**Error description MISFIRE CYL. 6**

Misfire at cylinder 6: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 43

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1328

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 6), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

44 / 1450 / CmbChbMisfire7**Error description MISFIRE CYL. 7**

Misfire at cylinder 7: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 44

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1450

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 7), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

45 / 1451 / CmbChbMisfire8**Error description MISFIRE CYL. 8**

Misfire at cylinder 8: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 45

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1451

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected (cylinder 8), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



46 / 1322 / CmbChbMisfireMul

Error description MULTIPL. CYL. MISFIRE

Misfire at more cylinders: the number of the misfire detected by ECU is out of the allowed limit value

Error codes

DEUTZ-Errorcode: 46

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1322

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected, magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

47 / 1346 / CmbChbSysReac

Error description MISFIRE SYST. REACT

Misfire at more cylinders: the number of the misfire detected by ECU is out of the allowed limit value; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 47

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1346

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Misfire detected with system reaction, magnet valve or injection pump defective, fuel system defective, motor engineering damaged

Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

48 / 1109 / CoEngShOffDemlgr

Error description SHUT OFF REQUEST

Request of engine off: the operator ignores the engine off request within an allowed period.

Error codes

DEUTZ-Errorcode: 48

BlinkCode (short-long-short): 3 - 4 - 1

SPN: 1109

possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Shut-off request ignored by operator

Take actions for error repair

Warranty relevant

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

52 / 1072 / CRERCD

Error description ENGINE BRAKE INT.

Engine brake actuator (internal): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the actuator is exceeded.

Error codes

DEUTZ-Errorcode: 52

BlinkCode (short-long-short): 5 - 2 - 8

SPN: 1072

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check actuator and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output, capacity reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 2

Measurement @ errortime: setpoint for output status

53 / 1081 / CSLpCD

Error description PREHEAT LAMP

Indicator lamp of air heater relay: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the lamp is exceeded

Error codes

DEUTZ-Errorcode: 53

BlinkCode (short-long-short): 3 - 2 - 8

SPN: 1081

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: setpoint for output status

54 / 704 / CTLpCD

Error description TEMP. LAMP

Warning lamp for coolant temperature: the current drain measured by ECU is out of the target range or the maximum temperature of the ECU component for power supply of the lamp is exceeded

Error codes

DEUTZ-Errorcode: 54

BlinkCode (short-long-short): 1 - 2 - 3

SPN: 704

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: setpoint for output status

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300

55 / 110 / CTSCD

Error description ENG COOLANT TEMP.

Coolant temperature sensor: the voltage of the sensor measured by ECU is out of the target range; the coolant temperature calculated by ECU is implausible compared with the oil temperature or the received value via CAN is defective

Error codes

DEUTZ-Errorcode: 55

BlinkCode (short-long-short): 2 - 2 - 5

SPN: 110

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

56 / 110 / CTSCDSysReac

Error description ENG COOLANT TEMP.

Coolant temperature: the coolant temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 56

BlinkCode (short-long-short): 2 - 3 - 2

SPN: 110

possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder

blinking. Entry in errormemory.

Possible reason for error

Outside target range with system reaction, cooling system not enough to be filled, clogged or damaged, cooling compressor dropped out, sensor defective, onnection cable damaged

Take actions for error repair

Check cycle cooling system and compressor, inspect cooling system and if necessary repair it, check cooling compressor and if necessary replace it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: CTSCD_stSysReacReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

57 / 701 / Dummy1CD_Max

Error description RESERVE 2

Reserve output 1: the ECU detects a short circuit to battery

Error codes

DEUTZ-Errorcode: 57

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 701

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to Ubatt (output 1), connection cable damaged

Take actions for error repair

Check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



58 / 701 / Dummy1CD_Min

Error description RESERVE 2

Reserve output 1: the ECU detects a short circuit to ground

Error codes

DEUTZ-Errorcode: 58

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 701

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to ground (output 1), connection cable damaged

Take actions for error repair

Check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

59 / 701 / Dummy1CD_SigNpl

Error description RESERVE 2

Reserve output 1: the ECU detects no load or excess temperature of the ECU component for power supply of the connected components

Error codes

DEUTZ-Errorcode: 59

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 701

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or ECU internal error (output 1), connection cable damaged, connected components defective, parametering of the output inaccurate, ECU defective

Take actions for error repair

Check connection cable and if necessary repair or replace it, check parameters and if necessary correct it, replace ECU

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

60 / 702 / Dummy2CD_Max

Error description THRUST MODE

Reserve output 2: the ECU detects a short circuit to battery

Error codes

DEUTZ-Errorcode: 60

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 702

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to Ubatt (output 2), connection cable damaged

Take actions for error repair

Check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



61 / 702 / Dummy2CD_Min

Error description THRUST MODE

Reserve output 2: the ECU detects a short circuit to ground

Error codes

DEUTZ-Errorcode: 61

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 702

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to ground (output 2), connection cable damaged

Take actions for error repair

Check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

62 / 702 / Dummy2CD_SigNpl

Error description THRUST MODE

Reserve output 2: the ECU detects no load or excess temperature of the ECU component for power supply of the connected components

Error codes

DEUTZ-Errorcode: 62

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 702

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or ECU internal error (output 2), connection cable damaged, connected components defective, parametering of the output inaccurate, ECU defective

Take actions for error repair

Check connection cable and if necessary repair or replace it, check parameters and if necessary correct it, replace ECU

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

69 / 2791 / EGRCD_Max

Error description EGR ACTUATOR

Actuator of the external EGR valve: the ECU detects a short circuit to battery

Error codes

DEUTZ-Errorcode: 69

BlinkCode (short-long-short): 4 - 1 - 4

SPN: 2791

possible FMI:

- 3. Voltage to high or short circuit to +Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to Ubatt, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



70 / 2791 / EGRCD_Min

Error description EGR ACTUATOR

Actuator of the external EGR valve: the ECU detects a short circuit to ground

Error codes

DEUTZ-Errorcode: 70

BlinkCode (short-long-short): 4 - 1 - 4

SPN: 2791

possible FMI:

- 12. Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to ground, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

71 / 2791 / EGRCD_SigNpl

Error description EGR ACTUATOR

Actuator of the external EGR valve: the ECU detects no load or excess temperature of the ECU component for power supply of the connected components

Error codes

DEUTZ-Errorcode: 71

BlinkCode (short-long-short): 4 - 1 - 5

SPN: 2791

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or excess temperature, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

72 / 2791 / EGRCDIntEGR

Error description EGR ACTUATOR

Actuator of the internal EGR valve: the ECU detects no load or excess temperature of the ECU component for power supply of the actuator

Error codes

DEUTZ-Errorcode: 72

BlinkCode (short-long-short): 4 - 1 - 6

SPN: 2791

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break, short circuit or excess temperature, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



74 / 923 / EngCDTrqCalcOut

Error description ENGINE POWER OUT

Output with PWM signal of the engine power: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component to control the output is exceeded

Error codes

DEUTZ-Errorcode: 74

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 923

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Engine Power output: cable break or short circuit, output defective, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

75 / 190 / EngMBackUp

Error description ENGINE SPEED

Crankshaft speed sensor: the ECU receives no signal and uses the signal from camshaft speed sensor as alternative to calculate the engine speed

Error codes

DEUTZ-Errorcode: 75

BlinkCode (short-long-short): 2 - 1 - 2

SPN: 190

possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Engine running only with cam-shaft speed signal, transmitter defective, connection cable damaged

Take actions for error repair

Check cabling of crankschaft sensor, check crankschaft sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, calculation of injektion initiation point will be incorrect

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: -

76 / 190 / EngMCaS1

Error description ENGINE SPEED

Camshaft speed sensor: the ECU receives no signal or the signal is defective

Error codes

DEUTZ-Errorcode: 76

BlinkCode (short-long-short): 2 - 1 - 2

SPN: 190

possible FMI:

- 12: Defective component
- 8: unusual frequency, pulse or period.
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Speed signal from cam-shaft defective or missing, transmitter defective, connection cable damaged, parametering of the sensor wheel inaccurate

Take actions for error repair

Check cabling, check camshaft sensor and if necessary replace it, check configuration of sensor wheel, check connection cable and if necessary repair or replace it, check parameters and if necessary correct them

other error properties

System reaction: Warning, difficult start

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: 0

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



77 / 190 / EngMCRs1

Error description ENGINE SPEED

Crankshaft speed sensor: the ECU receives no signal or the signal is defective

Error codes

DEUTZ-Errorcode: 77

BlinkCode (short-long-short): 2 - 1 - 2

SPN: 190

possible FMI:

- 12: Defective component
- 8: unusual frequency, pulse or period.
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Speed signal from crankshaft defectiveiv or missing, transmitter defective, connection cable damaged, sensor wheel installed inaccurately

Take actions for error repair

Check cabling, check camshaft sensor and if necessary replace it, check configuration of sensor wheel, check connection cable and if necessary repair or replace it, check the position of sensor wheel and if necessary correct it

other error properties

System reaction: Warning, power reduction via second topcurve
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: 0

78 / 190 / EngMOfsCaSCrS

Error description ENGINE SPEED

Speed sensor of crankshaft and camshaft: the received signals are out of phase

Error codes

DEUTZ-Errorcode: 78

BlinkCode (short-long-short): 2 - 1 - 3

SPN: 190

possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Speed signals of crank-shaft and cam-shaft are phase-shifted, sensor wheel installed in wrong position, sensor wrong wired

Take actions for error repair

Check position from crankshaft sensor wheel to camshaft sensor wheel, polarisation crankshaft or camshaft sensor, check position of sensor wheel and if necessary correct it, check cabling and if necessary correct it

other error properties

System reaction: Warning, not possible to start engine
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 4
Measurement @ errortime: -

79 / 190 / EngPrtSysReacFOC

Error description ENGINE SPEED

Engine speed: the engine speed calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 79

BlinkCode (short-long-short): 2 - 1 - 4

SPN: 190

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

Engine overspeed detected with system reaction, maximum engine speed exceeded

Take actions for error repair

other error properties

System reaction:
Behaviour error lamp: blinking
Selfhealing: no
Signal Priority: 5
Measurement @ errortime: actual value

80 / 190 / EngPrtSysReacORC

Error description ENGINE SPEED

Engine speed: under overrun conditions, the engine speed calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 80

BlinkCode (short-long-short): 2 - 1 - 4

SPN: 190

possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Overrun conditions detected with system reaction, maximum engine speed exceeded

Take actions for error repair

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

81 / 703 / ESLpCD

Error description ENG. RUNNING LAMP

Indicator lamp for engine running: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the lamp is exceeded

Error codes

DEUTZ-Errorcode: 81

BlinkCode (short-long-short): 1 - 4 - 2

SPN: 703

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or internal ECU error, lamp defective, connection cable damaged

Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

82 / 1074 / ExFICD

Error description BRAKE FLAP ACTUATOR

Engine brake flap actuator: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the actuator is exceeded

Error codes

DEUTZ-Errorcode: 82

BlinkCode (short-long-short): 2 - 1 - 9

SPN: 1074

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Engine brake flap actuator: cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 2

Measurement @ errortime: shut off value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



83 / 975 / FanCD

Error description FAN ACTUATOR

Fan power stage: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the actuator is exceeded

Error codes

DEUTZ-Errorcode: 83

BlinkCode (short-long-short): 2 - 3 - 8

SPN: 975

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 2
Measurement @ errortime: Sollwert

85 / 1639 / FanCDEval

Error description

Fan speed sensor: the current drain measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 85

BlinkCode (short-long-short): 2 - 3 - 8

SPN: 1639

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Sensor defective, connection cable damaged, fan speed outside the target range

Take actions for error repair

Check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, check fan

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime: actual value

86 / 523602 / FanCDSysReac

Error description FAN SPEED

Fan speed: the fan speed calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 86

BlinkCode (short-long-short): 2 - 3 - 8

SPN: 523602

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Above target range with system reaction

Take actions for error repair

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



87 / 97 / FIFCD

Error description WATER IN FUEL

Fuel filter water level sensor: the voltage of sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 87

BlinkCode (short-long-short): 2 - 2 - 8

SPN: 97

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

89 / 97 / FIFCD_WtLvl

Error description WATER IN FUEL

Water in fuel: the water level calculated by ECU is above the allowed limit value

Error codes

DEUTZ-Errorcode: 89

BlinkCode (short-long-short): 2 - 2 - 8

SPN: 97

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Above target range, excess of maximum permissible water level in fuel filter

Take actions for error repair

flush water separator

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 3
Measurement @ errortime: actual value

90 / 94 / FIPSCD

Error description FUEL PRE PRESS.

Low fuel pressure sensor: the voltage of sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 90

BlinkCode (short-long-short): 2 - 1 - 6

SPN: 94

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

91 / 94 / FIPSCDSysReac

Error description FUEL PRE PRESS.

Low fuel pressure: the low fuel pressure calculated by ECU is underneath the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 91

BlinkCode (short-long-short): 2 - 1 - 6

SPN: 94

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Below target range with system reaction, interruption in cycling process of low fuel pressure (for example, fuel pump defective), sensor defective, connection cable damaged

Take actions for error repair

Check low fuel pressure loop system, Check fuel pump, inspect fuel system and if necessary repair it; check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: FLPSCD_stSysReacReq

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

94 / 523239 / FrmMngDecV1

Error description CAN ERROR DEC-V1

CAN message DecV1 (Pseudo Pedal): the message can not be received by ECU or the received value is above the target range

Error codes

DEUTZ-Errorcode: 94

BlinkCode (short-long-short): 5 - 2 - 6

SPN: 523239

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Defective component
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing or value above target range (message "DecV1" = pseudo pedal), CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to customers configuration.

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: default value

95 / 523240 / FrmMngFunModCtl

Error description CAN ERROR FUNMODCTL

CAN message FunModCtl (Function Mode Control): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 95

BlinkCode (short-long-short): 5 - 2 - 7

SPN: 523240

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "FunModCtl" = function mode control, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to customers configuration.

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



106 / 523212 / FrmMngTOEngPrt

Error description CAN ERROR ENGPRt

CAN message EngPrt (Engine Protection): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 106

BlinkCode (short-long-short): 3 - 3 - 3

SPN: 523212

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "EngPrt" = engine protection, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, Hold last value.
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

110 / 523216 / FrmMngTOPrHtEnCmd

Error description CAN ERROR PRHTENCMD

CAN message PrHtEnCmd (Preheat and Engine Command): the message received can not be received by ECU

Error codes

DEUTZ-Errorcode: 110

BlinkCode (short-long-short): 3 - 3 - 7

SPN: 523216

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "PrHtEnCmd" = preheat and engine command; CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to customers configuration.
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

112 / 523218 / FrmMngTORxCCVS

Error description CAN ERROR RXCCVS

CAN message RxCCVS (Cruise Control): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 112

BlinkCode (short-long-short): 1 - 1 - 1

SPN: 523218

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "RxCCVS" = cruise control; CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



113 / 523604 / FrmMngTORxEngTemp

Error description CAN ERROR RxEngTemp

CAN message RxEngTemp (Engine Temperature): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 113

BlinkCode (short-long-short): 1 - 1 - 2

SPN: 523604

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "RxEngTemp" = engine temperature, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

117 / 523238 / FrmMngTOSwtOut

Error description CAN ERROR SWTOUT

CAN message SwtOut (Switching Output): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 117

BlinkCode (short-long-short): 1 - 1 - 5

SPN: 523238

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "SwtOut" = switch outputs, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

118 / 523222 / FrmMngTOTCO1

Error description CAN ERROR TCO1

CAN message "TCO1" (Speedo Signal): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 118

BlinkCode (short-long-short): 1 - 1 - 6

SPN: 523222

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TCO1" = speedo signal, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 1
Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



120 / 523605 / FrmMngTOTSC1AE

Error description CAN ERROR TSC1-AE

CAN message TSC1-AE (Torque/Speed Control #1 from Automatic Traction Control to Engine): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 120

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523605

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-AE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

121 / 523606 / FrmMngTOTSC1AR

Error description CAN ERROR TSC1-AR

CAN message TSC1-AR (Torque/Speed Control #1 from Automatic Traction Control to Retarder): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 121

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 523606

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-AR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

122 / 523607 / FrmMngTOTSC1DE

Error description CAN ERROR TSC1-DE

CAN message TSC1-DE (Torque/Speed Control #1 from Driveline to Engine): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 122

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523607

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-DE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



123 / 523608 / FrmMngTOTSC1DR

Error description CAN ERROR TSC1-DR

CAN message TSC1-DR (Torque/Speed Control #1 from Driveline to Retarder): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 123

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 523608

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-DR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

124 / 523609 / FrmMngTOTSC1PE

Error description CAN ERROR TSC1-PE

CAN message TSC1-PE (Torque/Speed Control #1 from Power Take Off to Engine): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 124

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523609

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-PE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

125 / 898 / FrmMngTOTSC1TE

Error description CAN ERROR TSC1-TE

CAN message TSC1-TE (Torque/Speed Control #1 from Traction Control to Engine): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 125

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 898

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-TE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



126 / 520 / FrmMngTOTSC1TR

Error description CAN ERROR TSC1-TR

CAN message TSC1-TR (Torque/Speed Control #1 from Traction Control to Retarder): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 126

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 520

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-TR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

127 / 523610 / FrmMngTOTSC1VE

Error description CAN ERROR TSC1-VE

CAN message TSC1-VE (Torque/Speed Control #1 from Vehicle Control to Engine): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 127

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523610

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-VE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

128 / 523611 / FrmMngTOTSC1VR

Error description CAN ERROR TSC1-VR

CAN message TSC1-VR (Torque/Speed Control #1 from Vehicle Control to Retarder): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 128

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 523611

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Missing message "TSC1-VR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



131 / 523500 / FrmMngTxTO

Error description CAN MESS. TIMEOUT

CAN message: the ECU detects a timeout for one or more posted message

Error codes

DEUTZ-Errorcode: 131

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 523500

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12: Defective component
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Timeout for sent messages

Take actions for error repair

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: -

133 / 174 / FTSCD

Error description FUEL TEMP. SENSOR

Fuel temperature sensor: the voltage measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 133

BlinkCode (short-long-short): 2 - 2 - 7

SPN: 174

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Fuel temp. sensor: cable break or short circuit, sendor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

134 / 174 / FTSCDSysReac

Error description FUEL TEMP. SENSOR

Fuel temperature: the fuel temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 134

BlinkCode (short-long-short): 2 - 3 - 7

SPN: 174

possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

Above target range with system reaction, interruption of fuel loop (for example, rail pressure relief valve defective), sensor defective, connection cable damaged

Take actions for error repair

Check fuel system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: FTSCD_stSysReacReq

Behaviour error lamp: permanent light
oder
blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



136 / 523618 / GOTSCD

Error description CUSTOMER TEMPSSENS 1

Customer specific temperature sensor 1: the voltage of sensor measured by ECU is out of the target range or the received value of temperature via CAN is defective

Error codes

DEUTZ-Errorcode: 136

BlinkCode (short-long-short): 1 - 3 - 3

SPN: 523618

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit (sensor 1), sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Customer specific bugfixing, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus scheduling, polarity, short circuit, power interrupt), test protocol of receiver, check CAN fun

other error properties

System reaction: Warning, substitute value (customer specific)

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: default value

137 / 523619 / GOTSCDSysReac

Error description

Customer specific temperature 1: the temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 137

BlinkCode (short-long-short): 1 - 3 - 3

SPN: 523619

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light

oder

blinking. Entry in errormemory.

Possible reason for error

Outside target range with system reaction (temperature 1), dependant on the application

Take actions for error repair

Customer specific bugfixing, dependant on application

other error properties

System reaction: Advice: GOTSCD_stSysReacReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

138 / 29 / HdThrt

Error description THROTTLE 2

Hand throttle pedal sensor: the voltage measured by ECU is out of the target range or the calculated pedal position is implausible compared with the position of accelerator pedal 1

Error codes

DEUTZ-Errorcode: 138

BlinkCode (short-long-short): 1 - 2 - 6

SPN: 29

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, signal implausible compared to signal of idle sensor, transmitter defective, connection cable damaged

Take actions for error repair

Check cabling, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, changing to substitute values according to priority chain or limp home

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300

139 / 1638 / HOTSCD

Error description CUSTOMER TEMPSSENS 2

Customer specific temperature sensor 2: the voltage of sensor measured by ECU is out of the target range or the received value of temperature via CAN is defective

Error codes

DEUTZ-Errorcode: 139

BlinkCode (short-long-short): 3 - 1 - 4

SPN: 1638

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Defective component
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit (sensor 2), sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Customer specific bugfixing, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN fun

other error properties

System reaction: Warning, substitute value (customer specific)
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime: default value

140 / 1638 / HOTSCDSysReac

Error description CUSTOMER TEMPSSENS 2

Customer specific temperature 2: the temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 140

BlinkCode (short-long-short): 3 - 1 - 4

SPN: 1638

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

Outside target range with system reaction (temperature 2), dependant on the application

Take actions for error repair

Customer specific bugfixing, dependant on application
other error properties

System reaction: Advice: HOTSCD_stSysReacReq
Behaviour error lamp: permanent light
oder
blinking
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

141 / 523617 / HWEMonCom

Error description INTERNAL COMM. ERROR

Internal hardware monitoring: the ECU detects a communication disturbance

Error codes

DEUTZ-Errorcode: 141

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523617

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Communication with chip CJ 940 disturbed, ECU defective

Take actions for error repair

If cannot delete the error, change ECU

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 4
Measurement @ errortime: -

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



142 / 630 / HWEMonEEPROM

Error description EEPROM MEM. ACCESS

Internal hardware monitoring: the ECU finds an error during the access to ist EEPROM memory or works with an alternative value

Error codes

DEUTZ-Errorcode: 142

BlinkCode (short-long-short): 2 - 8 - 1

SPN: 630

possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 12: Defective component
- 12: Defective component

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Error during EEPROM memory access or EEPROM works with substitute value, programming error. ECU defective

Take actions for error repair

If not programmed, EEPROM is defect → ECU is defect, reprogram ECU and if necessary replace it

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 4
Measurement @ errortime: -

143 / 523612 / HWEMonRcyLocked

Error description INT. RECOVERY

Internal hardware monitoring: the CPU of the ECU is reset and the cause is logged internally; no item will be created in error memory

Error codes

DEUTZ-Errorcode: 143

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 14: Special Instructions

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

A recovery occurred which is stored as protected

Take actions for error repair

Recovery occurred which is stored as protected
With parameter HWEMon_numRexxxxxx the recovery nummer and the subsequent position can be identified. See especially SW-Doku_roy_auto.pdf

other error properties

System reaction: Recovery of ECU
Behaviour error lamp: blinking
Selfhealing: no
Signal Priority: 5
Measurement @ errortime: -

144 / 523612 / HWEMonRcySuppressed

Error description INT. RECOVERY

Internal hardware monitoring: the CPU of the ECU is reset and the cause is logged internally; no item will be created in error memory

Error codes

DEUTZ-Errorcode: 144

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 14: Special Instructions

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

A recovery occurred which is not stored

Take actions for error repair

Recovery occurred which is stored as protected
With parameter HWEMon_numRexxxxxx the recovery nummer and the subsequent position can be identified. See especially SW-Doku_roy_auto.pdf

other error properties

System reaction: Warning, shown at error path
Behaviour error lamp: blinking
Selfhealing: no
Signal Priority: 5
Measurement @ errortime: -

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



145 / 523612 / HWEMonRcyVisible

Error description INT. RECOVERY

Internal hardware monitoring: the CPU of the ECU is reset and an item will be created in error memory

Error codes

DEUTZ-Errorcode: 145

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 14: Special Instructions

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

A recovery occurred which is visible in the error memory

Take actions for error repair

Recovery occurred which is stored as protected

With parameter HWEMon_numRexxxxxx the recovery nummer and the subsequent position can be identified. See especially SW-Doku_rcy_auto.pdf

other error properties

System reaction: Recovery of ECU

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errorime: -

146 / 523612 / HWEMonUMaxSupply

Error description INT. RECOVERY

Internal hardware monitoring: the ECU detects an excess of the target range for the power supply of 1st communication module

Error codes

DEUTZ-Errorcode: 146

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Overvoltage at CJ940, power supply voltage too high, ECU defective

Take actions for error repair

Check working voltage and if necessary correct it, Check ECU and if necessary replace it

other error properties

System reaction: Power stage shut off

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errorime: -

147 / 523612 / HWEMonUMinSupply

Error description INT. RECOVERY

Internal hardware monitoring: the ECU detects an undershooting of the target range for the power supply of 1st communication module

Error codes

DEUTZ-Errorcode: 147

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

possible FMI:

- 12. Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Undervoltage at CJ940, power supply voltage too low, ECU defective

Take actions for error repair

Check working voltage and if necessary correct it, Check ECU and if necessary replace it

other error properties

System reaction: Power stage shut off

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errorime: -

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300

149 / 105 / IATSCD

Error description CHARGE AIR TEMP.

Charge air temperature sensor: the voltage of sensor measured by ECU is out of the target range or the received value of temperature via CAN is defective

Error codes

DEUTZ-Errorcode: 149

BlinkCode (short-long-short): 1 - 2 - 8

SPN: 105

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check cabling, LDF6T-sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, c

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: default value

150 / 105 / IATSCDSysReac

Error description CHARGE AIR TEMP.

Charge air temperature: die charge air temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 150

BlinkCode (short-long-short): 2 - 3 - 3

SPN: 105

possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

Above target range with system reaction, air system damaged, sensor defective, connection cable damaged

Take actions for error repair

Check construction of LDF6T , check suction parts, check air system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: IATSCD_stSysReacReq
Behaviour error lamp: permanent light
oder
blinking
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

153 / 523350 / InjVlvBnk1A

Error description INJECTOR BANK A

Injector cylinder bank 1: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 153

BlinkCode (short-long-short): 1 - 5 - 1

SPN: 523350

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 13: out of calibrated range
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder bank 1), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, cylinder shut off
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



154 / 523351 / InjVlvBnk1B

Error description INJECTOR BANK A

Injector cylinder bank 1: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 154

BlinkCode (short-long-short): 1 - 5 - 1

SPN: 523351

possible FMI:

13: out of calibrated range

13: out of calibrated range

5: current to low or broken wire

13: out of calibrated range

Error detection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder bank 1), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, cylinder shut off

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

155 / 523352 / InjVlvBnk2A

Error description INJECTOR BANK B

Injector cylinder bank 2: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 155

BlinkCode (short-long-short): 1 - 5 - 2

SPN: 523352

possible FMI:

3: Voltage to high or short circuit to +Ubatt

4: Voltage to low or short circuit to -Ubatt

13: out of calibrated range

12: Errormode not identifiable

Error detection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder bank 2), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, cylinder shut off

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

156 / 523353 / InjVlvBnk2B

Error description INJECTOR BANK B

Injector cylinder bank 2: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 156

BlinkCode (short-long-short): 1 - 5 - 2

SPN: 523353

possible FMI:

13: out of calibrated range

13: out of calibrated range

5: current to low or broken wire

13: out of calibrated range

Error detection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder bank 2), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, cylinder shut off

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



157 / 523354 / InjVlvChipA

Error description PWR. INJ. BANK B

Internal hardware monitoring: the ECU detects an error of ist injector high current output

Error codes

DEUTZ-Errorcode: 157

BlinkCode (short-long-short): 1 - 5 - 3

SPN: 523354

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 2: data stream is defective
- 14: Special Instructions
- 12: Defective component

Errorredetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

High power stage Injector A, ECU defective

Take actions for error repair

If error is not removable, change ECU

other error properties

System reaction: Warning, outputs shut off

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: actual value

158 / 523355 / InjVlvChipB

Error description PWR. INJ. BANK B

Internal hardware monitoring: the ECU detects a disturbance in its injector high current output

Error codes

DEUTZ-Errorcode: 158

BlinkCode (short-long-short): 1 - 5 - 3

SPN: 523355

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Defective component
- 12: Defective component

Errorredetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

High power stage Injector B, ECU defective

Take actions for error repair

If error is not removable, change ECU

other error properties

System reaction: Warning, outputs shut off

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: actual value

159 / 651 / InjVlvCyl1A

Error description INJECTOR 1

Injector 1: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 159

BlinkCode (short-long-short): 1 - 5 - 4

SPN: 651

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 1), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



160 / 651 / InjVlvCyl1B

Error description INJECTOR 1

Injector 1: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 160

BlinkCode (short-long-short): 1 - 5 - 4

SPN: 651

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Error detection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 1), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

161 / 652 / InjVlvCyl2A

Error description INJECTOR 2

Injector 2: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 161

BlinkCode (short-long-short): 1 - 5 - 5

SPN: 652

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Error detection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 2), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

162 / 652 / InjVlvCyl2B

Error description INJECTOR 2

Injector 2: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 162

BlinkCode (short-long-short): 1 - 5 - 5

SPN: 652

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Error detection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 2), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



163 / 653 / InjVlvCyl3A

Error description INJECTOR 3

Injector 3: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 163

BlinkCode (short-long-short): 1 - 5 - 6

SPN: 653

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 3), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

164 / 653 / InjVlvCyl3B

Error description INJECTOR 3

Injector 3: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 164

BlinkCode (short-long-short): 1 - 5 - 6

SPN: 653

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 3), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

165 / 654 / InjVlvCyl4A

Error description INJECTOR 4

Injector 4: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 165

BlinkCode (short-long-short): 1 - 6 - 1

SPN: 654

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 4), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



166 / 654 / InjVlvCyl4B

Error description INJECTOR 4

Injector 4: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 166

BlinkCode (short-long-short): 1 - 6 - 1

SPN: 654

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 4), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

167 / 655 / InjVlvCyl5A

Error description INJECTOR 5

Injector 5: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 167

BlinkCode (short-long-short): 1 - 6 - 2

SPN: 655

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 5), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

168 / 655 / InjVlvCyl5B

Error description INJECTOR 5

Injector 5: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 168

BlinkCode (short-long-short): 1 - 6 - 2

SPN: 655

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 5), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



169 / 656 / InjVlvCyl6A

Error description INJECTOR 6

Injector 6: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 169

BlinkCode (short-long-short): 1 - 6 - 3

SPN: 656

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 6), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

170 / 656 / InjVlvCyl6B

Error description INJECTOR 6

Injector 6: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 170

BlinkCode (short-long-short): 1 - 6 - 3

SPN: 656

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 6), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

171 / 657 / InjVlvCyl7A

Error description INJECTOR 7

Injector 7: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 171

BlinkCode (short-long-short): 1 - 6 - 4

SPN: 657

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 7), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



172 / 657 / InjVlvCyl7B

Error description INJECTOR 7

Injector 7: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 172

BlinkCode (short-long-short): 1 - 6 - 4

SPN: 657

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 7), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

173 / 658 / InjVlvCyl8A

Error description INJECTOR 8

Injector 8: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 173

BlinkCode (short-long-short): 1 - 6 - 5

SPN: 658

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit (cylinder 8), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

174 / 658 / InjVlvCyl8B

Error description INJECTOR 8

Injector 8: the current drain measured by ECU is underneath the target range

Error codes

DEUTZ-Errorcode: 174

BlinkCode (short-long-short): 1 - 6 - 5

SPN: 658

possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break (cylinder 8), injector defective, connection cable damaged

Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



175 / 523370 / InjVlvErrDet

Error description RAIL PRESS. MON. DISABLED

Rail pressure monitoring: the monitoring of the rail pressure will be deactivated by ECU because of the activation of the function "compression test" by user

Error codes

DEUTZ-Errorcode: 175

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523370

possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows . Entry in errormemory.

Possible reason for error

Compression test active: rail-pressure monitoring is going to be disabled

Take actions for error repair

not correct

other error properties

System reaction: Rail pressure monitoring disabled

Behaviour error lamp:

Selfhealing: -

Signal Priority: 1

Measurement @ errorime:

176 / 523615 / MeUnCD_ADC

Error description METERING UNIT

Fuel volume flow rate: the fuel volume rate calculated by ECU at outlet of the fuel metering unit is out of the target range

Error codes

DEUTZ-Errorcode: 176

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Flow rate outside target range

Take actions for error repair

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errorime: actual value

177 / 523615 / MeUnCDNoLoad

Error description METERING UNIT

Valve at outlet of the fuel metering unit: the ECU detects no load or temperature excess of the ECU component for power supply of the valve

Error codes

DEUTZ-Errorcode: 177

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 5: current to low or broken wire
- 12: Defective component

Errorredetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

Possible reason for error

wiring error or ECU output is switched off because of overtemperature, fuel metering unit defective, connection cable damaged

Take actions for error repair

Check cabling , if necessary check FCU, check fuel metering unit and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, max.extraction of FCU --> open rail pressure relief valve --> shut the engine off in about 5 minutes
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errorime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



178 / 523615 / MeUnCDSCBat

Error description METERING UNIT

Valve at outlet of the fuel metering unit: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 178

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

Possible reason for error

Short circuit to Ubatt, fuel metering unit defective, connection cable damaged

Take actions for error repair

Check cabling , if necessary check FCU, check fuel metering unit and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, rail pressure relief valve will open
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

179 / 523615 / MeUnCDSCGnd

Error description METERING UNIT

Valve at outlet of the fuel metering unit: the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 179

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

Possible reason for error

Short circuit to ground, fuel metering unit defective, connection cable damaged

Take actions for error repair

Check cabling , if necessary check FCU, check fuel metering unit and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, rail pressure relief valve will open
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

182 / 2634 / MnRly1_SCB

Error description MAIN RELAY

Main relay 1: the current drains measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 182

BlinkCode (short-long-short): 1 - 3 - 7

SPN: 2634

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to Ubatt (relay 1), relay defective, connection cable damaged

Take actions for error repair

Check cabling, check ECU, check relay and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff the outputs MPROP

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



183 / 2634 / MnRly1_SCG

Error description MAIN RELAY

Main relay 1: the current drains measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 183

BlinkCode (short-long-short): 1 - 3 - 8

SPN: 2634

possible FMI:

- 12. Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to ground (relay 1), relay defective, connection cable damaged

Take actions for error repair

Check cabling, check ECU, check relay and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff the outputs MPROP

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

184 / 523420 / Montr

Error description WATCHDOG COUNTER

Internal hardware monitoring: the ECU detects an disturbance in ist monitoring module (Watchdog)

Error codes

DEUTZ-Errorcode: 184

BlinkCode (short-long-short): 1 - 3 - 9

SPN: 523420

possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 14: Special Instructions

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

Watchdog counter exceeds maximum, ECU defective

Take actions for error repair

If error is not removable, change ECU

other error properties

System reaction: Recovery of ECU

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: -

186 / 2634 / MRlyCD

Error description MAIN RELAY

Main relay: during the switching off, main relay does not switch on within an allowed time

Error codes

DEUTZ-Errorcode: 186

BlinkCode (short-long-short): 2 - 6 - 1

SPN: 2634

possible FMI:

- 7: Mechanical system not OK
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

EDC16: main relay not open in allowed time or main relay open too early; EDC7: main relay not open in allowed time or short circuit of main relay to ground; EDC16: main relay defective, connection cable damaged; generally: rapid shut-off of the ECU (witho

Take actions for error repair

EDC16: check external main relay, check cabling

EDC7: if error is not removable, change ECU, EDC16: Check main relay and if necessary replace it, check connection cable and if necessary repair or replace it; both: if error is not removable, change ECU

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



187 / 563 / MRlyCDMnRly2

Error description MAIN RELAY 2

Main relay 2 (in ECU): during the switching off, main relay does not switch on within an allowed time

Error codes

DEUTZ-Errorcode: 187

BlinkCode (short-long-short): 2 - 6 - 1

SPN: 563

possible FMI:

- 7: Mechanical system not OK
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

rapid shut-off of the ECU (without waiting till the end of the afterrun), ECU defective

Take actions for error repair

If error not removable, change ECU

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

188 / 2634 / MRlyCDMnRly3

Error description MAIN RELAY

Main relay 3 (in ECU): during the switching off, main relay does not switch on within an allowed time

Error codes

DEUTZ-Errorcode: 188

BlinkCode (short-long-short): 2 - 6 - 1

SPN: 2634

possible FMI:

- 7: Mechanical system not OK
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Short circuit to ground or emergency shut-off (relay 3 internal), rapid shut-off of the ECU (without waiting till the end of the afterrun), ECU defective

Take actions for error repair

Check cabling, check ECU, if error not removable, change ECU

other error properties

System reaction: Warning, shutoff the outputs MPROP (see

BOSCH-Electricity operating plan)

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

189 / 523450 / MSSCD1

Error description MULTISTATE SWITCH 1

Multi state switch 1: the voltage measured by ECU is out of the target range or the switch setting is not plausible

Error codes

DEUTZ-Errorcode: 189

BlinkCode (short-long-short): 1 - 4 - 3

SPN: 523450

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, input voltage outside target range (switch 1), switch defective, connection cable damaged

Take actions for error repair

Check cabling and sensor, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



190 / 523451 / MSSCD2

Error description MULTISTATE SWITCH 2

Multi state switch 2: the voltage measured by ECU is out of the target range or the switch setting is not plausible

Error codes

DEUTZ-Errorcode: 190

BlinkCode (short-long-short): 1 - 4 - 3

SPN: 523451

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, input voltage outside target range (switch 2), switch defective, connection cable damaged

Take actions for error repair

Check cabling and sensor, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime: default value

191 / 523452 / MSSCD3

Error description MULTISTATE SWITCH 3

Multi state switch 3: the voltage measured by ECU is out of the target range or the switch setting is not plausible

Error codes

DEUTZ-Errorcode: 191

BlinkCode (short-long-short): 1 - 4 - 3

SPN: 523452

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, input voltage outside target range (switch 3), switch defective, connection cable damaged

Take actions for error repair

Check cabling and sensor, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime: default value

192 / 639 / NetMngCANAOff

Error description CAN A BUS OFF

CAN bus A: the ECU is not allowed to send messages, because the status "BusOff" is detected

Error codes

DEUTZ-Errorcode: 192

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 639

possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, off-state (CAN bus A), CAN bus deactivated, connection cable damaged

Take actions for error repair

Check cabling of CAN bus and if necessary repair it, check connection cable and if necessary repair or replace it

other error properties

System reaction:
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime:

193 / 1231 / NetMngCANBOff**Error description CAN B BUS OFF**

CAN bus B: the ECU is not allowed to send messages, because the status "BusOff" is detected

Error codes

DEUTZ-Errorcode: 193

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 1231

possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, off-state (CAN bus B), CAN bus deactivated, connection cable damaged

Take actions for error repair

Check cabling of CAN bus and if necessary repair it, check connection cable and if necessary repair or replace it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime:

194 / 1235 / NetMngCANCOff**Error description CAN C BUS OFF**

CAN bus C: the ECU is not allowed to send messages, because the status "BusOff" is detected

Error codes

DEUTZ-Errorcode: 194

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 1235

possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, off-state (CAN bus C), CAN bus deactivated, connection cable damaged

Take actions for error repair

Check cabling of CAN bus and if necessary repair it, check connection cable and if necessary repair or replace it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime:

195 / 705 / OPLpCD**Error description OIL PRESS LAMP**

Warning lamp for oil level: the current drain measured by ECU is out of the target range or the maximum temperature of the ECU component for power supply of the lamp is exceeded

Error codes

DEUTZ-Errorcode: 195

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 705

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



196 / 100 / OPSCD

Error description ENG OIL PRESS.

Oil pressure sensor: the voltage of sensor measured by ECU is out of the target range or the received value of oil pressure via CAN is implausible (Oil pressure is above the target range with higher oil temperature at the same time)

Error codes

DEUTZ-Errorcode: 196

BlinkCode (short-long-short): 2 - 2 - 4

SPN: 100

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 0: data valid, but above normal working area

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, chec

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: default value

197 / 100 / OPSCD1

Error description ENG OIL PRESS.

Oil pressure: the oil pressure calculated by ECU is implausibly low

Error codes

DEUTZ-Errorcode: 197

BlinkCode (short-long-short): 2 - 3 - 1

SPN: 100

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 1: data valid, but below normal working area

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Oil pressure implausible low, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime: actual value

198 / 100 / OPSCDSysReacHi

Error description ENG OIL PRESS.

Oil pressure: the oil pressure calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 198

BlinkCode (short-long-short): 2 - 3 - 1

SPN: 100

possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

Above target range, oil volume too large, sensor defective, oil pump defective, connection cable damaged

Take actions for error repair

Check oil level and if necessary correct it, check oil pump and if necessary replace it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: OPSCD_stSysReacReqHi
Behaviour error lamp: permanent light
oder
blinking
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



199 / 100 / OPSCDSysReacLo

Error description ENG OIL PRESS.

Oil pressure: the oil pressure calculated by ECU is underneath the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 199

BlinkCode (short-long-short): 2 - 3 - 1

SPN: 100

possible FMI:

- 1: data valid, but below normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

Below target range, oil volume too small, sensor defective, oil pump defective, connection cable damaged

Take actions for error repair

Check oil level and if necessary correct it, check oil pump and if necessary replace it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: OPSCD_stSysReacReqLo
Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errorime: actual value

200 / 1237 / OSwCD

Error description OVERRIDE SWITCH

Bridgeover switch: the ECU receives a permanent signal

Error codes

DEUTZ-Errorcode: 200

BlinkCode (short-long-short): 1 - 4 - 5

SPN: 1237

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Switch is blocked, taster locked, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errorime: actual value

201 / 175 / OTSCD

Error description OIL TEMP. SENSOR

Oil temperature sensor: the voltage of sensor measured by ECU is out of the target range; the oil temperature calculated by ECU is implausible compared with coolant temperature or the received value via CAN is defective

Error codes

DEUTZ-Errorcode: 201

BlinkCode (short-long-short): 1 - 4 - 4

SPN: 175

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errorime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



203 / 175 / OTSCDSysRead

Error description OIL TEMP. SENSOR

Oil temperature: the oil temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 203

BlinkCode (short-long-short): 1 - 4 - 4

SPN: 175

possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder

blinking. Entry in errormemory.

Possible reason for error

Above target range with system reaction, oil volume too small, oil loop disturbed, sensor defective, connection cable damaged

Take actions for error repair

Check cycle cooling system and compressor, check oil level and if necessary correct it, check sensor and if necessary replace it, check oil loop and if necessary repair it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: OTSCD_stSysReadReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

208 / 523470 / PRVMon

Error description RAIL PRESS. LIM. VALVE

Rail pressure relief valve: is open, will be forced to open, the forced-open failed

Error codes

DEUTZ-Errorcode: 208

BlinkCode (short-long-short): 1 - 4 - 6

SPN: 523470

possible FMI:

- 14: Special Instructions
- 2: data stream is defective
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

Possible reason for error

Rail pressure relief valve open or forced open abortive (interpretation of the rail pressure gradient), operating voltage too low, rail pressure sensor defective, fuel metering unit defective, rail pressure relief valve defective, air in fuel system

Take actions for error repair

Check working voltage and if necessary correct it, check rail-pressure sensor and if necessary replace it, check FCU and if necessary replace it, check rail pressure relief valve and if necessary replace it, bleed the fuel-system

other error properties

System reaction: Warning, shut the engine off in about 5 minutes

Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

209 / 157 / RailCD

Error description RAIL PRESS. SENSOR

Rail pressure sensor: the voltage of sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 209

BlinkCode (short-long-short): 1 - 4 - 7

SPN: 157

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, check rail pressure sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, max.extraction of FCU -> open rail pressure relief valve -> shut the engine off in about 5 minutes
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



210 / 157 / RailCDOfsTst

Error description RAIL PRESS. SENSOR

Rail pressure sensor: the change of the voltage measured by ECU during the engine start or the after-run is out of the target range

Error codes

DEUTZ-Errorcode: 210

BlinkCode (short-long-short): 1 - 4 - 7

SPN: 157

possible FMI:

- 0: data valid, but above normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Deviation of signal during start or after-run above target range, sensor defective

Take actions for error repair

Replace sensor

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 2
Measurement @ errortime: actual value

211 / 523613 / RailMeUn0

Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is above the target range which is dependant on the engine speed

Error codes

DEUTZ-Errorcode: 211

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
Blinking. Entry in errormemory.

Possible reason for error

- 1) Leakage in high pressure system (external) ,
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamt in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

Take actions for error repair

- (A) Check for leakage
- (B) Chek fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

other error properties

System reaction: Warning or Warning and power reduction
Behaviour error lamp: permanent light
oder
Blinking
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

212 / 523613 / RailMeUn1

Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is above the target range which is dependant on the volume flow rate

Error codes

DEUTZ-Errorcode: 212

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
Blinking. Entry in errormemory.

Possible reason for error

- 1) Leakage in high pressure system (external) ,
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamt in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

Take actions for error repair

- (A) Check for leakage
- (B) Chek fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

other error properties

System reaction: Warning or Warning and power reduction
Behaviour error lamp: permanent light
oder
Blinking
Selfhealing: yes
Signal Priority: 4
Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



213 / 523613 / RaiMeUn2

Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is underneath the target range which is dependant on the engine speed

Error codes

DEUTZ-Errorcode: 213

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

- 1) No power supply in FCU,
- 2) ZME clamped in open position,
- 3) Too high pressure nach Nullförderdrossel (FCU),
- 4) Nullförderdrossel clogged,
- 5) Too high primary pressure on low pressure side, sensor defective, fuel system disturbed

Take actions for error repair

- (A) Check return-pressure FCU
- (B) Check flow-pressure
- (C) Change FCU, check sensor and if necessary replace it, check fuel system and if necessary repair it

other error properties

System reaction: Warning or Warning and power reduction
Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

214 / 523613 / RaiMeUn3

Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is underneath the target range which is dependant on the volume flow rate

Error codes

DEUTZ-Errorcode: 214

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

possible FMI:

- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

- 1) Leakage in high pressure system (external) ,
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamped in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

Take actions for error repair

- (A) Check for leakage
- (B) Check fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

other error properties

System reaction: Warning or Warning and power reduction
Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

215 / 523613 / RaiMeUn4

Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is above the absolute target range

Error codes

DEUTZ-Errorcode: 215

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

- 1) No power supply in FCU,
- 2) ZME clamped in open position,
- 3) Too high pressure nach Nullförderdrossel (FCU),
- 4) Nullförderdrossel clogged,
- 5) Too high primary pressure on low pressure side, sensor defective, fuel system disturbed

Take actions for error repair

- (A) Check return-pressure FCU
- (B) Check flow-pressure
- (C) Change FCU, check sensor and if necessary replace it, check fuel system and if necessary repair it

other error properties

System reaction: Warning or Warning and power reduction
Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



216 / 523613 / RailMeUn7

Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is implausible compared with the setpoint setting of the fuel metering unit

Error codes

DEUTZ-Errorcode: 216

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light
oder
blinking. Entry in errormemory.

Possible reason for error

- 1) Leakage in high pressure system (external) ;
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamt in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

Take actions for error repair

- (A) Check for leakage
- (B) Check fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

other error properties

System reaction: Warning or Warning and power reduction

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

218 / 523490 / SOPTst

Error description REDUNDANT SHUT OFF DET.

Internal hardware monitoring: the ECU finds an disturbance in the redundant switch off path through a test during the ramp up phase

Error codes

DEUTZ-Errorcode: 218

BlinkCode (short-long-short): 1 - 4 - 9

SPN: 523490

possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Test of redundant shut-off paths

Take actions for error repair

Could be triggered by over/undervoltage or external Watchdog

other error properties

System reaction: Test will only be executed with ECU

Initialisation. Warning, dependent upon application.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: -

219 / 1079 / SSpMon1

Error description 5V SUPPLY 1 FAIL.

Internal hardware monitoring: the ECU detects a deviation of the target range of the power supply voltage of sensor 1

Error codes

DEUTZ-Errorcode: 219

BlinkCode (short-long-short): 2 - 8 - 2

SPN: 1079

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

5V sensor supply voltage 1 outside target range, operating voltage too high or to low, connection cable damaged, ECU defective

Take actions for error repair

If error not removable, change ECU, check cabling of external components, check working voltage and if necessary correct it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



221 / 1080 / SSpMon2

Error description 5V SUPPLY 2 FAIL.

Internal hardware monitoring: the ECU detects a deviation of the target range of the power supply voltage of sensor 2

Error codes

DEUTZ-Errorcode: 221

BlinkCode (short-long-short): 2 - 8 - 2

SPN: 1080

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

5V sensor supply voltage 2 outside target range, operating voltage too high or to low, connection cable damaged, ECU defective

Take actions for error repair

If error not removable, change ECU, check cabling of external components, check working voltage and if necessary correct it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

222 / 523601 / SSpMon3

Error description 5V SUPPLY 3 FAIL.

Internal hardware monitoring: the ECU detects a deviation of the target range of the power supply voltage of sensor 3

Error codes

DEUTZ-Errorcode: 222

BlinkCode (short-long-short): 2 - 8 - 2

SPN: 523601

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Wrong voltage of internal 5V reference source 3, operating voltage too high or too low, connection cable damaged, ECU defective

Take actions for error repair

If error not removable, change ECU, check cabling of external components, check working voltage and if necessary correct it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: actual value

223 / 677 / StrtCDHS

Error description START RELAY

Start relay (high side power stage): the current drain measured by ECU is above the target range

Error codes

DEUTZ-Errorcode: 223

BlinkCode (short-long-short): 5 - 1 - 2

SPN: 677

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Start relay (high side): short circuit, relay defective, connection cable defective

Take actions for error repair

Check cabling and start relay and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 1
Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



224 / 677 / StrtCDLS

Error description START RELAY

start relay (low side power stage): the current drain measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 224

BlinkCode (short-long-short): 5 - 1 - 2

SPN: 677

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Start relay (low side): cable break or short circuit, disabled by ECU, relay defective, connection cable damaged

Take actions for error repair

Check cabling and start relay and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

225 / 624 / SysLamp

Error description DIAGNOSTIC LAMP

Error lamp (diagnostic lamp): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the lamp is exceeded

Error codes

DEUTZ-Errorcode: 225

BlinkCode (short-long-short): 5 - 1 - 3

SPN: 624

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

Errordetection

Errorlamp shows -. Entry in errormemory.

Possible reason for error

Cable break or short circuit, disabled by ECU, lamp defective, connection cable damaged

Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: only error memory item

Behaviour error lamp: -

Selfhealing: no

Signal Priority: 2

Measurement @ errortime: setpoint Diagnosticlamp

226 / 158 / T15CD

Error description TERMINAL 15

Terminal 15: ECU receives no signal

Error codes

DEUTZ-Errorcode: 226

BlinkCode (short-long-short): 5 - 1 - 4

SPN: 158

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Ignition ON not detected, ignition switch defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check ignition switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, engine can not start

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 2

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300

227 / 523550 / T50CD

Error description TERMINAL 50

Terminal 50: ECU receives a permanent signal

Error codes

DEUTZ-Errorcode: 227

BlinkCode (short-long-short): 5 - 1 - 5

SPN: 523550

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Engine start switch stuck, start switch clamped, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check start switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: no
Signal Priority: 1
Measurement @ errorime: actual value

228 / 523550 / TPUMon

Error description TERMINAL 50

Internal hardware monitoring: ECU detects a deviation between the signal of time module and the system time

Error codes

DEUTZ-Errorcode: 228

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523550

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 2: data stream is defective

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

Time processing unit (TPU) defective, ECU defective

Take actions for error repair

If error not removable, change ECU

other error properties

System reaction: Recovery of ECU
Behaviour error lamp: blinking
Selfhealing: no
Signal Priority: 5
Measurement @ errorime: -

232 / 84 / VSSCD1

Error description VEHICLE SPEED

Vehicle speed: over the maximum, signal invalid or implausible compared with the injection quantity and the engine speed, offset factors unlearned

Error codes

DEUTZ-Errorcode: 232

BlinkCode (short-long-short): 5 - 2 - 1

SPN: 84

possible FMI:

- 0: data valid, but above normal working area
- 12: Defective component
- 8: unusual frequency, pulse or period.
- 14: Special Instructions

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Speed above target range, signal invalid or implausible compared to injection volume and engine speed, distance factor not learned, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errorime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



235 / 523600 / WdCom

Error description SERIAL INTERFACE DEF.

Internal hardware monitoring: the ECU detects a disturbance in internal communication

Error codes

DEUTZ-Errorcode: 235

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523600

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component

Errordetection

Errorlamp shows blinking. Entry in errormemory.

Possible reason for error

Communication disturbed, ECU defective

Take actions for error repair

If error not to removable, change ECU

other error properties

System reaction: Recovery of ECU

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: -

236 / 523470 / PRVMonSysReac

Error description RAIL PRESS. LIM. VALVE

Rail pressure relief valve: is open, will be forced to open, the forced-open failed; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 236

BlinkCode (short-long-short): 1 - 4 - 6

SPN: 523470

possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

Possible reason for error

Rail pressure relief valve open or forced open abortive (interpretation of the rail pressure gradient), power supply voltage too low, rail pressure sensor defective, fuel metering unit defective, rail pressure relief valve defective, air in fuel system

Take actions for error repair

Check working voltage and if necessary correct it, check rail-pressure sensor and if necessary replace it, check FCU and if necessary replace it, check rail pressure relief valve and if necessary replace it, bleed the fuel-system

other error properties

System reaction: Warning, shut the engine off in about 5 minutes

Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

237 / 523006 / APPCDSwtnSel

Error description CONTR. MODE SWITCH

Controller mode switch: the signal received by ECU is defective or implausible.

Error codes

DEUTZ-Errorcode: 237

BlinkCode (short-long-short): 2 - 4 - 2

SPN: 523006

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break, signal implausible, switch defective, connection cable damaged

Take actions for error repair

Check switch and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300

238 / 523007 / FrmMng_TORxEngPress

Error description CAN ERROR RxEngPress.

Error codes

DEUTZ-Errorcode: 238

BlinkCode (short-long-short): 2 - 1 - 5

SPN: 523007

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Take actions for error repair

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: default value

239 / 523008 / MplCtl

Error description MANIPULATION CONTROL

Data monitoring: the torque curve does not match the specification

Error codes

DEUTZ-Errorcode: 239

BlinkCode (short-long-short): 4 - 2 - 4

SPN: 523008

possible FMI:

- 1: data valid, but below normal working area
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errorredetection

Errorlamp shows . Entry in errormemory.

Possible reason for error

Manipulation of Topcurve detected, data manipulation, too slow changed curve

Take actions for error repair

other error properties

System reaction:

Behaviour error lamp:

Selfhealing: -

Signal Priority: 3

Measurement @ errortime:

240 / 98 / OLSCD

Error description OIL LEVEL SWITCH

Oil level sensor: the voltage of sensor measured by ECU is out of the target range or the received value of oil level via CAN is defective or the signal value is implausible

Error codes

DEUTZ-Errorcode: 240

BlinkCode (short-long-short): 2 - 1 - 1

SPN: 98

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Voltage outside target range, CAN signal error, signal implausible, sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shaduling, polarity, short circuit, power interrupt), test protocol of receiver, chec

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



241 / 98 / OLSCDSysReacHi

Error description OIL LEVEL SWITCH

Oil level: the oil level calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 241

BlinkCode (short-long-short): 2 - 5 - 1

SPN: 98

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Oil level too high with system reaction, oil volume too large, sensor defective, connection cable damaged, CAN data error

Take actions for error repair

Check oil level and if necessary correct it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: OLSCD_stSysReacReq

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

242 / 107 / ADPSCDana

Error description AIR FILTER COND.

Air filter differential pressure sensor: the voltage of sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 242

BlinkCode (short-long-short): 1 - 3 - 6

SPN: 107

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Voltage outside target range, sensor defective, connection cable damaged

Take actions for error repair

Check cable harness, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

243 / 98 / OLSCDSysReacLo

Error description OIL LEVEL SWITCH

Oil level: the oil level calculated by ECU is underneath the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 243

BlinkCode (short-long-short): 2 - 5 - 2

SPN: 98

possible FMI:

- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Oil level too low with system reaction, oil volume too small, sensor defective, connection cable damaged, CAN data error

Take actions for error repair

Check oil level and if necessary correct it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Advice: OLSCD_stSysReacReq

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



244 / 523009 / PrvMonWear

Error description REPL. RAIL PRESS. VALVE

Rail pressure relief valve: is open more frequently or for a longer time than what the technical specification allows

Error codes

DEUTZ-Errorcode: 244

BlinkCode (short-long-short): 2 - 5 - 3

SPN: 523009

possible FMI:

- 9: Abnormal update rated
- 10: Abnormal rate of change
- 14: Special Instructions
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Rail pressure relief valve open more frequently than the technical specification allowed, rail pressure relief valve open longer than the technical specification allowed, rail pressure relief valve defective

Take actions for error repair

Change rail pressure relief valve and remove the error through Serdia command

other error properties

System reaction: permanent error message, unerasurable by "Clear EM"

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

245 / 523010 / RailMeUn8

Error description LEAKAGE DETECTION

Wenn the engine is in idle running, the metering unit compares its output and rail pressure with the default value (Parameter) and calculates a correction factor-it calibrates itself then

Error codes

DEUTZ-Errorcode: 245

BlinkCode (short-long-short): 2 - 5 - 4

SPN: 523010

possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Take actions for error repair

other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

246 / 523650 / FISys_FLPFMSysReac

Error description

Low fuel pressure Diesel: the low fuel pressure calculated by ECU is underneath the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 246

BlinkCode (short-long-short): 5 - 4 - 1

SPN: 523650

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Diesel fuel pressure below target range with system reaction, interruption in cycling process of low fuel pressure (for example, fuel pump defective), sensor defective, connection cable damaged

Take actions for error repair

Check Diesel low fuel pressure loop system, Check electrical fuel pump, inspect fuel system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



247 / 523651 / FISys_FTSFMSysReac

Error description

Rape Oil Fuel temperature: the fuel temperature calculated by ECU is above the target range; the ECU activates a system reaction

Error codes

DEUTZ-Errorcode: 247

BlinkCode (short-long-short): 5 - 4 - 2

SPN: 523651

possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Rape oil fuel temperature above target range with system reaction, interruption of rape oil fuel loop (for example, heat exchanger not working properly), sensor defective, connection cable damaged

Take actions for error repair

Check rape oil fuel system as well as heat exchanger and heat exchanger valve, if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning and switchover to Diesel operation mode

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ runtime: default value

248 / 523652 / FISys_FlushStateEngineOff

Error description

Engine shut off without flushing or flushing was not already completed. ECU stores every shutoff with uncompleted or missing flushing process

Error codes

DEUTZ-Errorcode: 248

BlinkCode (short-long-short): 5 - 4 - 3

SPN: 523652

possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Engine shut off without flushing of the fuel system in Diesel operation mode, Shutoff before flushing in Diesel operation mode was finished

Take actions for error repair

Awaiting complete flushing of the fuel system everytime before engine shut off

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ runtime: -

249 / 523653 / FISys_RapeOilHeatEx

Error description RAPEOILSYSTEM

Awaited temperatur rise with opened heat exchanger valve did not occur. Error in fuel heating system.

Error codes

DEUTZ-Errorcode: 249

BlinkCode (short-long-short): 5 - 4 - 4

SPN: 523653

possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Fuel heating system (heat exchanger) not working correctly

Take actions for error repair

Check Heat exchanger and heat exchanger valve, check cooling system going to the heat exchanger, check rape oil system going to the heat exchanger

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ runtime: -

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



250 / 523654 / FrmMngDieselLvl

Error description RAPEOILSYSTEM

Status DieselLvl (Diesel tank level): the voltage of the sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 250

BlinkCode (short-long-short): 5 - 4 - 5

SPN: 523654

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

251 / 523655 / FrmMngFuelTemp

Error description RAPEOILSYSTEM

Status FuelTemp (Fuel Temperature): the voltage of the sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 251

BlinkCode (short-long-short): 5 - 4 - 6

SPN: 523655

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

252 / 523656 / FrmMngLowPressureDiesel

Error description RAPEOILSYSTEM

Status LowPressureDiesel (Low fuel pressure diesel): the voltage of the sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 252

BlinkCode (short-long-short): 5 - 4 - 7

SPN: 523656

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



253 / 523657 / FrmMngRapeOilIn

Error description RAPEOILSYSTEM

CAN messageRapeOilIn (Rape oil input): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 253

BlinkCode (short-long-short): 5 - 6 - 1

SPN: 523657

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, substitute values
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

254 / 523658 / FrmMngRapeOilVl

Error description RAPEOILSYSTEM

Status RapeOilVl (Rape oil tank level): the voltage of the sensor measured by ECU is out of the target range

Error codes

DEUTZ-Errorcode: 254

BlinkCode (short-long-short): 5 - 6 - 2

SPN: 523658

possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning, substitute value
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

255 / 523659 / FrmMngRapeOilVlV1

Error description RAPEOILSYSTEM

Status RapeOilVlV1 (Valve 1): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

Error codes

DEUTZ-Errorcode: 255

BlinkCode (short-long-short): 5 - 6 - 3

SPN: 523659

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning and switchover to Diesel operation mode
Behaviour error lamp: permanent light
Selfhealing: yes
Signal Priority: 3
Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



256 / 523660 / FrmMngRapeOilVlv2

Error description RAPEOILSYSTEM

Status RapeOilVlv2 (Valve 2): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

Error codes

DEUTZ-Errorcode: 256

BlinkCode (short-long-short): 5 - 6 - 4

SPN: 523660

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning and switchover to Diesel operation mode

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

257 / 523661 / FrmMngRapeOilVlv3

Error description RAPEOILSYSTEM

Status RapeOilVlv3 (Valve 3): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

Error codes

DEUTZ-Errorcode: 257

BlinkCode (short-long-short): 5 - 6 - 5

SPN: 523661

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning and switchover to Diesel operation mode

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

258 / 523662 / FrmMngRapeOilVlv4

Error description RAPEOILSYSTEM

Status RapeOilVlv4 (Valve 4): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

Error codes

DEUTZ-Errorcode: 258

BlinkCode (short-long-short): 5 - 6 - 6

SPN: 523662

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

DTC-List

Diagnosis- and Errorcodes

referenced ECU-Software
P490_: 220, 310, 501
P491_: 220, 310, 400, 501

P492_: 213
P513_: 214, 300



259 / 523663 / FrmMngRapeOilVlv5

Error description RAPEOILSYSTEM

Status RapeOilVlv5 (Valve 5): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

Error codes

DEUTZ-Errorcode: 259

BlinkCode (short-long-short): 5 - 6 - 7

SPN: 523663

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

260 / 523664 / FrmMngSTIN1RX

Error description RAPEOILSYSTEM

CAN message STIN1 (State Inputs 1): the message can not be received by ECU

Error codes

DEUTZ-Errorcode: 260

BlinkCode (short-long-short): 5 - 6 - 8

SPN: 523664

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

Errordetection

Errorlamp shows permanent light. Entry in errormemory.

Possible reason for error

CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

other error properties

System reaction: Warning, substitute values

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value



MECALAC Baumaschinen GmbH

Am Friedrichsbrunnen 2
D-24782 Büdelsdorf

Tel: +49 (0)4331 351 325
Fax: +49 (0)4331 351 491

E-Mail: info@mecalac.com
Web: www.mecalac.com