

Table of Contents

1 Fundamental safety instructions

1.1	Warnings and symbols	1 - 2
1.2	Proper use of the loader	1 - 2
1.3	Organizational measures	1 - 2
1.4	Selection of personnel and necessary qualifications; basic responsibilities	1 - 3
1.5	Safety Information for Certain Operating Phases	1 - 4
1.5.1	Normal Operation	1 - 4
1.5.2	Special work regarding the use of the machine and elimination of defects during work; disposal	1 - 7
1.6	Instructions regarding special categories of danger	1 - 9
1.6.1	Electrical energy	1 - 9
1.6.2	Hydraulics	1 - 10
1.6.3	Noise	1 - 10
1.6.4	Oil, grease and other chemical substances	1 - 10
1.6.5	Gas, dust, steam, smoke	1 - 11
1.7	Transport and towing; recommissioning	1 - 11
1.8	Safety information for the contractor or the contractor's authorized personnel	1 - 12
1.8.1	Organizational measures	1 - 12
1.8.2	Selection of personnel and necessary qualifications; basic responsibilities	1 - 12

2 Signs

3 Protection against theft

3.1	Identifying features on the loader	3 - 2
3.2	Parking the loader	3 - 2
3.3	Drive-away interlocks	3 - 3
3.3.1	Drive-away interlock transponder	3 - 3
3.3.2	Encodable drive-away interlock	3 - 3

4 Description

4.1	Overview	4 - 2
4.2	Loader	4 - 3
4.3	Wheel change	4 - 6
4.4	Controls	4 - 7
4.4.1	Multifunction panel	4 - 9
4.4.2	Fuses/relays	4 - 10

5 Operation

5.1	Checks before start-up	5 - 2
5.2	Commissioning	5 - 2
5.2.1	Start the diesel engine	5 - 2
5.2.2	Winter operation	5 - 3
5.2.2.1	Fuel	5 - 3
5.2.2.2	Engine oil change	5 - 3
5.2.2.3	Oil change, hydraulic system	5 - 3
5.2.2.4	Anti-freezing agent for windshield washer system	5 - 4
5.2.3	Driving the loader on public roads	5 - 4
5.2.4	Working with the loader	5 - 5
5.2.5	Heater and ventilation system	5 - 6
5.2.5.1	Setting the air flow	5 - 6
5.2.5.2	Switch on the heater	5 - 6
5.3	Decommissioning the loader	5 - 7
5.3.1	Parking the loader	5 - 7

Table of Contents



5.3.2	Switch off the diesel engine	5 - 7
5.3.3	Switching off the heater and ventilation system	5 - 7
5.3.4	Leaving the loader	5 - 7
5.4	Adjusting the driver's seat	5 - 8
5.4.1	Grammer seat	5 - 8
5.4.2	KAB seat	5 - 10
5.5	Switching the steering type	5 - 11
5.5.1	Overview of switching options	5 - 11

6 Attachments

6.2	Mounting and dismounting attachments with hydraulic connections	6 - 2
6.2.1	Multi-purpose bucket	6 - 2
6.3	Mounting and dismounting rear attachments	6 - 4
6.3.1	Rear mounting plate	6 - 4
6.4	Use of additional attachments	6 - 5

7 Rescue, towing, lashing, craning

7.1	Rescue, towing, lashing	7 - 2
7.1.1	Towing the front loader if the engine has failed or if the propulsion drive has failed	7 - 2
7.1.1.1	Towing the front loader if the engine has failed	7 - 2
7.1.1.2	Towing the front loader if the propulsion drive has failed	7 - 4
7.2	Lifting by crane	7 - 5

8 Maintenance

8	Maintenance schedule	8 - 1
8.1	Notes regarding maintenance	8 - 2
8.2	Maintenance work	8 - 3
8.2.1	Engine inspections	8 - 3
8.2.1.1	Engine oil level check	8 - 3
8.2.1.2	Cooling water check	8 - 3
8.2.1.3	V-belt check	8 - 4
8.2.1.4	V-belt tension check	8 - 4
8.2.1.5	Other important engine checks	8 - 4
8.2.2	Oil level check for axles	8 - 4
8.2.2.1	Rear axle	8 - 4
8.2.2.2	Planetary gear	8 - 4
8.2.2.3	Front axle	8 - 5
8.2.2.4	Oil level check of ancillary/distribution gear	8 - 5
8.2.3	Oil level check, hydraulic oil reservoir	8 - 5
8.2.4	Fuel filter	8 - 6
8.2.4.1	Draining the water trap of the fuel filter	8 - 6
8.2.4.2	Replacing the fuel filter	8 - 6
8.2.5	Oil change, engine	8 - 7
8.2.6	Changing the engine oil filter insert	8 - 9
8.2.7	Oil change, axles	8 - 10
8.2.7.1	Rear axle	8 - 10
8.2.7.2	Planetary gear	8 - 10
8.2.7.3	Front axle	8 - 11
8.2.7.4	Oil change of ancillary/distribution gear	8 - 12
8.2.8	Oil change, hydraulic system	8 - 12
8.2.9	Changing the hydraulic oil filter insert	8 - 13
8.2.10	Maintaining/replacing the air filter	8 - 14
8.2.11	Replacing the safety cartridge	8 - 15
8.2.12	Replacing the starter battery	8 - 15
8.2.13	Checking/topping up the brake fluid level	8 - 16

8.3	Grease lubrication points	8 - 16
8.3.1	bucket assembly	8 - 16
8.3.2	Rear axle	8 - 18
8.3.3	Rear axle pivot bolts	8 - 18
8.3.4	Front axle	8 - 19
8.3.5	Engine hood	8 - 19
8.3.6	Multi-purpose bucket	8 - 19

10 Circuit diagrams

10.1	Electric wiring diagram	10 - 3
10.2	Hydraulic circuit diagram	10 - 7

11 Technical data (loader)

1.1	AF 1050	11 - 2
11.1.1	Loader	11 - 2
11.1.2	Engine	11 - 2
11.1.2.1	48 kW engine	11 - 2
11.1.2.2	55 kW engine	11 - 2
11.1.3	Starter	11 - 2
11.1.4	Alternator	11 - 2
11.1.5	Hydrostatic drive motor	11 - 2
11.1.6	Axle loads	11 - 3
11.1.7	Tyres	11 - 3
11.1.8	Steering system	11 - 3
11.1.9	Brakes	11 - 3
11.1.10	Electrical system	11 - 3
11.1.11	Hydraulic system	11 - 4
11.1.12	Fuel supply system	11 - 4
11.1.13	Heater and ventilation system	11 - 4
11.1.14	Suction/return flow filter	11 - 4
11.1.15	Electric contamination indicator	11 - 4
11.1.16	Combination cooler with temperature-controlled fan	11 - 4
11.1.17	Noise emission	11 - 4
11.2.18	Vibrations	11 - 4
11.2	AF 1200	11 - 5
11.2.1	Loader	11 - 5
11.2.2	Engine	11 - 5
11.2.2.1	55 kW engine	11 - 5
11.2.2.2	63 kW engine	11 - 5
11.2.3	Starter	11 - 5
11.2.4	Alternator	11 - 5
11.2.5	Hydrostatic drive motor	11 - 5
11.2.6	Axle loads	11 - 6
11.2.7	Tyres	11 - 6
11.2.8	Steering system	11 - 6
11.2.9	Brakes	11 - 6
11.2.10	Electrical system	11 - 6
11.2.11	Hydraulic system	11 - 7
11.2.12	Fuel supply system	11 - 7
11.2.13	Heater and ventilation system	11 - 7
11.2.14	Suction/return flow filter	11 - 7
11.2.15	Electric contamination indicator	11 - 7
11.2.16	Combination cooler with temperature-controlled fan	11 - 7
11.2.17	Noise emission	11 - 7
11.2.18	Vibrations	11 - 7

12 Technical data (attachments)

12.1	AF 1050	12	-	2
12.1.1	Buckets	12	-	2
12.1.2	Fork-lift attachment	12	-	4
12.1.3	Lifting hook	12	-	4
12.2	AF 1200	12	-	6
12.2.1	Buckets	12	-	6
12.2.2	Fork-lift attachment	12	-	8
12.2.3	Lifting hook	12	-	8

13 Additional options

13.1	Additional options	13	-	2
13.1.1	Hand throttle	13	-	2
13.1.2	Inching speed	13	-	2