

Index

A

- Acoustic power level 2-7,
2-8, 2-9
- Acoustic pressure level 2-7,
2-8, 2-9
- Adjusting the operator's seat 5-8
- Alternator 3-1, 3-4, 3-7, 3-23
- Anti-freezing agent for the
windshield washer system 5-4
- Articulation pivot joint 4-1
- Attachments 6-1
 - Fork-lift attachment 6-2
 - Lifting hook 6-3
 - Multi-purpose bucket 6-4
 - Mounting 6-4
 - Dismounting 6-5
 - Standard/lightweight bucket 6-1
 - Mounting 6-1
 - Dismounting 6-2
 - Using other attachments 6-7
- Attachments AL 70e 3-10
 - Buckets 3-10
 - Fork-lift attachment 3-12
 - Lifting hook 3-12
- Attachments AL 85t 3-14
 - Buckets 3-14
 - Fork-lift attachment 3-16
 - Lifting hook 3-16
- Attachments AL 100t 3-18
 - Buckets 3-18
 - Fork-lift attachment 3-20
 - Lifting hook 3-20
- Attachments AL 100ti 3-26
 - Buckets 3-26
 - Fork-lift attachment 3-28
 - Lifting hook 3-28
- Axle loads 3-2, 3-5, 3-8, 3-24

B

- Battery main switch 4-10

- Beacon light 4-11
- Biodegradable hydraulic oil. See
Oil change: Hydraulic system
- Brake system 3-2, 3-5, 3-8, 3-24
- Bucket position mark 4-7
- Bucket protection 4-1, 5-5
- Buckets 3-10, 3-14, 3-18

C

- Changing a wheel 4-8
- Checking/adjusting the
service/parking brake 8-16
- Control lamp for
battery charging 4-11
- Controls 4-10

D

- Directional indicator 4-11

E

- Electrical contamination
indicator 3-3, 3-6, 3-9, 3-25
- Electrical system 3-2,
3-5, 3-8, 3-24
- Engine 3-1, 3-4, 3-7, 3-23
- Engine oil pressure 4-11
- Engine oil
temperature display 4-11
- Equalising reservoir
for brake fluid 8-16

F

- Float position 4-5, 4-6
- Fork-lift attachment 3-12,
3-16, 3-20, 3-28, 6-2
- Fuel gauge 4-11
- Fuel supply system 3-3,
3-6, 3-9, 3-25
- Fuel tank 4-1, 4-5
- Fuse box 4-11
- Fuses 2-2

H

- Hazard flasher 4-11
- Heating and ventilation system
 - 3-3, 3-6, 3-9, 3-25, 4-11, 5-8
 - Adjusting the amount of air 5-6
 - Switching on the heater 5-6
- High beam 4-11
- Hydraulic oil filter 4-11
- Hydraulic oil reservoir 4-1
- Hydraulic oil temperature 4-11
- Hydraulic system 3-3, 3-6, 3-9, 3-25
- Hydrostatic traction drive 3-1, 3-4, 3-7, 3-23

I

- Instrument panel 4-11
- Interval wiper, front 4-11

L

- Lifting by crane 7-7
- Lifting device suspension 4-6
- Lifting height restriction 4-7
- Lifting hook 3-12, 3-16, 3-20, 3-28, 6-3
- Lightweight bucket 3-11, 3-15, 3-19
- Lubrication points 8-14
 - Door of the driver's cabin 8-14
 - Engine hood 8-14
 - Multi-purpose bucket 8-14

M

- Maintaining/replacing the air filter 8-3
- Maintaining/replacing the fresh air filter 8-17
- Maintenance work 8-2
 - Checking/adjusting the service/parking brake 8-16
- Lubrication points 8-14
 - Door of the driver's cabin 8-14
 - Engine hood 8-14
 - Multi-purpose bucket 8-14

- Maintaining/replacing the air filter 8-3
- Maintaining/replacing the fresh air filter 8-17
- Oil change
 - Engine 8-2
 - Front axle 8-6
 - Hydraulic system 8-12
 - Planetary gear 8-11
 - Rear axle 8-8
- Oil level check
 - Engine 8-2
 - Front axle 8-5
 - Planetary gear 8-11
 - Rear axle 8-7
- Replacing the fuel prefilter 8-2
- Replacing the hydraulic oil filter insert 8-13
- Replacing the safety cartridge 8-5
- Replacing the starter battery 8-15
- Malfunctions, causes and remedies 9-1
- Multi-purpose bucket 3-11, 3-15, 3-19, 6-4
- Mounting 6-4
- Dismounting 6-5

O

- Oil change
 - Distribution gear. See Oil change: Rear axle:
 - Fast loader » 30 km/h «
- Engine 8-2
- Front axle 8-6
- Hydraulic system 8-12
- Intermediate gear.
 - See Oil change: Rear axle:
 - Slow loader » 20 km/h «
- Planetary gear 8-11
- Rear axle 8-8
 - Fast loader » 30 km/h « 8-9
 - Slow loader » 20 km/h « 8-8
- Oil cooler 3-3, 3-6, 3-9, 3-25

Oil level check

- Distribution gear. See Oil level check: Rear axle:
 - Fast loader » 30 km/h «
- Engine 8-2
- Front axle 8-5
- Intermediate gear. See Oil level check: Rear axle:
 - Slow loader » 20 km/h «
- Planetary gear 8-11
- Rear axle 8-7
 - Fast loader
 - » 30 km/h « 8-7
 - Slow loader
 - » 20 km/h « 8-7

Operating hour meter 4-11

P

- Parking brake 4-11
- Pipe break safety device 4-6
- Pivot arm 4-1
- Protection against theft 10-1
 - Identifying features on the loader 10-1
- Parking the loader 10-1
- Transponder for drive-away interlock 10-2

R

- Rear window heater 4-11
- Release of
 - quick-change device 4-11
- Releasing the brake 7-3
- Replacing the fuel prefilter 8-2
- Replacing the
 - hydraulic oil filter insert 8-13
- Replacing the safety cartridge 8-5
- Replacing the starter battery 8-15
- Rescue, towing, lashing 7-1
 - Releasing the brake 7-3
- Return-flow suction filter 3-3, 3-6, 3-9, 3-25

S

- Signs 2-1
 - Fuses 2-2
 - Symbols 2-3
 - Warning and information signs 2-1
- Socket 4-11
- Standard bucket 3-11, 3-15, 3-19, 3-26
- Standard/lightweight bucket 6-1
 - Mounting 6-1
 - Dismounting 6-2
- Starter 3-1, 3-4, 3-7, 3-23
- Starter switch 4-11
- Starting the diesel engine 5-1
- Steering system 3-2, 3-5, 3-8, 3-24
- Switching off
 - the diesel engine 5-7
- Switching off the heating and ventilation system 5-8
- Symbols 2-3

T

- Technical data 3-1, 3-7
 - AL 70e 3-1, 3-7
 - AL 85t 3-4
 - AL 100t 3-7
 - AL 100ti 3-23
- Tip lever 4-1
- Tip rod 4-1
- Tires 3-2, 3-5, 3-8, 3-24
- Transmission switch 4-11

W

- Warning and information signs 2-1
- Windshield washer, front 4-11
- Winter operation 5-2
 - Anti-freezing agent for the windshield washer system 5-4
 - Changing the engine oil 5-3
 - Changing the oil in the hydraulic system 5-3
 - Fuel 5-2
- Work lights 4-11