

# Table of contents

## **1 Fundamental safety instructions**

|       |                                                                                                                       |   |   |    |
|-------|-----------------------------------------------------------------------------------------------------------------------|---|---|----|
| 1.1   | Warnings and symbols .....                                                                                            | 1 | - | 2  |
| 1.2   | Proper use of the loader .....                                                                                        | 1 | - | 2  |
| 1.3   | Organizational measures .....                                                                                         | 1 | - | 2  |
| 1.4   | Selection of personnel and necessary qualifications; basic responsibilities .....                                     | 1 | - | 3  |
| 1.5   | Safety information for certain operating phases .....                                                                 | 1 | - | 4  |
| 1.5.1 | Normal operation .....                                                                                                | 1 | - | 4  |
| 1.5.2 | Special work in the context of machine operation and elimination of defects<br>during process or work; disposal ..... | 1 | - | 7  |
| 1.6   | Instructions regarding special categories of danger .....                                                             | 1 | - | 9  |
| 1.6.1 | Electrical energy .....                                                                                               | 1 | - | 9  |
| 1.6.2 | Hydraulics .....                                                                                                      | 1 | - | 10 |
| 1.6.3 | Noise .....                                                                                                           | 1 | - | 10 |
| 1.6.4 | Oil, grease and other chemical substances .....                                                                       | 1 | - | 11 |
| 1.6.5 | Gas, dust, steam, smoke .....                                                                                         | 1 | - | 11 |
| 1.7   | Transport and towing, recommissioning .....                                                                           | 1 | - | 11 |
| 1.8   | Safety information for the contractor or the contractor's authorized personnel .....                                  | 1 | - | 12 |
| 1.8.1 | Organizational measures .....                                                                                         | 1 | - | 12 |
| 1.8.2 | Selection of personnel and necessary qualifications; basic responsibilities .....                                     | 1 | - | 12 |

## **2 Signs**

## **3 Protection against theft**

|     |                                            |   |   |   |
|-----|--------------------------------------------|---|---|---|
| 3.1 | Identifying features on the loader .....   | 3 | - | 2 |
| 3.2 | Parking the loader .....                   | 3 | - | 2 |
| 3.3 | Transponder for drive-away interlock ..... | 3 | - | 3 |

## **4 Description**

|     |                    |   |   |   |
|-----|--------------------|---|---|---|
| 4.1 | Overview .....     | 4 | - | 2 |
| 4.2 | Loader .....       | 4 | - | 3 |
| 4.3 | Wheel change ..... | 4 | - | 6 |
| 4.4 | Controls .....     | 4 | - | 7 |
| 4.5 | Fuses .....        | 4 | - | 9 |

## **5 Operation**

|         |                                                            |   |   |   |
|---------|------------------------------------------------------------|---|---|---|
| 5.1     | Checks before commissioning .....                          | 5 | - | 2 |
| 5.2     | Commissioning .....                                        | 5 | - | 2 |
| 5.2.1   | Starting the diesel engine .....                           | 5 | - | 2 |
| 5.2.2   | Winter operation .....                                     | 5 | - | 3 |
| 5.2.2.1 | Fuel .....                                                 | 5 | - | 3 |
| 5.2.2.2 | Engine oil change .....                                    | 5 | - | 3 |
| 5.2.2.3 | Changing the oil in the hydraulic system .....             | 5 | - | 3 |
| 5.2.2.4 | Anti-freezing agent for the windshield washer system ..... | 5 | - | 4 |
| 5.2.3   | Driving the loader on public roads .....                   | 5 | - | 4 |
| 5.2.4   | Working with the loader .....                              | 5 | - | 5 |
| 5.2.5   | Heating and ventilation system .....                       | 5 | - | 6 |
| 5.2.5.1 | Adjusting the air flow .....                               | 5 | - | 6 |
| 5.2.5.2 | Switching on the heater .....                              | 5 | - | 6 |
| 5.3     | Decommissioning the loader .....                           | 5 | - | 7 |
| 5.3.1   | Parking the loader .....                                   | 5 | - | 7 |
| 5.3.2   | Switching off the diesel engine .....                      | 5 | - | 7 |
| 5.3.3   | Switching off the heating and ventilation system .....     | 5 | - | 7 |
| 5.3.4   | Leaving the loader .....                                   | 5 | - | 7 |

|           |                                                                                 |    |   |    |
|-----------|---------------------------------------------------------------------------------|----|---|----|
| 5.4       | Adjusting the driver's seat .....                                               | 5  | - | 8  |
| 5.4.1     | Klepp seat .....                                                                | 5  | - | 8  |
| 5.4.2     | Isri seat .....                                                                 | 5  | - | 8  |
| 5.4.3     | Grammer seat .....                                                              | 5  | - | 9  |
| <b>6</b>  | <b>Attachments</b>                                                              |    |   |    |
| 6.1       | Mounting and dismounting attachments without hydraulic connections .....        | 6  | - | 2  |
| 6.1.1     | Standard/lightweight bucket .....                                               | 6  | - | 2  |
| 6.1.2     | Fork-lift attachment .....                                                      | 6  | - | 3  |
| 6.2       | Mounting and dismounting attachments with a hydraulic connection .....          | 6  | - | 4  |
| 6.2.1     | Multi-purpose bucket .....                                                      | 6  | - | 4  |
| 6.3       | Using other attachments .....                                                   | 6  | - | 6  |
| <b>7</b>  | <b>Rescue, towing, lashing, lifting by crane</b>                                |    |   |    |
| 7.1       | Rescue, towing, lashing .....                                                   | 7  | - | 2  |
| 7.1.1     | Rescue/towing of the articulated loader if the engine or drive has failed ..... | 7  | - | 2  |
| 7.1.1.1   | Towing the articulated loader if the engine has failed .....                    | 7  | - | 2  |
| 7.1.1.2   | Towing the articulated loader if the drive has failed .....                     | 7  | - | 5  |
| 7.2       | Lifting by crane .....                                                          | 7  | - | 6  |
| <b>8</b>  | <b>Maintenance</b>                                                              |    |   |    |
| 8         | Maintenance Plan AL 80 and AL 100 .....                                         | 8  | - | 1  |
| 8.1       | Notes regarding maintenance .....                                               | 8  | - | 3  |
| 8.2       | Maintenance work .....                                                          | 8  | - | 3  |
| 8.2.1     | Engine oil level check .....                                                    | 8  | - | 3  |
| 8.2.2     | Engine oil change .....                                                         | 8  | - | 4  |
| 8.2.3     | Fuel prefilter replacement .....                                                | 8  | - | 4  |
| 8.2.4     | Maintaining/replacing the air filter .....                                      | 8  | - | 4  |
| 8.2.5     | Replacing the safety cartridge .....                                            | 8  | - | 5  |
| 8.2.6     | Front axle oil change .....                                                     | 8  | - | 5  |
| 8.2.7     | Front axle oil change .....                                                     | 8  | - | 6  |
| 8.2.8     | Rear axle oil level check .....                                                 | 8  | - | 7  |
| 8.2.8.1   | Slow loader » 20 km/h « .....                                                   | 8  | - | 7  |
| 8.2.8.2   | Fast loader » 30 km/h « .....                                                   | 8  | - | 7  |
| 8.2.9     | Rear axle oil change .....                                                      | 8  | - | 8  |
| 8.2.9.1   | Slow loader » 20 km/h « .....                                                   | 8  | - | 8  |
| 8.2.9.2   | Fast loader » 30 km/h « .....                                                   | 8  | - | 9  |
| 8.2.10    | Planetary gear .....                                                            | 8  | - | 10 |
| 8.2.11    | Planetary gear oil change .....                                                 | 8  | - | 10 |
| 8.2.12    | Hydraulic system oil change .....                                               | 8  | - | 11 |
| 8.2.13    | Hydraulic oil filter cartridge replacement .....                                | 8  | - | 12 |
| 8.2.14    | Grease points .....                                                             | 8  | - | 12 |
| 8.2.14.1  | Articulated pendulum joint/steering cylinder .....                              | 8  | - | 12 |
| 8.2.14.2  | Bucket assembly AL 80, AL 100 and AL 100turbo .....                             | 8  | - | 13 |
| 8.2.14.3  | Bucket assembly AL 120 .....                                                    | 8  | - | 14 |
| 8.2.14.4  | Driver's cab door .....                                                         | 8  | - | 14 |
| 8.2.14.5  | Engine hood .....                                                               | 8  | - | 15 |
| 8.2.14.6  | Multi-purpose bucket .....                                                      | 8  | - | 15 |
| 8.2.15    | Oil lubrication points .....                                                    | 8  | - | 16 |
| 8.2.16    | Replacing the starter battery .....                                             | 8  | - | 16 |
| 8.2.17    | Checking/adjusting the service/parking brake .....                              | 8  | - | 16 |
| 8.2.18    | Maintaining/replacing the fresh air filter .....                                | 8  | - | 17 |
| <b>9</b>  | <b>Malfunctions, causes and remedies</b>                                        |    |   |    |
| <b>10</b> | <b>Diagrams</b>                                                                 |    |   |    |
| 10.1      | Electric wiring diagram .....                                                   | 10 | - | 3  |
| 10.2.1    | Hydraulic diagram (AL 80 and AL 100) .....                                      | 10 | - | 7  |
| 10.2.2    | Hydraulic diagram AL 120 .....                                                  | 10 | - | 9  |

### 11 Technical data (loader)

|         |                                                  |    |   |   |
|---------|--------------------------------------------------|----|---|---|
| 11.1    | <b>AL 80</b> .....                               | 11 | - | 2 |
| 11.1.1  | Loader .....                                     | 11 | - | 2 |
| 11.1.2  | Engine .....                                     | 11 | - | 2 |
| 11.1.3  | Starter .....                                    | 11 | - | 2 |
| 11.1.4  | Alternator .....                                 | 11 | - | 2 |
| 11.1.5  | Hydrostatic drive .....                          | 11 | - | 2 |
| 11.1.6  | Axle loads .....                                 | 11 | - | 2 |
| 11.1.7  | Tires .....                                      | 11 | - | 2 |
| 11.1.8  | Steering system .....                            | 11 | - | 3 |
| 11.1.9  | Brake system .....                               | 11 | - | 3 |
| 11.1.10 | Electrical system .....                          | 11 | - | 3 |
| 11.1.11 | Hydraulic system .....                           | 11 | - | 3 |
| 11.1.12 | Fuel supply system .....                         | 11 | - | 3 |
| 11.1.13 | Heating and ventilation system .....             | 11 | - | 3 |
| 11.1.14 | Return suction filter .....                      | 11 | - | 3 |
| 11.1.15 | Electric contamination indicator .....           | 11 | - | 3 |
| 11.1.16 | Oil cooler with temperature-controlled fan ..... | 11 | - | 3 |
| 11.1.17 | Noise emission .....                             | 11 | - | 3 |
| 11.2    | <b>AL 100</b> .....                              | 11 | - | 4 |
| 11.2.1  | Loader .....                                     | 11 | - | 4 |
| 11.2.2  | Engine .....                                     | 11 | - | 4 |
| 11.2.3  | Starter .....                                    | 11 | - | 4 |
| 11.2.4  | Alternator .....                                 | 11 | - | 4 |
| 11.2.5  | Hydrostatic drive .....                          | 11 | - | 4 |
| 11.2.6  | Axle loads .....                                 | 11 | - | 4 |
| 11.2.7  | Tires .....                                      | 11 | - | 4 |
| 11.2.8  | Steering system .....                            | 11 | - | 5 |
| 11.2.9  | Brake system .....                               | 11 | - | 5 |
| 11.2.10 | Electrical system .....                          | 11 | - | 5 |
| 11.2.11 | Hydraulic system .....                           | 11 | - | 5 |
| 11.2.12 | Fuel supply system .....                         | 11 | - | 5 |
| 11.2.13 | Heating and ventilation system .....             | 11 | - | 5 |
| 11.2.14 | Return suction filter .....                      | 11 | - | 5 |
| 11.2.15 | Electric contamination indicator .....           | 11 | - | 5 |
| 11.2.16 | Oil cooler with temperature-controlled fan ..... | 11 | - | 5 |
| 11.2.17 | Noise emission .....                             | 11 | - | 5 |
| 11.3    | <b>AL 100 turbo</b> .....                        | 11 | - | 6 |
| 11.3.1  | Loader .....                                     | 11 | - | 6 |
| 11.3.2  | Engine .....                                     | 11 | - | 6 |
| 11.3.3  | Starter .....                                    | 11 | - | 6 |
| 11.3.4  | Alternator .....                                 | 11 | - | 6 |
| 11.3.5  | Hydrostatic drive .....                          | 11 | - | 6 |
| 11.3.6  | Axle loads .....                                 | 11 | - | 6 |
| 11.3.7  | Tires .....                                      | 11 | - | 6 |
| 11.3.8  | Steering system .....                            | 11 | - | 7 |
| 11.3.9  | Brake system .....                               | 11 | - | 7 |
| 11.3.10 | Electrical system .....                          | 11 | - | 7 |
| 11.3.11 | Hydraulic system .....                           | 11 | - | 7 |
| 11.3.12 | Fuel supply system .....                         | 11 | - | 7 |
| 11.3.13 | Heating and ventilation system .....             | 11 | - | 7 |
| 11.3.14 | Return suction filter .....                      | 11 | - | 7 |
| 11.3.15 | Electric contamination indicator .....           | 11 | - | 7 |
| 11.3.16 | Oil cooler with temperature-controlled fan ..... | 11 | - | 7 |
| 11.3.17 | Noise emission .....                             | 11 | - | 7 |
| 11.4    | <b>AL 120</b> .....                              | 11 | - | 8 |
| 11.4.1  | Loader .....                                     | 11 | - | 8 |
| 11.4.2  | Engine .....                                     | 11 | - | 8 |
| 11.4.3  | Starter .....                                    | 11 | - | 8 |
| 11.4.4  | Alternator .....                                 | 11 | - | 8 |
| 11.4.5  | Hydrostatic drive .....                          | 11 | - | 8 |
| 11.4.6  | Axle loads .....                                 | 11 | - | 8 |

|         |                                                  |    |   |   |
|---------|--------------------------------------------------|----|---|---|
| 11.4.7  | Tires .....                                      | 11 | - | 8 |
| 11.4.8  | Steering system .....                            | 11 | - | 8 |
| 11.4.9  | Brake system .....                               | 11 | - | 9 |
| 11.4.10 | Electrical system .....                          | 11 | - | 9 |
| 11.4.11 | Hydraulic system .....                           | 11 | - | 9 |
| 11.4.12 | Fuel supply system .....                         | 11 | - | 9 |
| 11.4.13 | Heating and ventilation system .....             | 11 | - | 9 |
| 11.4.14 | Return suction filter .....                      | 11 | - | 9 |
| 11.4.15 | Electric contamination indicator .....           | 11 | - | 9 |
| 11.4.16 | Oil cooler with temperature-controlled fan ..... | 11 | - | 9 |
| 11.4.17 | Noise emission .....                             | 11 | - | 9 |

## **12 Technical data (attachments)**

|        |                                         |    |   |    |
|--------|-----------------------------------------|----|---|----|
| 12.1   | AL 80 attachments .....                 | 12 | - | 2  |
| 12.1.1 | Buckets .....                           | 12 | - | 2  |
| 12.1.2 | Fork-lift attachment .....              | 12 | - | 4  |
| 12.1.3 | Lifting hook .....                      | 12 | - | 4  |
| 12.2   | AL 100 / AL 100 turbo attachments ..... | 12 | - | 6  |
| 12.2.1 | Buckets .....                           | 12 | - | 6  |
| 12.2.2 | Fork-lift attachment .....              | 12 | - | 8  |
| 12.2.3 | Lifting hook .....                      | 12 | - | 8  |
| 12.3   | AL 120 attachments .....                | 12 | - | 10 |
| 12.3.1 | Buckets .....                           | 12 | - | 10 |
| 12.3.2 | Fork-lift attachment .....              | 12 | - | 12 |
| 12.3.3 | Lifting hook .....                      | 12 | - | 12 |

## **13 Additional options, modifications, notes on inspection for loaders**

|      |                          |    |   |   |
|------|--------------------------|----|---|---|
| 13.1 | Additional options ..... | 13 | - | 2 |
| 13.2 | Modifications .....      | 13 | - | 2 |