

Table of contents

1	Fundamental safety instructions		
1.1	Warnings and symbols	1	2
1.2	Use of the loader as authorized	1	2
1.3	Organizational measures	1	2
1.4	Selection of personnel and necessary qualifications	1	3
1.5	Safety information for certain operating phases	1	4
1.5.1	Normal operation	1	4
1.5.2	Special work within the exploitation of the machine and elimination of defects during process of work; disposal	1	7
1.6	Instructions regarding special categories of danger	1	9
1.6.1	Electrical energy	1	9
1.6.2	Hydraulic systems	1	10
1.6.3	Noise	1	10
1.6.4	Oil, grease and other chemical substances	1	11
1.6.5	Gas, dust, steam, smoke	1	11
1.7	Transport and towing; restart	1	11
1.8	Safety information for the contractor or the contractor's authorized personnel	1	12
1.8.1	Organizational measures	1	12
1.8.2	Selection of personnel and necessary qualification; additional duties	1	12
2	Signs		
3	Protection against theft		
3.1	Identifying features on the loader	3	2
3.2	Parking the loader	3	2
3.3	Transponder for drive-away interlock	3	3
4	Description		
4.1	Overview	4	2
4.2	Loader	4	3
4.3	Changing a wheel	4	6
4.4	Controls	4	8
4.5	Instrument panel	4	9
5	Operation		
5.1	Pre-use check	5	2
5.2	Starting up	5	2
5.2.1	Starting the diesel engine	5	2
5.2.2	Winter operation	5	3
5.2.2.1	Fuel	5	3
5.2.2.2	Changing the engine oil	5	4
5.2.2.3	Changing the oil in the hydraulic system	5	4
5.2.2.4	Anti-freezing agent for the windshield washer system	5	4
5.2.3	Driving the loader on public roads	5	4
5.2.4	Working with the loader	5	5
5.2.5	Heating and ventilation system	5	7
5.2.5.1	Adjusting the amount of air	5	7
5.2.5.2	Switching on the heater	5	7
5.3	Stopping loader operation	5	8
5.3.1	Parking the loader	5	8
5.3.2	Switching off the diesel engine	5	8
5.3.3	Switching off the heating and ventilation system	5	8
5.3.4	Leaving the loader	5	8
5.4	Adjusting the operator's seat	5	9
5.5	Switching the steering	5	9

6 Attachments

6.1	Mounting and dismounting attachments without hydraulic connections	6 - 2
6.1.1	Standard/lightweight bucket	6 - 2
6.1.2	Fork-lift attachment	6 - 3
6.1.3	Lifting hook	6 - 4
6.2	Mounting and dismounting attachments with a hydraulic connection	6 - 4
6.2.1	Multi-purpose bucket	6 - 4
6.3	Using other attachments	6 - 6

7 Rescue, towing, lashing, lifting by crane

7.1	Rescue, towing, lashing	7 - 2
7.1.1	Rescuing/towing of the loader if the engine or drive has failed	7 - 2
7.1.1.1	Towing the swivel loader when the engine has failed	7 - 2
7.1.1.2	Towing the swing shovel loader when the drive has failed	7 - 4
7.2	Lifting by crane	7 - 5

8 Maintenance

8	Maintenance plan	8 - 1
8.1	Maintenance notes	8 - 3
8.2	Maintenance work	8 - 4
8.2.1	Checking the engine oil level	8 - 4
8.2.2	Checking the oil level in the axles	8 - 4
8.2.2.1	Rear axle	8 - 4
8.2.2.2	Planetetary gear	8 - 4
8.2.2.3	Front axle	8 - 4
8.2.3	Changing the oil in the distribution gear	8 - 5
8.2.4	Checking the oil level in the hydraulic oil reservoir	8 - 5
8.2.5	Changing the engine oil	8 - 5
8.2.6	Changing the oil in the axles	8 - 6
8.2.6.1	Rear axle	8 - 6
8.2.6.2	Planetary gear	8 - 7
8.2.6.3	Front axle	8 - 7
8.2.7	Changing the oil in the hydraulic system	8 - 8
8.2.8	Changing the backflow suction filter insert/suction strainer	8 - 9
8.2.9	Maintaining/replacing the air filter	8 - 9
8.2.10	Changing the safety cartridge	8 - 10
8.2.11	Replacing the fuel filter	8 - 11
8.2.12	Exchanging the starter battery	8 - 11
8.2.13	Maintaining/replacing the fresh air filter	8 - 11
8.2.14	Checking/adjusting the parking brake	8 - 12
8.2.15	Checking/adjusting the service brake	8 - 13
8.3	Lubrication points	8 - 13
8.3.1	Rear axle pivot bolt	8 - 13
8.3.2	Rear axle	8 - 14
8.3.3	Front axle	8 - 14
8.3.4	Bucket motor	8 - 14
8.3.5	Ball rotary connection	8 - 15
8.3.6	Driver cabin door	8 - 15
8.3.7	Engine hood	8 - 15
8.3.8	Multi-purpose bucket	8 - 16

9 Malfunctions, causes and remedies

10 Diagrams

10.1	Wiring diagram	10 - 1
10.2	Hydraulic circuit diagram	10 - 4

11 Technical data (loader)

11.1	Loader	11	-	2
11.2	Engine	11	-	2
11.3	Starter	11	-	2
11.4	Alternator	11	-	2
11.5	Hydrostatic drive unit	11	-	2
11.6	Axle loads	11	-	2
11.7	Tires	11	-	3
11.8	Steering system	11	-	3
11.9	Brake system	11	-	3
11.10	Electrical system	11	-	3
11.11	Hydraulic system	11	-	3
11.11.1	Swivel mechanism	11	-	3
11.11.2	Stabilizers	11	-	3
11.12	Fuel supply system	11	-	4
11.13	Heating and ventilation system	11	-	4
11.14	Full flow suction filter	11	-	4
11.15	Electrical contamination indicator	11	-	4
11.16	Oil cooler with thermostat control	11	-	4
11.17	Noise emission	11	-	4

12 Technical data (Attachments)

12	Attachments	12	-	2
12.1	Buckets	12	-	2
12.2	Fork-lift attachment	12	-	4
12.4	Lifting hook	12	-	6

13 Additional options, modifications, notes on inspection for loaders

13.1	Additional options	13	-	2
13.2	Modifications	13	-	2