

Maintenance

8 Maintenance

8.1 Maintenance notes



DANGER

- The engine must be turned off.
- For work to be carried out under the bucket arm:
 - the bucket must be emptied or the attachment must be relieved,
 - the bucket arm support (1-1/arrow) is to be inserted,
 - the ball block valve for the working and auxiliary hydraulics (1-2/arrow) must be closed,
 - the swivel mechanism is to be blocked (1-4/arrow).
- The loader is to be secured against rolling by using the parking brake (4-10/8) and by setting the drive direction switch (4-10/3) to the "0" position. In addition, wedges must be placed on both sides of one of the two wheels of the front axle.



CAUTION

- Change the oil when the units are lukewarm.
- Perform maintenance work when the loader is on level ground and the bucket arm is in its lowest position.
- Replace damaged filter inserts and gaskets immediately.
- Clean pressure lubrication fittings before lubricating.



NOTE

- All necessary maintenance work is to be taken from the maintenance plan.
- Damage which is traceable to non-observance of the maintenance plan is not covered by the guarantee.
- The lubricants mentioned in the maintenance plan can be used at an ambient temperature from **-15°** to **+40°C**.



CAUTION

For ambient temperatures below **-15° C**, refer to the description in chapter 5.2.2 "Winter operation".



NOTE

If a hose and/or pipe break occurs, the two lids of the hydraulic oil filter (8-20/arrows) must be loosened because the loader does not have a shut-off valve that could prevent large amounts of hydraulic oil from escaping.

8.2 Maintenance work

8.2.1 Checking the engine oil level

See Engine Operating Instructions.

8.2.2 Checking the oil level in the axles

8.2.2.1 Rear axle of the slow loader » 20 km/h «

(1) Unscrew the plugs from the axle arch (8-1/arrow) and the intermediate gear (8-2/arrow).

NOTE

- The axle arch and the intermediate gear do not have a common oil reservoir.
- The oil level must reach the plug bores.
- Collect any escaping oil.

(2) Replace the plugs.




Figure 8-1




Figure 8-2

8.2.2.2 Rear axle of the » fast loader «

(1) Unscrew the plugs from the axle arch (8-3/arrow) and the distribution gear (8-4/arrow).




Figure 8-3




Figure 8-4

NOTE

- The axle arch and the distribution gear do not have a common oil reservoir.
- The oil level must reach the plug bores.
- Collect any escaping oil.

(2) Replace the plugs.



Figure 8-5

8.2.2.3 Planetary gear

(1) Move the loader until the marking line "OIL LEVEL" is horizontal and the plug is located above the top left of the marking line (8-5/arrow).

(2) Unscrew the plug.

NOTE

- The oil level must reach the plug bore.
- Collect any escaping oil.

(3) Fit a new gasket and replace the plug.




Figure 8-6

8.2.2.4 Front axle

(1) Unscrew the plug (8-6/arrow) from the axle arch.

NOTE

- The oil level must reach the plug bore.
- Collect any escaping oil.

(2) Replace the plug.

8.2.3 Checking the oil level in the hydraulic oil reservoir

- (1) Park the loader in a level position.
- (2) Move the bucket to its lowest position.
- (3) Tilt the quick-change device and move out the locking bolts using the hand lever for the auxiliary hydraulics (4-9/5).
- (4) Open the motor cover.
- (5) Check the oil level in the sight glass.

NOTE

The oil level must be visible in the upper quarter of the sight glass (8-7/arrow). If necessary, fill oil into the filler neck (8-18/arrow).




Figure 8-7

8.2.4 Changing the engine oil

- (1) Unscrew the maintenance flap from the motor protection (size 13) (8-8/arrow).
- (2) Place a sufficiently large oil drain pan underneath the motor oil sump.
- (3) Open the motor cover.
- (4) Unscrew the cover of the oil drain plug on the motor.
- (5) Screw the drainage nozzle with hose from the tool box (4-1/13) to the oil drain plug.
- (6) Remove the cover cap from the hose.
- (7) Further procedures are to be found in the Engine Operating Manual.



Figure 8-8

8.2.5 Changing the oil in the axles

8.2.5.1 Rear axle of the »slow loader« » 20 km/h «

- (1) Place a sufficiently large oil drain pan underneath the axle.
- (2) Unscrew the plugs from the axle arch (8-9/1, 8-9/2, 8-9/3 and 8-9/4) and the intermediate gear (8-10/1 and 8-10/2) and let the oil drain out.

CAUTION

Waste oil must be disposed of in such a way that it will not cause pollution!




Figure 8-9




Figure 8-10

(3) Replace the plugs for the axle arch (8-9/1 and 8-9/2) and the intermediate gear (8-10/2).

(4) Fill oil into the plug bore of the axle arch (8-9/3) and of the intermediate gear (8-10/1) until the oil reaches the opening (8-9/4 or 8-10/1).

NOTE

- The axle arch and the intermediate gear do not have a common oil reservoir.
- Information about the quantity of oil is given in the maintenance plan (chapter 8.4).
- After a few minutes, when the oil level has lowered, top up the oil until the oil level reaches the marked level and remains stable.

(5) Replace the plugs for the axle arch (8-9/3 and 8-9/4) and the intermediate gear (8-10/1).




Figure 8-11

8.2.5.2 Rear axle of the » fast loader «

(1) Place a sufficiently large oil drain pan underneath the axle.

(2) Remove the plugs from the axle arch (8-11/1, 8-11/2, 8-11/3 and 8-11/4) and the distribution gear (8-12/1 and 8-12/2) and drain the oil.

CAUTION

Waste oil must be disposed of in such a way that it will not cause pollution.

(3) Replace the plugs for the axle arch (8-11/1 and 8-11/2) and the distribution gear (8-12/2).

(4) Fill in oil via the plug hole in the axle arch (8-11/3) and the distribution gear (8-12/1) until the oil reaches the opening (8-11/4 or 8-12/1).

NOTE

- The axle arch and the distribution gear do not have a common oil reservoir.
- Information about the quantity of oil is given in the maintenance plan (chapter 8.4).
- After a few minutes, when the oil level has lowered, top up the oil until the oil level reaches the marked level and remains stable.

(5) Replace the plugs for the axle arch (8-11/3 and 8-11/4) and the distribution gear (8-12/1).




Figure 8-12

8.2.5.3 Planetary gear

- (1) Move the loader so that the plug (8-13/arrow) is positioned at 6 o'clock.
- (2) Place an oil drain vessel with a drain channel underneath the gear.
- (3) Unscrew the drain plug and let the oil drain out.

CAUTION

Waste oil must be disposed of in such a way that it will not cause pollution.



Figure 8-13

- (4) Move the loader until the marking line "OIL LEVEL" is horizontal and the plug is located above the top left of the marking line (8-14/arrow).
- (5) Fill in oil via the plug bore until the oil level reaches the opening.
- (6) Use a new gasket when replacing the plug.




Figure 8-14

8.2.5.4 Front axle

- (1) Place a sufficiently large oil drain pan underneath the axle.
- (2) Unscrew the plugs from the axle arch (8-15/1, 8-15/2, 8-15/3, 8-16/1 and 8-16/2) and drain the oil.

CAUTION

Waste oil must be disposed of in such a way that it will not cause pollution.




Figure 8-15




Figure 8-16

- (3) Replace the plugs (8-15/1 and 8-16/1).
- (4) Fill in oil via the plug bore (8-15/3) until the oil level reaches the opening (8-15/2 or 8-16/2).

NOTE

- Information about the quantity of oil is given in the maintenance plan (chapter 8.4).
- After a few minutes, when the oil level has lowered, top up the oil until the oil level reaches the marked level and remains stable.

- (5) Replace the plugs (8-15/2 and 8-15/3 and 8-16/2).

8.2.6 Changing the oil in the hydraulic system

- (1) Have an oil pan ready (at least 130 l).
- (2) Unscrew the cap of the oil drain (8-17/arrow).
- (3) Screw the drainage nozzle with hose from the tool box (4-1/13) to the oil drain plug.
- (4) Remove the cover cap from the hose.
- (5) Drain the oil into the drain pan.

CAUTION

Waste oil must be disposed of in such a way that it will not cause pollution!




Figure 8-17

- (6) Remove the nozzle with the hose and replace the cover cap on the hose.
- (7) Replace the cap on the oil drain.
- (8) Change the hydraulic oil filter inserts (section 8.2.7).
- (9) Fill in oil into the filler neck (8-18/arrow).

CAUTION

For those loaders which are fitted to run with biodegradable hydraulic oil (synthetic hydraulic oil on ester basis - viscosity class ISO VG 46 VI > 180) (designation can be found on the hydraulic oil tank and on the dashboard), only this type of oil may be used for oil changes.

Mineral and biodegradable oils must **never** be mixed.

Biodegradable hydraulic oil must be changed every **1000 operating hours**.

Changing the oil type from mineral oil to biodegradable oil must be performed according to the VDMA 24 569 conversion guidelines!

CAUTION

The service brake must only be operated with mineral oil!



Figure 8-18

- (10) Check the oil level at the sight glass (8-7/arrow).
- (11) Close the filling nozzle.

8.2.7 Changing the hydraulic oil filter inserts

CAUTION

Change the filter inserts according to the maintenance plan or when the clogging indicator lamp (4-11/23) lights up.

NOTE

The clogging indicator lamp may light up briefly after a cold start but will go out when the hydraulic oil has reached its operating temperature.

- (1) Move the seat to the frontmost position (5-12/2).
- (2) Tilt the backrest of the seat completely forward (5-11/2).
- (3) Fold back the insulation mats to the left and the right of the driver's seat, unscrew the four screws (size 13) (8-19/arrows) that fix the maintenance plate and remove the plate.
- (4) Loosen the lids of the hydraulic oil filters (8-20/arrows) and replace the filter inserts by new ones.

CAUTION

Waste hydraulic oil filter inserts must be disposed of in such a way that they will not cause pollution.

- (5) Lock the lids of the hydraulic oil filters.
- (6) Fasten the maintenance plate.
- (7) Restore the individual seat position.



Figure 8-19




Figure 8-20

8.2.8 Maintaining/replacing the air filter

NOTE

Maintenance of the filter cartridge is necessary when either the red range is visible in the maintenance indicator (8-21/1) or after 12 months, whichever is sooner.

- (1) Open the engine cover.
- (2) Loosen the three spring-loaded catches on the air filter lid (8-21/2) and remove the air filter lid.




Figure 8-21




Figure 8-22

(3) Pull out the filter cartridge (8-22/arrow) by carefully turning it back and forth.

(4) Clean the filter cartridge.

CAUTION

- For cleaning, use a compressed air gun to which a pipe (angled at 90°) has been attached. The pipe must be sufficiently long to reach the cartridge bottom. Use dry compressed air of no more than 5 bar to blow out the cartridge by moving the pipe back and forth in the interior of the cartridge. Cleaning can be stopped when dust formation ceases.

- Do not use petrol or hot liquid for cleaning.

(5) Use a hand-held lamp to check the filter cartridge for damage to the cartridge paper or the rubber gasket. If the cartridge or seals are damaged, replace the cartridge.

(6) Carefully insert the filter cartridge.

(7) Install the air filter lid on the filter housing in such a way that the direction arrow in the marking "OBEN-TOP" points towards half past one.



NOTE

The dust removal valve must be checked from time to time and cleaned if necessary.

(8) When the indicator field becomes red (8-21/1), push the reset button. The field becomes clear.



CAUTION

Check all connection pipes and hoses of the air filter system for damage before starting the engine.

8.2.9 Changing the safety cartridge

CAUTION

- The safety cartridge must not be cleaned.
- The safety cartridge must be replaced after the filter cartridge has been maintained/cleaned 5 times, at the latest after two years.
- Make sure that no dirt or dust can enter the filter housing during replacement of the safety cartridge.

(1) Remove the filter cartridge (section 8.2.8).

(2) Pierce the seal of the safety cartridge (8-23/arrow) from the inside by using a screwdriver or similar tool and pull up both strips.

(3) Hold the safety cartridge by both strips and pull it out by carefully turning it back and forth. Replace the safety cartridge and the filter cartridge by new ones.

(4) The remaining installation is performed as described in section 8.2.8 (6)-(8).




Figure 8-23

8.2.10 Replacing the fuel filter

See the Engine Operating Instructions.

8.2.11 Exchanging the starter battery

NOTE

The starter battery is a maintenance-free part according to DIN 72311, section 7. It is located to the right in the motor compartment.

- (1) Pull off the battery main switch (4-10/5).
- (2) Open the motor hood.
- (3) Remove the fastening screw (size 17) (8-24/1) of the battery holder.
- (4) Loosen and remove the connecting cables (8-24/2) from the battery (size 13).

DANGER

Always remove the negative pole cable first and then the positive cable. Installation is in the reverse order.

- (5) Remove the battery and replace it.
- (6) Apply grease to the connecting cables before fastening them.
- (7) Installation is in the reverse order.

DANGER

Make sure the fastenings are secure.

- (8) Close the motor hood.

8.2.12 Maintaining/replacing the fresh air filter

- (1) Lift the bucket arm, insert the bucket arm support and swivel the bucket arm all the way to the right or to the left.
- (2) Loosen the four fastening screws (size 10) (8-25/arrows) of the heater cover and remove the cover.
- (3) Remove the filter elements (8-26/arrows) and clean them with compressed air.

CAUTION

Do not use any petrol, hot fluids or compressed air for cleaning.

- (4) Check the filter elements for damage.

NOTE

The filter elements must be replaced when they are damaged or every **1500 operating hours**.

- (5) Insert the filter elements and install the heater cover.




Figure 8-24



Figure 8-25



Figure 8-26



Figure 8-27

8.2.13 Checking/adjusting the parking brake play

DANGER

- All work on the brake system must only be carried out by authorized personnel.
- Oil loss (leaks) in the brake system must be immediately reported to authorized personnel.

(1) Check the brake's hydraulic oil level (4-10/4) and top up if necessary.

(2) Pull the parking brake lever (8-27/arrow) and release it again (lowest position).

CAUTION

The parking brake should become effective on the third catch.




Figure 8-28

If the path the parking brake lever must travel before the parking brake becomes effective is significantly longer, the following work must be carried out:

NOTE

Figure 8-28 shows a top view of the front axle/chassis area.

1st possibility of an adjustment:

(3) Loosen the adjusting screw on the cable (8-28/3) from the holder and turn it until the visible end of the thread is reached.

(4) Tighten the adjusting screw (8-28/4) until it touches the holder.

2nd possibility of an adjustment:

(5) Loosen the counter nut (8-28/2) at the steering head (8-28/1).

(6) Unhook the steering head and turn it in clockwise direction.

(7) Hook the steering head in again.

(8) Tighten the counter nut again.

CAUTION

- While adjusting the leverage, make sure to check from time to time whether or not the parking brake becomes effective on the 3rd catch.

- The parallel leverage must make contact with the abutments (8-29/arrows) when the parking brake is released.




Figure 8-29

(9) Perform a functional check.

8.3 Grease/oil lubrication points

- Item 8 of the maintenance plan.
- Marked in red on the loader.

8.3.1 Rear axle pivot bolt (8-30/arrows)

CAUTION

The rear axle pivot bolt must be lubricated every **50 operating hours**.




Figure 8-30

8.3.2 Rear axle (8-31/arrows)

CAUTION

The spindle bolts must be lubricated every **50 operating hours**.

NOTE

Lubricate the top and the bottom of the axle spindle bolts on both sides of the axle.




Figure 8-31

8.3.3 Front axle (8-32/arrows)

CAUTION

The spindle bolts must be lubricated every **50 operating hours**.

NOTE

Lubricate the top and the bottom of the axle spindle bolts on both sides of the axle.




Figure 8-32



Figure 8-33

8.3.4 Bucket motor (8-33 and 8-34)

CAUTION

The support bolts of the bucket motor must be lubricated every **10 operating hours**.

Items	1 + 2	Swivel unit/bucket motor
Item	3	Toggle lever
Items	4 + 5	Bucket motor/quick-change device
Items	6 + 7	Tip rod bolt
Item	8	Tip lever
Item	9	Tip lever
Item	10	Deflection lever
Item	11	Deflection lever



Figure 8-34

8.3.5 Ball bearing ring

The grease filling is to avoid friction, and to provide sealing and protection against corrosion. Therefore, the ring must be lubricated **every 10 operating hours** until grease becomes visible on the outside. Swivel the bucket arm in steps of 20° while lubricating the ball bearing ring and make sure to inject grease in each of the four grease nipples (8-35/arrows). It is absolutely necessary to lubricate the machine before and after a longer period of inactivity.

DANGER

- Before you start lubricating, insert the bucket arm support (1-1/arrow), apply the parking brake (4-10/8) and set the drive direction switch (4-10/3) to the "0" position.
- **During** swiveling, no-one may be present in the swivel area of the bucket arm.



Figure 8-35

8.3.6 Driver's cabin doors (8-36/arrows)

CAUTION

The hinges of the driver's cabin doors must be lubricated **every 50 operating hours**.

NOTE

Lubricate the hinges on both doors of the driver's cabin.



Figure 8-36

8.3.7 Multi-purpose bucket

CAUTION

The bearing bolts of the multi-purpose bucket must be lubricated **every 10 operating hours**.

NOTE

- The bolt (8-37/arrow) must be lubricated on both sides of the multi-purpose bucket.




Figure 8-37

- The bolts (8-38/arrows) must be lubricated on both sides of the multi-purpose bucket.




Figure 8-38




Figure 8-39

8.3.8 Front-end excavator

CAUTION

The bearing bolts of the front-end excavator must be lubricated **every 10 operating hours**.

NOTE

- Lubricate the bolts (8-39/1, 8-39/2, 8-39/3, 8-39/5 and 8-39/7) at both ends.
- Item 8-39/4 shows the lubricating point of the shaft cylinder.
- Item 8-39/6 shows the lubricating point of the bucket cylinder.



Figure 8-40

- Item 8-40/1 shows the lubricating point of the shaft cylinder.
- Item 8-40/2 shows the lubricating point of the bucket cylinder.




Figure 8-41

8.3.9 Oil lubrication points

8.3.9.1 Parking brake

CAUTION

Use engine oil to lubricate the joints and deflection levers every 50 operating hours (8-41/arrows).

NOTE

Figure 8-41 shows a top view of the front axle/chassis area.

8.3.9.2 Supporting valve activation (8-42/ arrow)

CAUTION

The leverage of the supporting valve activation must be lubricated with engine oil **every 50 operating hours**.

NOTE

Lubricate only the visible surface of the spring housing piston rod.



Figure 8-42

8.4 Maintenance Plan

4182633A					Every x operating hours					max. permitted intervals or shorter (depending on use)	
					10	50	500	1500	Item	Maintenance points	
					○	△			1.	Engine	
						○			1.1	Maintenance according to manufacturer's regulations	
						○			1.2	Dry air filter system	
						○				Activate dust removal valve	
						○				Check maintenance display	
						○			1.3	Replace filter element if maintenance display is red →	
						○			2	Rear axle with axle power shift gear or gear shift	
						○	△	◇	2.1	Check oil level in axle gear (control screw) →	
						○			2.2	Change oil in axle gear →	
						○	△	◇	2.3	Check oil level in planetary gear (control screw) →	
						○			2.4	Change oil in planetary gear →	
						○			2.5	Check oil level in power shift gear (control screw) →	
						○	△	◇	2.6	Change oil in power shift gear →	
						○			3	Front axle	
						○	△	◇	3.1	Check oil level in axle gear (control screw) →	
						○			3.2	Change oil in axle gear →	
						○	△	◇	3.3	Check oil level in planetary gear (control screw) →	
						○			3.4	Change oil in planetary gear →	
						▲	○		4	Axles / cardan shaft(s)	
						▲	○		4.1	Check fastening of axles (720 Nm)	
						▲	○		4.2	Check fastening of cardan shaft(s) (32 Nm)	
						▲	○		5	Wheels and tyres	
						▲	○		5.1	Check air pressure	
						▲	○		5.2	Check fastening of wheel nuts (500 Nm)	
						▲	○		6	Ball bearing slewing ring (swivel loader only)	
						▲	○		6.1	Check fastening (300 Nm)	
						○	△	◇	7	Hydraulic system	
						○			7.1	Replace filter inserts, observe electric control lamp →	
						○			7.2	Oil level check (view glass) →	
						○			7.3	Oil change →	
						○			7.4	Check and clean hydraulic oil cooler →	
									8	Lubrication points (indicated in red) →	
							○		9	Battery	
									9.1	Visual check	
									10	Brake system	
						○			10.1	Service and parking brake: Take function and visual check before starting work	
									10.2	Service brake: visually check compensation tank	
									10.3	Parking brake: check and adjust if required →	
									11	Lighting system / fresh air filter	
									11.1	Take function test before starting work	
									11.2	Check fresh air filter	