



# **AX Series Articulated loader**



FIN: Valid from W09P85296FBA08807...

**Service manual**

Status: 16.07.2015

<b>Product</b>	Articulated loader AX Series
<b>FIN</b>	as from W09P85296FBA08807
<b>Publisher</b>	<p>MECALAC Baumaschinen GmbH Am Friedrichsbrunnen 2 D-24782 Büdelsdorf</p> <p>Tel: +49 (0)4331 351 325 Fax: +49 (0)4331 351 491 E-Mail: <a href="mailto:info@mecalac.com">info@mecalac.com</a> www: <a href="http://www.mecalac.com">www.mecalac.com</a></p> <p>This document is protected by copyright. All rights reserved. The document may not, in whole or in part, be copied, reproduced, translated or reduced to an electronic medium of machine-readable form without the express permission of MECALAC Baumaschinen GmbH .</p> <p>Subject to change without notice.</p>
<b>Foreword</b>	This operating manual contains all the information and instructions required for the correct execution of service tasks required for the wheel loader. Read this service manual before commencing the tasks and always keep it to hand for reference.
<b>Validity</b>	This Service manual applies together with the operating manual of the Articulated loader AX Series.
<b>Suggestions and comments</b>	...regarding this documentation or the wheel loader can be sent to the above-mentioned address.
<b>Most recent amendment</b>	16.07.2015



# Contents

<b>1 Notes for the Reader</b>	<b>5</b>
1.1 Validity	5
1.2 Illustrations	5
1.3 Accentuated text	5
1.3.1 Pictograms	5
1.3.2 Safety instructions	6
1.3.3 Safety note	6
1.3.4 Warning instructions	7
1.3.5 Guideline for action	7
<b>2 Description</b>	<b>9</b>
2.1 Parts of the wheel loader	9
2.2 Front section	10
2.2.1 Overview	10
2.2.2 Hydraulic hoses	10
2.3 Cab - interior	11
2.3.1 Multifunction panel	11
2.3.2 Display	11
2.4 Cab - exterior	14
2.4.1 Overview	14
2.4.2 Central electrics	15
2.5 Engine compartment	17
2.5.1 Overview	17
2.5.2 Diagnosis interface - engine control system	17
2.6 Diagnostic unit	18
2.6.1 Overview	18
2.6.2 Error messages	19
<b>3 Service tasks</b>	<b>21</b>
3.1 Checks	21
3.1.1 Checking the front axle oil level	21
3.1.2 Checking the rear axle oil level	24
3.1.3 Checking the planetary gear oil level	26
3.1.4 Checking the reduction gear oil level	28
3.1.5 Checking the electrical functions and connections	30
3.1.6 Checking the hydraulic hoses	31
3.2 Repair work	32
3.2.1 Changing a wheel	32
3.2.2 Changing the V-belt	35
3.2.3 Changing the fuel pre-filter	39
3.2.4 Changing the fuel filter	42
3.2.5 Changing the fresh air filter	44
3.2.6 Changing the hydraulic fluid filter	45
3.2.7 Changing the engine oil filter	48
3.2.8 Changing the air filter	50
3.3 Changing the consumables	55
3.3.1 Changing the engine oil	55
3.3.2 Changing the gearbox oil of the front axle	58
3.3.3 Changing the gearbox oil of the rear axle	62
3.3.4 Changing the gearbox oil of the planetary gear	65
3.3.5 Changing the gearbox oil of the reduction gear	68
3.3.6 Refilling with diesel fuel	72

3.4 Lubrication .....	74
3.4.1 Lubrication plan .....	74
3.4.2 Lubrication points - engine hood .....	74
3.4.3 Lubrication points - doors .....	75
<b>4 Circuit diagrams .....</b>	<b>77</b>
<b>5 Annex .....</b>	<b>79</b>
5.1 Spare Parts .....	79
5.1.1 Filter .....	79
5.1.2 Consumables .....	80
5.2 Deutz error messages .....	80

# 1 Notes for the Reader

In this chapter you will find information regarding the use of the Service manual:

- Validity (Page 5)
- Illustrations (Page 5)
- Accentuated text (Page 5)

## 1.1 Validity

This service manual contains information and codes of behaviour for service tasks on the Articulated loader AX Series. Read this service manual carefully before the first service. Always use the service manual when performing service tasks. Store the service manual at a central point and to hand for the responsible technical personnel. In accordance with current usage in the industry, the term wheel loader is used in this service manual.

This Service manual applies together with the operating manual of the Articulated loader AX Series.

This service manual applies to technical personnel.

## 1.2 Illustrations




The illustrations in this service manual show the wheel loader in partially simplified form.

## 1.3 Accentuated text

In this service manual, important information is highlighted by symbols or special formatting. The following examples illustrate the most important types of highlighting.

### 1.3.1 Pictograms

#### Pictograms used

Pictogram	Meaning
	Further useful information.
	Conditions that must be fulfilled in order to perform an action
	Tools or material required in order to perform an action.

### 1.3.2 Safety Note

Safety instruction: Special note for an informative section

Explanation of the note.

- The dot identifies measures that relate to the note.

### 1.3.3 Safety instructions

#### Safety Instruction

To ensure the safe implementation, ensure compliance with the following steps:

1. First step of a safety instruction  
! Important note regarding a safety instruction
  2. Second step of a safety instruction.  
→ The result of this step.
- ✓ The safety instruction is complete, the goal of the of a safety instruction has been achieved.

## 1.3.4 Warning notes



### DANGER

#### Warning of injuries leading to fatality

Failure to observe the safety instruction will result in serious damage to health, including death.

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.



### WARNING

#### Warning: Serious Injuries.

Failure to observe the warning can cause serious damage to health, or even death.

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.



### CAUTION

#### Warning: Injuries.

Failure to observe the warning can result in serious damage to health.

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.

### NOTICE

#### Warning: Damage to property.

Ignoring the warning instructions can result in serious damage to the wheel loader or in its surroundings

→ The arrow identifies a precautionary measure you have to take to avoid the hazard.

## 1.3.5 Guideline

Carry out the following steps: = Start of a set of instructions.

1. First step in a sequence of operations.

Required settings . . . . . **Setting values**

2. Second step in a sequence of operations.

↪ The result of this step.

✓ The operation is complete, the goal has been achieved.




## 2 Description

In this chapter you will find additional information regarding the parts of the wheel loader that are not described in the operating manual.

- Parts of the wheel loader (Page 9)
- Diagnostic unit (Page 18)

### 2.1 Parts of the wheel loader



Overview - Parts of the wheel loader


#### Key

No.	Designation	Function
1	Front section	See Chapter: "Front section" (Page 10).
2	Cab - interior	See Chapter: "Cab - interior" (Page 11).
3	Cab - exterior	See Chapter: "Cab - exterior" (Page 14).
4	Engine compartment	See Chapter: "Engine compartment" (Page 17).

## 2.2 Front section

The bucket arm and the valves required for the control of the hydraulic cylinders are located on the front section. The valves are controlled hydraulically or electrically. Due to the mechanical design of the articulated dumper, the supply and control lines in the articulated joint are subjected to high mechanical loading. Care must be taken that the lines are always fixed to the front and rear sections of the vehicle. The lines must be able to move freely without touching other components between the attachment points.

### 2.2.1 Overview



Overview - Front section | Hydraulic hoses and valves

#### Key

No.	Designation	Function
1	Valves	Are responsible for controlling the hydraulic cylinders.
2	Hydraulic hoses	See Chapter: "Hydraulic hoses" (Page 10).

### 2.2.2 Hydraulic hoses

Hydraulic lines must be checked within the framework of the service intervals. Detailed instructions in this regard are to be found in BGR 237.

A recommendation as to the replacement intervals has been compiled on the basis of DIN 20066.

Depending on the demands made on the hoses, the specified replacement intervals can be extended. The replacement interval remains the responsibility of the operator.

#### Description of the replacement intervals of the hydraulic hoses

Demands on the hydraulic hose	Recommended replacement interval
Normal use	6 years (operating life, including a maximum of 2 years' storage)




## Description of the replacement intervals of the hydraulic hoses (Cont.)

Demands on the hydraulic hose	Recommended replacement interval
<p>Enhanced demands:</p> <ul style="list-style-type: none"> <li>increased operating periods; for example, multi-shift operation or brief cycle times of the machine or the pressure impulses.</li> <li>severe external and internal (via the medium) effects, which markedly reduce the period of use of the hydraulic hose.</li> <li>manually-operated hydraulic tools, for example portable shears in scrap yards.</li> </ul>	2 years (operating life)

## 2.3 Cab - interior

### 2.3.1 Multi-function panel



Multi-function panel

#### Key

No.	Designation	Function
1	Display	See Chapter: "Display" (Page 11).


### 2.3.2 Display

#### 2.3.2.1 Overview


The function of the display has been enhanced in the new AX. In the new component, CANbus messages are displayed in addition to the familiar operating parameters. As a rule, these are error messages from the vehicle control system. The actual meaning of the error messages is described in Chapter "Error messages" (Page 19). An error message appears in the display for only as long as the cause remains active.

### 2.3.2.2 Settings in the display

The following flowchart shows how the various display modes and settings are implemented directly in the component. The operation of the display is described in the operating manual.




Display – settings



Display – engine and wheel loader messages

## 2.4 Cab - exterior

### 2.4.1 Overview



Cab - exterior | Side view – right-hand side


#### Key

No.	Designation	Function
1	Central electrical system	See Chapter: "Central electrical system" (Page 15).

## 2.4.2 Central electrical system

With the implementation of the required emission directives of the Tier standard, a new generation of vehicle control system has been introduced in the AX product segment. Electronic control of the power unit that is taken for granted in today's automotive industry in order to achieve the required emission values, has been enhanced in this stage of development to include electronic control of the hydraulic movement function. Furthermore, communication of the control signals has been optimised by the implementation of a CANbus system between the control units in the vehicle.

### 2.4.2.1 Overview




Overview - Central electrical system

#### Key

No.	Designation	Function
1	Diagnosis interface - vehicle control system	See section "Diagnosis interface - vehicle control system" (Page 15).
2	Location of the control systems	See section "Location of the control systems" (Page 16).


### 2.4.2.2 Diagnosis interface - vehicle control system



Diagnosis interface - vehicle control system

The diagnostic unit is connected to the vehicle control system diagnosis interface.  
Further information regarding the diagnostic unit can be found in Section: Diagnostic unit (Page 18).


#### **2.4.2.3 Location of the control systems**



Location of the control systems

## 2.5 Engine compartment

### 2.5.1 Overview



Overview - Engine compartment - frontal view

#### Key

No.	Designation	Function
1	Diagnosis interface - engine control system	See section Diagnosis interface - engine control system (Page 17).

### 2.5.2 Diagnosis interface - engine control system



Diagnosis interface - engine control system

The diagnostic unit is connected to the engine control system diagnosis interface. Further information regarding the diagnostic unit can be found in Section: Diagnostic unit (Page 18).



## 2.6 Diagnostic unit

### 2.6.1 Overview

The diagnostic unit serves as a reader to read and display engine and vehicle data from the CANbus system. In addition, stored error messages can be read and reset. The list of the error messages are to be found in Section Error messages (Page 19).

Active errors are displayed in the display. In addition, this error is stored in the main memory of the controller. The error memory is read and analysed within the framework of the recurring service.

Once the error has been processed, the error memory is deleted (reset).

The engine control diagnosis interface and the vehicle control diagnosis interface permit various diagnostic units to be used.



Diagnostic unit



## 2.6.2 Error messages

The controller messages that are shown in the display are listed in the following table. By using this information and a standard multimeter, the causes of the error can be identified and the function of the electrical components can be checked with on-board resources.

Errors from the engine control system are based on the mandatory SAE j1939 protocol. This is used internationally by various manufacturers.

The list of all messages from the "U05" engine controller are to be found in the annex of this service manual (See page 79: Annex).

Messages from the vehicle control system are generated as "M-messages (Mecalac)". As is the case with engine messages, they are shown in the display (only if active).

### Error messages from the driving control system

Error	Meaning	Remedy
M001	Tortoise Valve Y01	Check Valve Y01, check Circuit 1009
M002	Differential lock valve error	Check Valve Y055, check Circuit 1003
M003	Oil temperature sensor error	Check Sensor P06, check Circuit 1015 and GND_S2_U01
M004	Quick-change device error	Check Valve Y16, check Circuit 1003
M005	Drive train valve error	Check Valves Y33, Y34, Y37, check Circuits 1008, 1007, 1024
M006	Pipe burst detection valve error	Check Valves Y52a, Y52b, check Circuits 1004, 1005
M007	Inching pedal signal error	-
M008	Hand throttle signal error	Check Potentiometer JS05, check Circuit 1026
M009	Accelerator pedal signal error	Check Accelerator pedal P11, check Circuits 1016, 1017
M010	Engine communication error	Check Circuits CAN1-H, CAN1-L, check contact on Instrument U06 and Engine Controller U05
M011	Controller communication error	Check Circuits CAN1-H, CAN1-L, check contact on Instrument U06 and Engine Controller U05
M012	Front wiper control error	Check Relay K02, check Circuit 6003
M013	Option 3 control error	Check Relay K01, check Circuit 6015
M014	Option 4 control error	Check Relay K05, check Circuit 6016
M015	Control relay K14 (KI.50) error	Check Relay K14, check Circuit 6009




## 3 Service tasks

In this chapter you will find information regarding service tasks for technical personnel:

- Checks (Page 21)
- Repair work (Page 31)
- Changing the consumables (Page 54)
- Lubrication (Page 73)

### 3.1 Checks

#### 3.1.1 Checking the front axle oil level



Location of the bolts on the front axle

#### Key

No.	Designation
1	Filler plug
2	Oil level plug
3	Drain plug

**Requirement**

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.

**Tools required:**

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary

**WARNING****Health hazard posed by gearbox oil!**

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.


**NOTICE****Environmental hazard posed by gearbox oil!**

The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:


1. Place an oil drip tray beneath the front axle.
  - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.
2. Using an Allen key, unscrew the oil level plug.



3. Catch any escaping gearbox oil in the oil drip tray immediately.

4. Check the oil level of the front axle.

**!** The oil level must reach precisely below the lower edge of the inspection port .



5. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .

**!** In order to top up, the filler plug must be unscrewed.

6. Using an Allen key, secure the oil level plug.

7. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

✓ Done.

### 3.1.2 Checking the rear axle oil level



#### Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



#### Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary



#### **WARNING**

##### **Health hazard posed by gearbox oil!**

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

#### **NOTICE**

##### **Environmental hazard posed by gearbox oil!**


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the rear axle.
  - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.


2. Using an Allen key, unscrew the oil level plug.



3. Catch any escaping gearbox oil in the oil drip tray immediately.

4. Check the oil level of the rear axle.

**!** The oil level must reach precisely below the lower edge of the inspection port .



5. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .
6. Using an Allen key, secure the oil level plug.
7. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

✓ Done.

### 3.1.3 Checking the planetary gear oil level



#### Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



#### Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary



#### WARNING

##### Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

#### NOTICE


##### Environmental hazard posed by gearbox oil!

The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.


Carry out the following steps:

1. Move the wheel loader so that the oil level fill level line of the planetary gear is horizontal.






2. Place an oil drip tray in the tyre rim.  
 ↳ The oil drip tray prevents the gearbox oil from penetrating the subsoil.
3. Using an Allen key, unscrew the oil level plug.




4. Catch any escaping gearbox oil in the oil drip tray immediately.
5. Check the oil level of the planetary gear.  
 ! The oil level must reach precisely below the lower edge of the inspection port .



6. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .
  7. Using an Allen key, secure the oil level plug.
  8. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,
- ✓ Done.

### 3.1.4 Checking the reduction gear oil level



Location of the bolts on the of the reduction gear

#### Key

No.	Designation
1	Oil level plug
2	Drain plug



## Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



## Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil, if necessary



## WARNING

### Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

## NOTICE


### Environmental hazard posed by gearbox oil!

The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the reduction gear.  
➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.
2. Using an Allen key, unscrew the oil level plug.



3. Catch any escaping gearbox oil in the oil drip tray immediately.
  4. Check the oil level of the reduction gear.  
! The oil level must reach precisely below the lower edge of the inspection port .
  5. If required, top up with fresh gearbox oil up to the lower edge of the inspection port .
  6. Using an Allen key, secure the oil level plug.
  7. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,
- ✓ Done.

### 3.1.5 Checking the electrical functions and connections

Carry out the following steps:

1. Test all electrical functions
  2. Check that the electrical plugs and sockets are securely seated.
    - ↳ Fuses
    - ↳ Relays
  3. Perform a visual inspection of the cable harnesses.  
! Check that they are seated securely.
  4. Measure the battery voltage.
  5. Measure and check the functioning of the alternator.
  6. Check that the main battery switch functions correctly.
  7. Check that the body is electrically isolated.
- ✓ Done.

### 3.1.6 Checking the hydraulic hoses

Carry out the following steps:

1. Check all hydraulic hoses for leaks and mechanical damage.  
! Detailed instructions are to be found in BGR 237.
  2. Exchange damaged hydraulic hoses immediately.
- ✓ Done.



#### Info

The recommended replacement intervals for the hydraulic hoses to be found in Chapter: "Description" > "Hydraulic hoses" (Page 10).

## 3.2 Repair work

### 3.2.1 Changing a wheel



#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The direction of travel toggle switch must be in the neutral position.
- The ignition key has been removed.



#### Tools required:

- Two persons
- One jack suitable for the mass of the wheel loader
- A suitable base for the jack
- Safety block
- Protective gloves
- Wheel-brace
- A torque wrench
- A new wheel

Dismount the  
wheel



### CAUTION


#### Hazard of crush injuries to limbs!

The tyre of the wheel loader is large and heavy. You can be crushed if it tips over!


- Always wear protective gloves!
- Always wear safety shoes!
- Always work carefully!
- Always carry out a wheel change with two persons!

Carry out the following steps:

1. Using the wheel-brace loosen all eight wheel nuts by approximately half a turn.



2. Position a suitable base beneath the jack below the jacking points of the axle of the wheel to be changed.




3. Place the safety blocks centrally on the upper end of the jack.



4. Using the jack lift up the wheel loader.

! The wheel must be lifted approximately one centimetre off the ground.



↪ The wheel has been lifted.

5. Using the wheel-brace remove all eight wheel nuts.



6. With two persons, carefully lift the wheel off the axle .

The wheel has been dismounted.

Mounting the  
wheel.



Carry out the following steps:

1. With two persons, carefully lift the new wheel onto the axle .
2. Screw in the eight wheel nuts on the wheel loader.  
! Only fasten the wheel nuts finger-tight.
3. Loosen the jack.
4. Remove the jack, the base and the safety blocks.

5. Tighten all eight wheel nuts to 500 Nm .  
! For fastening, use a suitable torque wrench.



The wheel has been mounted.


✓ Done.



#### Info

After approximately ten hours of operation, re-tighten the wheel nuts of the wheel that has been changed.

### 3.2.2 Changing the V-belt



Location of fastening nuts

#### Key

No.	Designation
1	upper fastening nut
2	lower fastening nut





## Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The ignition key has been removed.



## Tools required:

- Protective gloves
- A new V-belt
- Ratchet with extension and SW 13 socket
- Allen key SW 13



## CAUTION


### Hazard of injuries to limbs by crushing and cutting!

The engine bay of the wheel loader is very cramped. You can be cut and crushed when performing maintenance tasks!


- Always wear protective gloves!
- Always work carefully!

Carry out the following steps:


1. Using the ratchet, loosen the upper fastening nut.



2. Using the wrench, loosen the upper fastening nut.




3. Turn the alternator inwards in the engine bay.




→ The V-belt is loosened.

4. Remove the V-belt.



5. Install the new V-belt.

6. Pull the alternator upwards.  
↳ The V-belt is tensioned.
7. Refasten the upper and lower fastening nuts.



✓ Done.

### 3.2.3 Changing the fuel pre-filter



#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



#### Tools required:

- Strap wrench
- Protective gloves
- A new fuel pre-filter

Changing the fuel  
pre-filter



#### **WARNING**

#### **Fire hazard due to ignition of the diesel fuel!**

Burns may result. In addition, the wheel loader will be damaged by the fire!

- Smoking is prohibited when working on the fuel filter of the wheel loader!
- Immediately clean up any diesel fuel that has spilled.



#### **WARNING**

#### **Health hazard posed by diesel fuel!**

The diesel fuel is hazardous to health. Frequent skin contact can be carcinogenic.

- Avoid continuous skin contact with the diesel fuel.
- Always wear gloves when carrying out this job.

#### **NOTICE**

#### **Environmental hazard posed by diesel fuel!**


The diesel fuel used by the wheel loader is hazardous to the environment!

- Dispose of the diesel fuel according to the local statutory provisions,
- Catch the draining diesel fuel in a suitable container.
- Prevent the diesel fuel from entering the soil.

Carry out the following steps:

1. Carefully detach the connection cable for the water level sensor.






2. Place the strap of the strap wrench around the fuel pre-filter.
3. Loosen the fuel pre-filter with the aid of the strap wrench.



4. Carefully pull the fuel pre-filter from the mounting.
5. Unscrew the water separator valve from the fuel pre-filter .



6. Fasten the water separator valve onto the new fuel pre-filter .
7. Screw the new fuel pre-filter into the mounting.
8. Install the connection cable for the water level sensor.

The fuel pre-filter has been changed.

#### Bleeding the fuel system



Carry out the following steps:

1. Insert the ignition key of the wheel loader into the ignition lock.
2. Turn the ignition key clockwise to position **I**.
  - ↪ The ignition system of the wheel loader is switched on.
  - ↪ The fuel supply pump is switched on.
3. Wait 20 seconds.
4. Turn the ignition key clockwise to position **0**.
  - ↪ The ignition system of the wheel loader is switched off.
5. Repeat steps **1 TO 4** twice.
  - ↪ The fuel system is bled piece by piece.
  - ↪ The fuel pressure required for operation is built up.

The fuel system has been bled.

✓ Done.

### 3.2.4 Changing the fuel filter



#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



#### Tools required:

- Strap wrench
- Protective gloves
- A new fuel filter



#### WARNING

##### **Fire hazard due to ignition of the diesel fuel!**

Burns may result. In addition, the wheel loader will be damaged by the fire!

- ➔ Smoking is prohibited when working on the fuel filter of the wheel loader!
- ➔ Immediately clean up any diesel fuel that has spilled.



#### WARNING

##### **Health hazard posed by diesel fuel!**

The diesel fuel is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the diesel fuel.
- ➔ Always wear gloves when carrying out this job.

#### NOTICE

##### **Environmental hazard posed by diesel fuel!**

The diesel fuel used by the wheel loader is hazardous to the environment!

- ➔ Dispose of the diesel fuel according to the local statutory provisions,
- ➔ Catch the draining diesel fuel in a suitable container.
- ➔ Prevent the diesel fuel from entering the soil.

Carry out the following steps:

1. Place the strap of the strap wrench around the fuel pre-filter.
2. Loosen the fuel pre-filter with the aid of the strap wrench.



3. Carefully pull the fuel pre-filter from the mounting.
  4. Screw the new fuel pre-filter into the mounting.
- ✓ Done.



## 3.2.5 Changing the fresh air filter



### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.




### Tools required:

- Protective gloves
- A new fresh air filter
- Wrench

Carry out the following steps:

1. Using the wrench, remove the four screw fasteners of the driver's seat baseplate.



2. Carefully lift the driver's seat together with the base plate out of the cab.
3. Carefully withdraw the old fresh air filter.
4. Install the new fresh air filter.V-belt.
5. Carefully lift the driver's seat together with the base plate into the cab.

6. Using the wrench, fasten the four screw fasteners of the driver's seat baseplate.

✓ Done.

### 3.2.6 Changing the hydraulic fluid filter




#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



#### Tools required:

- Two persons
- Protective gloves
- Wrench SW 27
- Oil-absorbent mat
- Oil drip tray
- A new hydraulic fluid filter

Remove the  
hydraulic fluid filter  




### WARNING

#### Health hazard posed by hydraulic fluid!

The hydraulic fluid is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the hydraulic fluid.
- ➔ Always wear gloves when carrying out this job.

### NOTICE

#### Environmental hazard posed by hydraulic fluid!


The used hydraulic fluid of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used hydraulic fluid according to the local statutory provisions,
- ➔ Catch the draining hydraulic fluid in a suitable container.
- ➔ Prevent the hydraulic fluid from entering the soil.

Carry out the following steps:

1. Place the oil-absorbent mats around the hydraulic fluid reservoir.
  - ➔ The oil-absorbent mat protect the interior of the engine bay from contamination.


2. Using the wrench loosen the lid of the hydraulic fluid reservoir.



3. Unscrew the lid by hand.
4. Withdraw the hydraulic fluid filter by the handle .



5. Allow the surplus hydraulic fluid to run into the hydraulic fluid reservoir .



6. Place the hydraulic fluid filter in the oil drip tray.

! The oil drip tray must be held by a second person.



The hydraulic fluid filter is dismantled.

Install the  
hydraulic fluid filter



Carry out the following steps:

1. Insert the new hydraulic fluid filter in the hydraulic fluid reservoir .
2. Screw the lid back onto the hydraulic fluid reservoir by hand.
3. Using the wrench, tighten the lid of the hydraulic fluid reservoir.
4. Remove the oil-absorbent mats.
5. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The hydraulic fluid filter is installed.

✓ Done.

### 3.2.7 Changing the engine oil filter



#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The parking brake is applied.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



#### Tools required:

- Strap wrench
- Protective gloves
- A new engine oil filter
- Oil drip tray

Dismounting the  
engine oil filter



#### WARNING

#### Health hazard posed by engine oil!

The engine oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the engine oil.
- ➔ Always wear gloves when carrying out this job.

#### NOTICE

#### Environmental hazard posed by engine oil!


The used engine oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used engine oil according to the local statutory provisions,
- ➔ Catch the draining engine oil in a suitable container.
- ➔ Prevent the engine oil from entering the soil.

Carry out the following steps:

1. Place the oil drip tray beneath the engine oil filter.
  - ➔ The oil drip tray prevents the engine oil from penetrating the subsoil or entering the interior of the engine bay.
2. Place the strap of the strap wrench around the engine oil filter.

3. Loosen the engine oil filter with the aid of the strap wrench.



4. Carefully pull the engine oil filter from the mounting .

The engine oil filter has been removed.

Install the new  
engine oil filter



Carry out the following steps:

1. Coat the surfaces of the new engine oil filter with fresh lubricating oil.
2. Screw the new engine oil filter into the mounting.
3. Fasten the engine oil filter by hand.
4. Check the oil level of the engine.
5. Dispose of the engine oil that has been collected according to the local statutory provisions.

The new engine oil filter has been installed.

✓ Done.

## 3.2.8 Changing the air filter



### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The diesel engine must be cold.
- The engine hood of the wheel loader is open.
- The ignition key has been removed.



### Tools required:


- A new air filter cartridge
- A new safety cartridge

Dismounting the  
air filter cartridge



Carry out the following steps:

1. Open the three locking mechanisms of the lid.




2. Remove the lid.



**3. Remove the filter cartridge.**

**!** Loosen the filter cartridge with gentle rotating movements left and right.



The air filter cartridge has been dismounted.


Exchanging the  
safety cartridge.



Carry out the following steps:

**1. Remove the safety cartridge.**

**!** Loosen the safety cartridge with gentle rotating movements left and right.






2. Check the interior of the filter housing for dust and dirt.

! If necessary, carefully clean the interior of the filter housing with a cloth.



3. Slide the new safety cartridge carefully into the filter housing.




The safety cartridge has been exchanged.

Re-install the air  
filter cartridge



Carry out the following steps:

1. Slide the inspected filter cartridge back into the holder.




2. Re-install the lid.

! When remounting the lid, take care that the TOP marking faces **upwards** .



**3.** Secure the three locking mechanisms of the lid.



The air filter cartridge has been installed.

✓ Done.

## 3.3 Changing the consumables

### 3.3.1 Changing the engine oil



#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The ignition key has been removed.
- The engine must be warm.



#### Tools required:

- A sufficiently large oil collection container
- A suitable oil drainage hose
- Wrench SW 17
- Protective gloves

Draining the  
engine oil



### WARNING

#### Health hazard posed by engine oil!

The engine oil is hazardous to health. Frequent skin contact can be carcinogenic.

- Avoid continuous skin contact with the engine oil.
- Always wear gloves when carrying out this job.

### NOTICE


#### Environmental hazard posed by engine oil!

The used engine oil of the wheel loader is hazardous to the environment!


- Dispose of the used engine oil according to the local statutory provisions,
- Catch the draining engine oil in a suitable container.
- Prevent the engine oil from entering the soil.

Carry out the following steps:

1. Slacken the three lugs of the sump guard.



**2.** Remove the sump guard.



**3.** Place an oil collection container beneath the sump.

**4.** Unscrew the protective cap of the oil drain plug.



5. Screw the oil drainage hose onto the oil drain plug.  
↳ The engine oil begins draining.
6. Wait until the engine oil has drained completely.
7. Unscrew the oil drainage hose from the oil drain plug.
8. Screw the protective cap back onto the oil drain plug.

The engine oil has been drained.

#### Topping up the engine oil



Carry out the following steps:

- ➔ Refill the engine oil.

The engine oil has been changed.

#### Performing the check



Carry out the following steps:


1. Switch on the diesel engine.
2. Allow the diesel engine to idle for a short while.
3. Switch off the diesel engine.
4. Inspect the sump and the oil drain plug for leaks.
5. Remove the oil collection container.
6. Re-install the sump guard on the wheel loader by using the three lugs.
7. Dispose of the engine oil that has been collected according to the local statutory provisions.

The check is complete.

✓ Done.



## 3.3.2 Changing the gearbox oil of the front axle



Location of the bolts on the front axle

### Key

No.	Designation
1	Filler plug
2	Oil level plug
3	Drain plug



## Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



## Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

Draining the  
gearbox oil

**WARNING****Health hazard posed by gearbox oil!**

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

**NOTICE****Environmental hazard posed by gearbox oil!**

The used gearbox oil of the wheel loader is hazardous to the environment!


- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the front axle.
  - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.



2. Using an Allen key, unscrew the oil drain plug.



↪ The gearbox oil drains immediately.

3. Wait until the gearbox oil has drained completely.
4. Using an Allen key, screw the drain plug back into the front axle.


The gearbox oil has been drained.

Refilling the  
gearbox oil




Carry out the following steps:


1. Using an Allen key, unscrew the oil level plug.



2. Using an Allen key, unscrew the oil drain plug.



3. Refill with fresh gearbox oil up to the lower edge of the inspection port .



4. Using an Allen key, secure the oil level plug.
5. Using an Allen key, secure the oil filler plug.
6. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.

✓ Done.

### 3.3.3 Changing the gearbox oil of the rear axle



#### Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



#### Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

Draining the  
gearbox oil



#### **WARNING**

#### **Health hazard posed by gearbox oil!**

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

#### **NOTICE**

#### **Environmental hazard posed by gearbox oil!**


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the rear axle.
  - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.

2. Using an Allen key, unscrew the oil drain plug.



↪ The gearbox oil drains immediately.

3. Wait until the gearbox oil has drained completely.
4. Using an Allen key, screw the drain plug back into the rear axle.


The gearbox oil has been drained.

#### Refilling the gearbox oil




Carry out the following steps:

1. Using an Allen key, unscrew the oil level plug.



2. Refill with fresh gearbox oil up to the lower edge of the inspection port .



3. Using an Allen key, secure the oil level plug.
4. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.

✓ Done.

### 3.3.4 Changing the gearbox oil of the planetary gear



#### Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



#### Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

Draining the  
gearbox oil



## WARNING

### Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

## NOTICE

### Environmental hazard posed by gearbox oil!

The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.


Carry out the following steps:

1. Move the wheel loader so that the oil level plug of the planetary gear is at the lowest position.





2. Place an oil drip tray in the tyre rim.  
→ The oil drip tray prevents the gearbox oil from penetrating the subsoil.
3. Using an Allen key, unscrew the oil level plug.



→ The gearbox oil drains immediately.

4. Wait until the gearbox oil has drained completely.
5. Using an Allen key, fasten the oil level plug in teplanetary gear.


The gearbox oil has been drained.

Refilling the  
gearbox oil




Carry out the following steps:

1. Move the wheel loader so that the **OIL LEVEL** fill level line of the planetary gear is horizontal.




2. Using an Allen key, unscrew the oil level plug.



3. Fill with fresh gearbox oil in the inspection port.

! The oil level must reach precisely below the lower edge of the inspection port .




4. Using an Allen key, secure the oil level plug.
5. Wipe off any escaping gearbox oil with a cloth .
6. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.

✓ Done.



### 3.3.5 Changing the gearbox oil of the reduction gear



Location of the bolts on the of the reduction gear

#### Key

No.	Designation
1	Oil level plug
2	Drain plug



### Requirement

- The wheel loader is warmed up.
- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The parking brake is applied.
- The ignition key has been removed.



### Tools required:

- Allen key SW 12
- Oil drip tray
- Protective gloves
- Suitable, fresh gearbox oil

### Draining the gearbox oil



## WARNING

### Health hazard posed by gearbox oil!

The gearbox oil is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the gearbox oil.
- ➔ Always wear gloves when carrying out this job.

## NOTICE

### Environmental hazard posed by gearbox oil!


The used gearbox oil of the wheel loader is hazardous to the environment!

- ➔ Dispose of the used gearbox oil according to the local statutory provisions,
- ➔ Catch the draining gearbox oil in a suitable container.
- ➔ Prevent the gearbox oil from entering the soil.

Carry out the following steps:

1. Place an oil drip tray beneath the reduction gear.
  - ➔ The oil drip tray prevents the gearbox oil from penetrating the subsoil.

2. Using an Allen key, unscrew the oil drain plug.



↪ The gearbox oil drains immediately.

3. Wait until the gearbox oil has drained completely.
4. Using an Allen key, secure the oil drain plug.


The gearbox oil has been drained.

Refilling the  
gearbox oil



Carry out the following steps:

1. Using an Allen key, unscrew the oil level plug.



2. Pour fresh gearbox oil into the reduction gear.  
**!** The oil level must reach precisely below the lower edge of the inspection port .
3. Using an Allen key, secure the oil level plug.
4. Remove the oil collection container.

5. Dispose of the gearbox oil that has been collected, according to the local statutory provisions,

The gearbox oil has been refilled.

✓ Done.

### 3.3.6 Refilling with diesel fuel



#### Requirement

- The wheel loader is standing on a horizontal surface.
- The wheel loader is switched off.
- The ignition key has been removed.
- The parking brake is applied.



#### Tools required:

- Cloths
- Ignition key
- Protective gloves
- Ratchet with extension and socket
- Diesel fuel collection container
- suitable fresh diesel fuel

Drain the diesel fuel



#### WARNING

#### Fire hazard due to ignition of the diesel fuel!

Burns may result. In addition, the wheel loader will be damaged by the fire!

- ➔ Refuel the wheel loader only once it has cooled down.
- ➔ Smoking **es strictly prohibited** when refuelling the wheel-loader!
- ➔ Immediately clean up any diesel fuel that has spilled.



#### WARNING

#### Health hazard posed by diesel fuel!

The diesel fuel is hazardous to health. Frequent skin contact can be carcinogenic.

- ➔ Avoid continuous skin contact with the diesel fuel.
- ➔ Always wear gloves when carrying out this job.

#### NOTICE

#### Environmental hazard posed by diesel fuel!


The diesel fuel used by the wheel loader is hazardous to the environment!

- ➔ Dispose of the diesel fuel according to the local statutory provisions,
- ➔ Catch the draining diesel fuel in a suitable container.
- ➔ Prevent the diesel fuel from entering the soil.

Carry out the following steps:

1. Place a diesel fuel collection container beneath the diesel fuel tank.
  - ➔ The diesel fuel collection container prevents the diesel fuel from penetrating the subsoil.

2. Using the ratchet and extension, remove the drain plug.



→ The diesel fuel drains immediately.

3. Wait until the diesel fuel has drained completely.
4. Using the ratchet and extension, refasten the drain plug.

The diesel fuel has been drained.

Refilling diesel fuel Carry out the following steps:



1. Open the engine hood.
2. Open the **«TANK CAP»** of the **«DIESEL FUEL FILLING NOZZLE»**.



3. Carefully pour the **«DIESEL FUEL»** into the **«TANK»**.
4. Close the **«TANK CAP»** of the **«DIESEL FUEL FILLING NOZZLE»**.
5. Wipe off any spilled **«DIESEL FUEL»** with a **«CLOTH»**.

## 6. Close the engine hood.

The diesel fuel has been topped up.

✓ Done.

## 3.4 Lubrication

### 3.4.1 Lubrication plan

Wheel loader lubrication schedule AX Series

Lubrication intervals	Part on wheel loader	Number of lubrication points
after 50 hours of operation	Engine hood	2 lubrication points, see Section "Lubrication points - engine hood" (Page 73).
after 50 hours of operation	Doors	4 lubrication points, see Section "Lubrication points - doors" (Page 74).


### 3.4.2 Lubrication points - engine hood



Engine hood | 2 lubrication points



### 3.4.3 Lubrication points - doors



Doors | each of 2 lubrication points (both sides)

## 4 Circuit diagrams

---


Circuit diagrams can be obtained from Mecalac on request.



## 5 Annex

### 5.1 Spare Parts

#### 5.1.1 Filter



Filter – overview

#### Key

No.	Designation	Mecalac TKZ
1	Filter set	23133428
2	Engine oil filter	23110650
3	Fuel filter	23133339
4	Fuel filter	23133338
5	Air filter set	4198305A
6	Safety cartridge	4198304A
7	Hydraulic fluid filter	23109159

### 5.1.2 Consumables

**Key**

Designation	Quantity	Mecalac TKZ
Engine oil	8	2320062
Gearbox oil	16	23104578
Hydraulic fluid	60	23107305
Lubricating grease cartridge	1	4117807A
Coolant	14	23129554

## 5.2 Deutz error messages



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



Deutz-Code / SPN / Fehlername	Seite
11 / 107 / AirFitSysReac	3
12 / 91 / APP1	3
14 / 91 / APPWm	3
15 / 91 / APPWmPer	4
16 / 108 / APSCD	4
17 / 729 / ArH1	4
18 / 730 / ArH2	5
19 / 676 / ArHCD_NoLd	5
20 / 676 / ArHCD_RlyErr	5
22 / 168 / BattCD	6
23 / 168 / BattCDSysReac	6
24 / 523561 / BIPCy1	6
25 / 523562 / BIPCy2	7
26 / 523563 / BIPCy3	7
27 / 523564 / BIPCy4	7
28 / 523565 / BIPCy5	8
29 / 523566 / BIPCy6	8
30 / 523567 / BIPCy7	8
31 / 523568 / BIPCy8	9
32 / 102 / BPSCD	9
33 / 102 / BPSCDSysReac	9
37 / 111 / CLSCDSysReac	10
38 / 1323 / CmbChbMisfire1	10
39 / 1324 / CmbChbMisfire2	10
40 / 1325 / CmbChbMisfire3	11
41 / 1326 / CmbChbMisfire4	11
42 / 1327 / CmbChbMisfire5	11
43 / 1328 / CmbChbMisfire6	12
44 / 1450 / CmbChbMisfire7	12
45 / 1451 / CmbChbMisfire8	12
46 / 1322 / CmbChbMisfireMul	13
47 / 1346 / CmbChbSysReac	13
48 / 1109 / CoEngShOffDemlgr	13
52 / 1072 / CRERCD	14
53 / 1081 / CSLpCD	14
54 / 704 / CTLpCD	14
55 / 110 / CTSCD	15

Deutz-Code / SPN / Fehlername	Seite
56 / 110 / CTSCDSysReac	15
57 / 701 / Dummy1CD_Max	15
58 / 701 / Dummy1CD_Min	16
59 / 701 / Dummy1CD_SigNpl	16
60 / 702 / Dummy2CD_Max	16
61 / 702 / Dummy2CD_Min	17
62 / 702 / Dummy2CD_SigNpl	17
69 / 2791 / EGRCD_Max	17
70 / 2791 / EGRCD_Min	18
71 / 2791 / EGRCD_SigNpl	18
72 / 2791 / EGRCDIntEGR	18
74 / 923 / EngCDTrqCalcOut	19
75 / 190 / EngMBackUp	19
76 / 190 / EngMCaS1	19
77 / 190 / EngMCrS1	20
78 / 190 / EngMOfsCaSCrS	20
79 / 190 / EngPrtSysReacFOC	20
80 / 190 / EngPrtSysReacORC	21
81 / 703 / ESLpCD	21
82 / 1074 / EXFICD	21
83 / 975 / FanCD	22
85 / 1639 / FanCDEval	22
86 / 523602 / FanCDSysReac	22
87 / 97 / FIFCD	23
89 / 97 / FIFCD_WtLVl	23
90 / 94 / FIPSCD	23
91 / 94 / FIPSCDSysReac	24
94 / 523239 / FrmMngDecv1	24
95 / 523240 / FrmMngFunModOil	24
106 / 523212 / FrmMngTOEngPrt	25
110 / 523216 / FrmMngTOPrHtEnCmd	25
112 / 523218 / FrmMngTORxCCVS	25
113 / 523604 / FrmMngTORxEngTemp	26
117 / 523238 / FrmMngTOSwtOut	26
118 / 523222 / FrmMngTOTCO1	26
120 / 523605 / FrmMngTOTSC1AE	27
121 / 523606 / FrmMngTOTSC1AR	27

Deutz-Code / SPN / Fehlername	Seite
122 / 523607 / FrmMngTOTSC1DE	27
123 / 523608 / FrmMngTOTSC1DR	28
124 / 523609 / FrmMngTOTSC1PE	28
125 / 898 / FrmMngTOTSC1TE	28
126 / 520 / FrmMngTOTSC1TR	29
127 / 523610 / FrmMngTOTSC1VE	29
128 / 523611 / FrmMngTOTSC1VR	29
131 / 523500 / FrmMngTxTO	30
133 / 174 / FTSCD	30
134 / 174 / FTSCDSysReac	30
136 / 523618 / GOTSCD	31
137 / 523619 / GOTSCDSysReac	31
138 / 29 / HdThrt	31
139 / 1638 / HOTSCD	32
140 / 1638 / HOTSCDSysReac	32
141 / 523617 / HWEMonCom	32
142 / 630 / HWEMonEEPROM	33
143 / 523612 / HWEMonRcyLocked	33
144 / 523612 / HWEMonRcySuppressed	33
145 / 523612 / HWEMonRcyVisible	34
146 / 523612 / HWEMonUMaxSupply	34
147 / 523612 / HWEMonUMinSupply	34
149 / 105 / IATSCD	35
150 / 105 / IATSCDSysReac	35
153 / 523350 / InjVlvBnk1A	35
154 / 523351 / InjVlvBnk1B	36
155 / 523352 / InjVlvBnk2A	36
156 / 523353 / InjVlvBnk2B	36
157 / 523354 / InjVlvChipA	37
158 / 523355 / InjVlvChipB	37
159 / 651 / InjVlvCyl1A	37
160 / 651 / InjVlvCyl1B	38
161 / 652 / InjVlvCyl2A	38
162 / 652 / InjVlvCyl2B	38
163 / 653 / InjVlvCyl3A	39
164 / 653 / InjVlvCyl3B	39
165 / 654 / InjVlvCyl4A	39



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software

P490\_ : 220, 310, 501

P491\_ : 220, 310, 400, 501

P492\_ : 213

P513\_ : 214, 300



Deutz-Code / SPN / Fehlername	Seite
166 / 654 / InjVlvCyl4B	40
167 / 655 / InjVlvCyl5A	40
168 / 655 / InjVlvCyl5B	40
169 / 656 / InjVlvCyl6A	41
170 / 656 / InjVlvCyl6B	41
171 / 657 / InjVlvCyl7A	41
172 / 657 / InjVlvCyl7B	42
173 / 658 / InjVlvCyl8A	42
174 / 658 / InjVlvCyl8B	42
175 / 523370 / InjVlvErrDet	43
176 / 523615 / MeUnCD_ADC	43
177 / 523615 / MeUnCDNoLoad	43
178 / 523615 / MeUnCDSCBat	44
179 / 523615 / MeUnCDSCGnd	44
182 / 2634 / MnRly1_SCB	44
183 / 2634 / MnRly1_SCG	45
184 / 523420 / Montir	45
186 / 2634 / MRlyCD	45
187 / 563 / MRlyCDMnRly2	46
188 / 2634 / MRlyCDMnRly3	46
189 / 523450 / MSSCD1	46
190 / 523451 / MSSCD2	47
191 / 523452 / MSSCD3	47
192 / 639 / NetMngCANAOff	47
193 / 1231 / NetMngCANBOff	48
194 / 1235 / NetMngCANCOff	48
195 / 705 / OPLpCD	48
196 / 100 / OPSCD	49
197 / 100 / OPSCD1	49
198 / 100 / OPSCDSysReachHi	49
199 / 100 / OPSCDSysReacLo	50
200 / 1237 / OSwCD	50
201 / 175 / OTSCD	50
203 / 175 / OTSCDSysReac	51
208 / 523470 / PRVMon	51
209 / 157 / RailCD	51
210 / 157 / RailCDOfsTst	52

Deutz-Code / SPN / Fehlername	Seite
211 / 523613 / RailMeUn0	52
212 / 523613 / RailMeUn1	52
213 / 523613 / RailMeUn2	53
214 / 523613 / RailMeUn3	53
215 / 523613 / RailMeUn4	53
216 / 523613 / RailMeUn7	54
218 / 523490 / SOPTst	54
219 / 1079 / SSpMon1	54
221 / 1080 / SSpMon2	55
222 / 523601 / SSpMon3	55
223 / 677 / StrtCDHS	55
224 / 677 / StrtCDLS	56
225 / 624 / SysLamp	56
226 / 158 / T15CD	56
227 / 523550 / T50CD	57
228 / 523550 / TPUMon	57
232 / 84 / VSSCD1	57
235 / 523600 / WdCom	58
236 / 523470 / PRVMonSysReac	58
237 / 523006 / APPCDSwtnSel	58
238 / 523007 / FrmMng_TORxEngPress	59
239 / 523008 / MplClt	59
240 / 98 / OLSCD	59
241 / 98 / OLSCDSysReachHi	60
242 / 107 / ADPSCDAna	60
243 / 98 / OLSCDSysReacLo	60
244 / 523009 / PrvMonWear	61
245 / 523010 / RailMeUn8	61
246 / 523650 / FISys_FLPFMSysReac	61
247 / 523651 / FISys_FTSFMSysReac	62
248 / 523652 / FISys_FlushStateEngineOff	62
249 / 523653 / FISys_RapeOilHeatEx	62
250 / 523654 / FrmMngDieselLvl	63
251 / 523655 / FrmMngFuelTemp	63
252 / 523656 / FrmMngLowPressureDiesel	63
253 / 523657 / FrmMngRapeOilIn	64
254 / 523658 / FrmMngRapeOilLvl	64

Deutz-Code / SPN / Fehlername	Seite
255 / 523659 / FrmMngRapeOilVlv1	64
256 / 523660 / FrmMngRapeOilVlv2	65
257 / 523661 / FrmMngRapeOilVlv3	65
258 / 523662 / FrmMngRapeOilVlv4	65
259 / 523663 / FrmMngRapeOilVlv5	66
260 / 523664 / FrmMngSTIN1RX	66

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 11 / 107 / AirFitSysReac

#### Error description AIR FILTER COND.

Air filter differential pressure: the pressure difference of the intake air between the filter inlet and outlet calculated by ECU is above the target range and the ECU activates a system reaction

##### Error codes

DEUTZ-Errorcode: 11

BlinkCode (short-long-short): 1 - 3 - 6

SPN: 107

##### possible FMI:

- 0: data valid, but above normal working area
- 12: Errorcode not identifiable
- 12: Errorcode not identifiable
- 12: Errorcode not identifiable

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Pressure loss above target range with system reaction, air filter clogged or defective, sensor not working, connection cable damaged

##### Take actions for error repair

Check airfilter and if necessary clean or renew it, check cabling, check air filter and if necessary replace the filter component, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning or Warning and power reduction

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: actual value

### 12 / 91 / APP1

#### Error description THROTTLE 1

Analog accelerator pedal sensor 1 or double accelerator pedal sensor: the voltage measured by ECU is out of the target range or the calculated pedal position is implausible compared with the position of the second pedal

##### Error codes

DEUTZ-Errorcode: 12

BlinkCode (short-long-short): 2 - 2 - 6

SPN: 91

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errorcode not identifiable
- 2: data stream is defective

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Voltage outside target range, signal implausible compared to signal of redundant pedal (analog pedal 1), sensor defective, connection cable damaged

##### Take actions for error repair

Check cabling, check accelerator pedal sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, switching to substitute value

Behaviour error lamp: Priority-Chain or Limp Home

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 14 / 91 / APPWm

#### Error description THROTTLE 1

Digital accelerator pedal sensor (PWM): the signal received by ECU is defective or implausible or the pulse-duty factor is out of the target range

##### Error codes

DEUTZ-Errorcode: 14

BlinkCode (short-long-short): 2 - 2 - 2

SPN: 91

##### possible FMI:

- 8: unusual frequency, pulse or period.
- 8: unusual frequency, pulse or period.
- 2: data stream is defective
- 8: unusual frequency, pulse or period.

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Duty cycle outside target range, signal erroneous or implausible (pedal 1), sensor defective, connection cable damaged

##### Take actions for error repair

Check cabling, check accelerator pedal sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, switching to substitute value

correspond to Priority-Chain or Limp Home

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300

### 15 / 91 / APPWmPer

#### Error description THROTTLE 1

digital accelerator pedal sensor (PWM): the frequency of the signal received by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 15

BlinkCode (short-long-short): 2 - 2 - 2

SPN: 91

#### possible FMI:

- 8: unusual frequency, pulse or period.
- 8: unusual frequency, pulse or period.
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Pulse frequency outside target range (pedal 1), sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, check accelerator pedal sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, switching to substitute value correspond to Priority-Chain or Limp Home

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 16 / 108 / APSCD

#### Error description BAROMETRIC PRESS.

Ambient air pressure sensor (in ECU): the voltage measured by ECU is out of the target range or the calculated ambient air pressure is implausible compared with the charge air pressure

#### Error codes

DEUTZ-Errorcode: 16

BlinkCode (short-long-short): 2 - 9 - 2

SPN: 108

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Ambient air pressure sensor defective, ECU defective

#### Take actions for error repair

Change ECU

#### other error properties

System reaction: Warning, substitute value (0.85bar)

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

### 17 / 729 / ArHt1

#### Error description AIR HEATER RELAY

Air heater relay: the current drain measured by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 17

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 729

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit at EDC output, relay defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check relay and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: shut off value

**18 / 730 / ArHt2****Error description AIR HEATER VALVE**

Air heater magnet valve: the current drain measured by ECU is out of the target range

**Error codes**

DEUTZ-Errorcode: 18

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 730

**possible FMI:**

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

**Errordetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Cable break or short circuit, valve defective, connection cable damaged

**Take actions for error repair**

Check valve and if necessary replace it, check connection cable and if necessary repair or replace it

**other error properties**

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: shut off value

**19 / 676 / ArHtCD\_NoLd****Error description AIR HEATER**

Air heater relay: the ECU detects no switching operation at the input of a readback process

**Error codes**

DEUTZ-Errorcode: 19

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 676

**possible FMI:**

- 12: Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

**Errordetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Relay energized, but no feedback on sense line, relay defective or wrong wired, preheat component defective, connection cable damaged

**Take actions for error repair**

Check cabling of preheat component, if relay not working check relay and if necessary replace it, check preheat component and if necessary replace it, check connection cable and if necessary repair or replace it

**other error properties**

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 3  
Measurement @ errortime: setpoint for output status

**20 / 676 / ArHtCD\_RlyErr****Error description AIR HEATER**

Air heater relay: the ECU detects an implausible signal at the input of a readback process

**Error codes**

DEUTZ-Errorcode: 20

BlinkCode (short-long-short): 2 - 6 - 3

SPN: 676

**possible FMI:**

- 5: current to low or broken wire
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

**Errordetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Relay not energized, but working voltage on sense line, relay defective (can not disconnect or switch off), preheat component defective, connection cable damaged

**Take actions for error repair**

Check cabling of preheat component, if relay not working check relay and if necessary replace it, check preheat component and if necessary replace it, check connection cable and if necessary repair or replace it

**other error properties**

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 3  
Measurement @ errortime: setpoint for output status

**22 / 168 / BattCD****Error description BATTERY VOLTAGE**

Battery voltage: the voltage measured by ECU is out of the target range

**Error codes**

DEUTZ-Errorcode: 22

BlinkCode (short-long-short): 3 - 1 - 8

SPN: 168

**possible FMI:**

- 0: data valid, but above normal working area
- 1: data valid, but below normal working area
- 12: Errorcode not identifiable
- 12: Errorcode not identifiable

**Errorredetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Voltage below target range, battery defective, too high power supply voltage, too high contact resistance, wiring damaged, energie system overloaded, parametering inaccurate, ECU defective

**Take actions for error repair**

Check LIMA?. ECU, cabling, contact resistance, safety fuses, too high load in energy system, check battery and if necessary replace it, check battery pole and if necessary clean it, check connection cable and if necessary repair or replace it, check volta

**other error properties**

System reaction: Warning, substitute value, dependent upon supply voltage (12V, 24V)

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

**23 / 168 / BattCDSysReac****Error description BATTERY VOLTAGE**

Battery voltage: the voltage measured by ECU is out of the target range; the ECU activates a system reaction

**Error codes**

DEUTZ-Errorcode: 23

BlinkCode (short-long-short): 3 - 1 - 8

SPN: 168

**possible FMI:**

- 2: data stream is defective
- 2: data stream is defective
- 12: Errorcode not identifiable
- 12: Errorcode not identifiable

**Errorredetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Above target range with system reaction, too high power supply voltage, parametering inaccurate, ECU defective

**Take actions for error repair**

Check dataset of calibration of working voltage for application, check LIMA? Check voltage of generator, check the parameters and if necessary correct them, replace ECU

**other error properties**

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

**24 / 523561 / BIPCyl1****Error description INJECT. PERIOD ZYL.1**

Begin of injection of cylinder 1: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

**Error codes**

DEUTZ-Errorcode: 24

BlinkCode (short-long-short): 5 - 3 - 1

SPN: 523561

**possible FMI:**

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

**Errorredetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Value outside target range or missing (cylinder 1), magnet valve or injection pump defective

**Take actions for error repair**

Check magnetic valve or injection pump and if necessary change them

**other error properties**

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 25 / 523562 / BIPCyl2

#### Error description INJECT. PERIOD ZYL.2

Begin of injection of cylinder 2: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

#### Error codes

DEUTZ-Errorcode: 25

BlinkCode (short-long-short): 5 - 3 - 2

SPN: 523562

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Value outside target range or missing (cylinder 2), magnet valve or injection pump defective

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

#### other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

### 26 / 523563 / BIPCyl3

#### Error description INJECT. PERIOD ZYL.3

Begin of injection of cylinder 3: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

#### Error codes

DEUTZ-Errorcode: 26

BlinkCode (short-long-short): 5 - 3 - 3

SPN: 523563

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Value outside target range or missing (cylinder 3), magnet valve or injection pump defective

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

#### other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

### 27 / 523564 / BIPCyl4

#### Error description INJECT. PERIOD ZYL.4

Begin of injection of cylinder 4: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

#### Error codes

DEUTZ-Errorcode: 27

BlinkCode (short-long-short): 5 - 3 - 4

SPN: 523564

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Value outside target range or missing (cylinder 4), magnet valve or injection pump defective

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

#### other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value



**28 / 523565 / BIPCyl5****Error description INJECT. PERIOD ZYL.5**

Begin of injection of cylinder 5: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

**Error codes**

**DEUTZ-Errorcode:** 28

**BlinkCode** (short-long-short): 5 - 3 - 5

**SPN:** 523565

**possible FMI:**

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

**Errordetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Value outside target range or missing (cylinder 5), magnet valve or injection pump defective

**Take actions for error repair**

Check magnetic valve or injection pump and if necessary change them

**other error properties**

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

**29 / 523566 / BIPCyl6****Error description INJECT. PERIOD ZYL.6**

Begin of injection of cylinder 6: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

**Error codes**

**DEUTZ-Errorcode:** 29

**BlinkCode** (short-long-short): 5 - 3 - 6

**SPN:** 523566

**possible FMI:**

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

**Errordetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Value outside target range or missing (cylinder 6), magnet valve or injection pump defective

**Take actions for error repair**

Check magnetic valve or injection pump and if necessary change them

**other error properties**

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

**30 / 523567 / BIPCyl7****Error description INJECT. PERIOD ZYL.7**

Begin of injection of cylinder 7: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

**Error codes**

**DEUTZ-Errorcode:** 30

**BlinkCode** (short-long-short): 5 - 3 - 7

**SPN:** 523567

**possible FMI:**

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

**Errordetection**

Errorlamp shows permanent light. Entry in errormemory.

**Possible reason for error**

Value outside target range or missing (cylinder 7), magnet valve or injection pump defective

**Take actions for error repair**

Check magnetic valve or injection pump and if necessary change them

**other error properties**

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 31 / 523568 / BIPCyl8

#### Error description INJECT. PERIOD ZYL.8

Begin of injection of cylinder 8: the ECU can not identify the magnet valve or the injection pump with the measured value of current drain at the begin of the injection

#### Error codes

DEUTZ-Errorcode: 31

BlinkCode (short-long-short): 5 - 3 - 8

SPN: 523568

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective
- 2: data stream is defective

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Value outside target range or missing (cylinder 8), magnet valve or injection pump defective

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary change them

#### other error properties

System reaction: No function at the moment/ Allocation check cylinder!

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

### 32 / 102 / BPSCD

#### Error description CHARGE AIR PRESS.

Charge air pressure sensor: the measured voltage of sensor by ECU is out of the target range; the calculated charge air pressure is implausible or the received value via CAN is defective

#### Error codes

DEUTZ-Errorcode: 32

BlinkCode (short-long-short): 2 - 2 - 3

SPN: 102

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit; sensor defective, onnection cable damaged

#### Take actions for error repair

Check cabling, if LDF6T sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

### 33 / 102 / BPSCDSysReac

#### Error description CHARGE AIR PRESS.

Charge air pressure: the charge air pressure calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 33

BlinkCode (short-long-short): 2 - 2 - 3

SPN: 102

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows permanent light oder blinking. Entry in errormemory.

#### Possible reason for error

Outside target range with system reaction, air system damaged, sensor defective, onnection cable damaged

#### Take actions for error repair

Check air system, inspect air system and if necessary repair it, check sensor and if necessary replace it; check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: BPSCD\_stSysReacReq

Behaviour error lamp: permanent light oder blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 37 / 111 / CLSCDSysReac

#### Error description ENG COOLANT LEVEL

Coolant level: the coolant level calculated by ECU is underneath the allowed minimum

#### Error codes

DEUTZ-Errorcode: 37

BlinkCode (short-long-short): 2 - 3 - 5

SPN: 111

#### possible FMI:

- 1: data valid, but below normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light oder blinking. Entry in errormemory.

#### Possible reason for error

Outside target range with system reaction, cooling system unlight, sensor defective, onnection cable damaged

#### Take actions for error repair

Check coolant level, check cabling, inspect cooling system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: CLSCD\_stSysReacReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

### 38 / 1323 / CmbChbMisfire1

#### Error description MISFIRE CYL. 1

Misfire at cylinder 1: the number of the misfire detected by ECU is out of the allowed limit value

#### Error codes

DEUTZ-Errorcode: 38

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1323

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected (cylinder 1), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 39 / 1324 / CmbChbMisfire2

#### Error description MISFIRE CYL. 2

Misfire at cylinder 2: the number of the misfire detected by ECU is out of the allowed limit value

#### Error codes

DEUTZ-Errorcode: 39

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1324

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected (cylinder 2), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 40 / 1325 / CmbChbMisfire3

#### Error description MISFIRE CYL. 3

Misfire at cylinder 3: the number of the misfire detected by ECU is out of the allowed limit value

##### Error codes

DEUTZ-Errorcode: 40

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1325

##### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Misfire detected (cylinder 3), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

##### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

##### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 41 / 1326 / CmbChbMisfire4

#### Error description MISFIRE CYL. 4

Misfire at cylinder 4: the number of the misfire detected by ECU is out of the allowed limit value

##### Error codes

DEUTZ-Errorcode: 41

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1326

##### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Misfire detected (cylinder 4), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

##### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

##### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 42 / 1327 / CmbChbMisfire5

#### Error description MISFIRE CYL. 5

Misfire at cylinder 5: the number of the misfire detected by ECU is out of the allowed limit value

##### Error codes

DEUTZ-Errorcode: 42

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1327

##### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Misfire detected (cylinder 5), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

##### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

##### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 43 / 1328 / CmbChbMisfire6

#### Error description MISFIRE CYL. 6

Misfire at cylinder 6: the number of the misfire detected by ECU is out of the allowed limit value

#### Error codes

DEUTZ-Errorcode: 43

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1328

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected (cylinder 6), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 44 / 1450 / CmbChbMisfire7

#### Error description MISFIRE CYL. 7

Misfire at cylinder 7: the number of the misfire detected by ECU is out of the allowed limit value

#### Error codes

DEUTZ-Errorcode: 44

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1450

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected (cylinder 7), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 45 / 1451 / CmbChbMisfire8

#### Error description MISFIRE CYL. 8

Misfire at cylinder 8: the number of the misfire detected by ECU is out of the allowed limit value

#### Error codes

DEUTZ-Errorcode: 45

BlinkCode (short-long-short): 2 - 4 - 1

SPN: 1451

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected (cylinder 8), magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 46 / 1322 / CmbChbMisfireMul

#### Error description MULTIPL. CYL. MISFIRE

Misfire at more cylinders: the number of the misfire detected by ECU is out of the allowed limit value

#### Error codes

**DEUTZ-Errorcode:** 46

**BlinkCode** (short-long-short): 2 - 4 - 1

**SPN:** 1322

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected, magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 47 / 1346 / CmbChbSysReac

#### Error description MISFIRE SYST. REACT

Misfire at more cylinders: the number of the misfire detected by ECU is out of the allowed limit value; the ECU activates a system reaction

#### Error codes

**DEUTZ-Errorcode:** 47

**BlinkCode** (short-long-short): 2 - 4 - 1

**SPN:** 1346

#### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Misfire detected with system reaction, magnet valve or injection pump defective, fuel system defective, motor engineering damaged

#### Take actions for error repair

Check magnetic valve or injection pump and if necessary replace them, check fuel system and if necessary repair it, check motor engineering and if necessary repair it

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 0

Measurement @ errortime: actual value

### 48 / 1109 / CoEngShOffDemlgr

#### Error description SHUT OFF REQUEST

Request of engine off: the operator ignores the engine off request within an allowed period.

#### Error codes

**DEUTZ-Errorcode:** 48

**BlinkCode** (short-long-short): 3 - 4 - 1

**SPN:** 1109

#### possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Shut-off request ignored by operator

#### Take actions for error repair

Warranty relevant

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 52 / 1072 / CRERCD

#### Error description ENGINE BRAKE INT.

Engine brake actuator (internal): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the actuator is exceeded.

##### Error codes

DEUTZ-Errorcode: 52

BlinkCode (short-long-short): 5 - 2 - 8

SPN: 1072

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

##### Take actions for error repair

Check actuator and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, shutoff output, capacity reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 2

Measurement @ errortime: setpoint for output status

### 53 / 1081 / CSLpCD

#### Error description PREHEAT LAMP

Indicator lamp of air heater relay: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the lamp is exceeded

##### Error codes

DEUTZ-Errorcode: 53

BlinkCode (short-long-short): 3 - 2 - 8

SPN: 1081

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: data stream is defective

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

##### Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: setpoint for output status

### 54 / 704 / CTLpCD

#### Error description TEMP. LAMP

Warning lamp for coolant temperature: the current drain measured by ECU is out of the target range or the maximum temperature of the ECU component for power supply of the lamp is exceeded

##### Error codes

DEUTZ-Errorcode: 54

BlinkCode (short-long-short): 1 - 2 - 3

SPN: 704

##### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

##### Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: setpoint for output status



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300

### 55 / 110 / CTSCD

#### Error description ENG COOLANT TEMP.

Coolant temperature sensor: the voltage of the sensor measured by ECU is out of the target range; the coolant temperature calculated by ECU is implausible compared with the oil temperature or the received value via CAN is defective

##### Error codes

**DEUTZ-Errorcode:** 55

**BlinkCode** (short-long-short): 2 - 2 - 5

**SPN:** 110

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

##### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

### 56 / 110 / CTSCDSysReac

#### Error description ENG COOLANT TEMP.

Coolant temperature: the coolant temperature calculated by ECU is above the target range; the ECU activates a system reaction

##### Error codes

**DEUTZ-Errorcode:** 56

**BlinkCode** (short-long-short): 2 - 3 - 2

**SPN:** 110

##### possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light  
oder

blinking. Entry in errormemory.

##### Possible reason for error

Outside target range with system reaction, cooling system not enough to be filled, clogged or damaged, cooling compressor dropped out, sensor defective, onnection cable damaged

##### Take actions for error repair

Check cycle cooling system and compressor, inspect cooling system and if necessary repair it, check cooling compressor and if necessary replace it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Advice: CTSCD\_stSysReacReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 57 / 701 / Dummy1CD\_Max

#### Error description RESERVE 2

Reserve output 1: the ECU detects a short circuit to battery

##### Error codes

**DEUTZ-Errorcode:** 57

**BlinkCode** (short-long-short): 1 - 0 - 0

**SPN:** 701

##### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit to Ubatt (output 1), connection cable damaged

##### Take actions for error repair

Check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 58 / 701 / Dummy1CD\_Min

#### Error description RESERVE 2

Reserve output 1: the ECU detects a short circuit to ground

#### Error codes

DEUTZ-Errorcode: 58

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 701

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to ground (output 1), connection cable damaged

#### Take actions for error repair

Check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

### 59 / 701 / Dummy1CD\_SigNpl

#### Error description RESERVE 2

Reserve output 1: the ECU detects no load or excess temperature of the ECU component for power supply of the connected components

#### Error codes

DEUTZ-Errorcode: 59

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 701

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or ECU internal error (output 1), connection cable damaged, connected components defective, parametering of the output inaccurate, ECU defective

#### Take actions for error repair

Check connection cable and if necessary repair or replace it,

check parameters and if necessary correct it, replace ECU

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

### 60 / 702 / Dummy2CD\_Max

#### Error description THRUST MODE

Reserve output 2: the ECU detects a short circuit to battery

#### Error codes

DEUTZ-Errorcode: 60

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 702

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to Ubatt (output 2), connection cable damaged

#### Take actions for error repair

Check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 61 / 702 / Dummy2CD\_Min

#### Error description THRUST MODE

Reserve output 2: the ECU detects a short circuit to ground

#### Error codes

DEUTZ-Errorcode: 61

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 702

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to ground (output 2), connection cable damaged

#### Take actions for error repair

Check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

### 62 / 702 / Dummy2CD\_SigNpl

#### Error description THRUST MODE

Reserve output 2: the ECU detects no load or excess temperature of the ECU component for power supply of the connected components

#### Error codes

DEUTZ-Errorcode: 62

BlinkCode (short-long-short): 1 - 0 - 0

SPN: 702

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or ECU internal error (output 2), connection cable damaged, connected components defective, parametering of the output inaccurate, ECU defective

#### Take actions for error repair

Check connection cable and if necessary repair or replace it, check parameters and if necessary correct it, replace ECU

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

### 69 / 2791 / EGRCD\_Max

#### Error description EGR ACTUATOR

Actuator of the external EGR valve: the ECU detects a short circuit to battery

#### Error codes

DEUTZ-Errorcode: 69

BlinkCode (short-long-short): 4 - 1 - 4

SPN: 2791

#### possible FMI:

- 3. Voltage to high or short circuit to +Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to Ubatt, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 70 / 2791 / EGRCD\_Min

#### Error description EGR ACTUATOR

Actuator of the external EGR valve: the ECU detects a short circuit to ground

#### Error codes

DEUTZ-Errorcode: 70

BlinkCode (short-long-short): 4 - 1 - 4

SPN: 2791

#### possible FMI:

- 12. Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to ground, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

### 71 / 2791 / EGRCD\_SigNpl

#### Error description EGR ACTUATOR

Actuator of the external EGR valve: the ECU detects no load or excess temperature of the ECU component for power supply of the connected components

#### Error codes

DEUTZ-Errorcode: 71

BlinkCode (short-long-short): 4 - 1 - 5

SPN: 2791

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or excess temperature, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

### 72 / 2791 / EGRCDIntEGR

#### Error description EGR ACTUATOR

Actuator of the internal EGR valve: the ECU detects no load or excess temperature of the ECU component for power supply of the actuator

#### Error codes

DEUTZ-Errorcode: 72

BlinkCode (short-long-short): 4 - 1 - 6

SPN: 2791

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break, short circuit or excess temperature, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output, power reduction via second topcurve?

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: shut off value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 74 / 923 / EngCDTrqCalcOut

#### Error description ENGINE POWER OUT

Output with PWM signal of the engine power: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component to control the output is exceeded

#### Error codes

**DEUTZ-Errorcode:** 74

**BlinkCode** (short-long-short): 5 - 5 - 5

**SPN:** 923

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Engine Power output: cable break or short circuit, output defective, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

### 75 / 190 / EngMBackUp

#### Error description ENGINE SPEED

Crankshaft speed sensor: the ECU receives no signal and uses the signal from camshaft speed sensor as alternative to calculate the engine speed

#### Error codes

**DEUTZ-Errorcode:** 75

**BlinkCode** (short-long-short): 2 - 1 - 2

**SPN:** 190

#### possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Engine running only with cam-shaft speed signal, transmitter defective, connection cable damaged

#### Take actions for error repair

Check cabling of crankschaft sensor, check crankschaft sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, calculation of injektion initiation point will be incorrect

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: -

### 76 / 190 / EngMCaS1

#### Error description ENGINE SPEED

Camshaft speed sensor: the ECU receives no signal or the signal is defective

#### Error codes

**DEUTZ-Errorcode:** 76

**BlinkCode** (short-long-short): 2 - 1 - 2

**SPN:** 190

#### possible FMI:

- 12: Defective component
- 8: unusual frequency, pulse or period.
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Speed signal from cam-shaft defective or missing, transmitter defective, connection cable damaged, parametering of the sensor wheel inaccurate

#### Take actions for error repair

Check cabling, check camshaft sensor and if necessary replace it, check configuration of sensor wheel, check connection cable and if necessary repair or replace it, check parameters and if necessary correct them

#### other error properties

System reaction: Warning, difficult start

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: 0

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 77 / 190 / EngMCRs1

#### Error description ENGINE SPEED

Crankshaft speed sensor: the ECU receives no signal or the signal is defective

##### Error codes

DEUTZ-Errorcode: 77

BlinkCode (short-long-short): 2 - 1 - 2

SPN: 190

##### possible FMI:

- 12: Defective component
- 8: unusual frequency, pulse or period.
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Speed signal from crankshaft defectiveiv or missing, transmitter defective, connection cable damaged, sensor wheel installed inaccurately

##### Take actions for error repair

Check cabling, check camshaft sensor and if necessary replace it, check configuration of sensor wheel, check connection cable and if necessary repair or replace it, check the position of sensor wheel and if necessary correct it

##### other error properties

System reaction: Warning, power reduction via second topcurve  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: 0

### 78 / 190 / EngMOfsCaSCrS

#### Error description ENGINE SPEED

Speed sensor of crankschaft and camshaft: the received signals are out of phase

##### Error codes

DEUTZ-Errorcode: 78

BlinkCode (short-long-short): 2 - 1 - 3

SPN: 190

##### possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Speed signals of crank-shaft and cam-shaft are phase-shifted, sensor wheel installed in wrong position, sensor wrong wired

##### Take actions for error repair

Check position from crankschaft sensor wheel to camshaft sensor wheel, polarisation crankschaft or camshaft sensor, check position of sensor wheel and if necessary correct it, check cabling and if necessary correct it

##### other error properties

System reaction: Warning, not possible to start engine  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 4  
Measurement @ errortime: -

### 79 / 190 / EngPrtSysReacFOC

#### Error description ENGINE SPEED

Engine speed: the engine speed calculated by ECU is above the target range; the ECU activates a system reaction

##### Error codes

DEUTZ-Errorcode: 79

BlinkCode (short-long-short): 2 - 1 - 4

SPN: 190

##### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows blinking. Entry in errormemory.

##### Possible reason for error

Engine overspeed detected with system reaction, maximum engine speed exceeded

##### Take actions for error repair

##### other error properties

System reaction:  
Behaviour error lamp: blinking  
Selfhealing: no  
Signal Priority: 5  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 80 / 190 / EngPrtSysReacORC

#### Error description ENGINE SPEED

Engine speed: under overrun conditions, the engine speed calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 80

BlinkCode (short-long-short): 2 - 1 - 4

SPN: 190

#### possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Overrun conditions detected with system reaction, maximum engine speed exceeded

#### Take actions for error repair

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 81 / 703 / ESLpCD

#### Error description ENG. RUNNING LAMP

Indicator lamp for engine running: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the lamp is exceeded

#### Error codes

DEUTZ-Errorcode: 81

BlinkCode (short-long-short): 1 - 4 - 2

SPN: 703

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or internal ECU error, lamp defective, connection cable damaged

#### Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: shut off value

### 82 / 1074 / ExFICD

#### Error description BRAKE FLAP ACTUATOR

Engine brake flap actuator: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the actuator is exceeded

#### Error codes

DEUTZ-Errorcode: 82

BlinkCode (short-long-short): 2 - 1 - 9

SPN: 1074

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Engine brake flap actuator: cable break or short circuit, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 2

Measurement @ errortime: shut off value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 83 / 975 / FanCD

#### Error description FAN ACTUATOR

Fan power stage: the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the actuator is exceeded

#### Error codes

DEUTZ-Errorcode: 83

BlinkCode (short-long-short): 2 - 3 - 8

SPN: 975

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

cable break or short circuit, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, sensor defect, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 2  
Measurement @ errortime: Sollwert

### 85 / 1639 / FanCDEval

#### Error description

Fan speed sensor: the current drain measured by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 85

BlinkCode (short-long-short): 2 - 3 - 8

SPN: 1639

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Sensor defective, connection cable damaged, fan speed outside the target range

#### Take actions for error repair

Check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, check fan

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: actual value

### 86 / 523602 / FanCDSysReac

#### Error description FAN SPEED

Fan speed: the fan speed calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 86

BlinkCode (short-long-short): 2 - 3 - 8

SPN: 523602

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Above target range with system reaction

#### Take actions for error repair

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 87 / 97 / FIFCD

#### Error description WATER IN FUEL

Fuel filter water level sensor: the voltage of sensor measured by ECU is out of the target range

##### Error codes

DEUTZ-Errorcode: 87

BlinkCode (short-long-short): 2 - 2 - 8

SPN: 97

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

cable break or short circuit, sensor defective, connection cable damaged

##### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

### 89 / 97 / FIFCD\_WtLvl

#### Error description WATER IN FUEL

Water in fuel: the water level calculated by ECU is above the allowed limit value

##### Error codes

DEUTZ-Errorcode: 89

BlinkCode (short-long-short): 2 - 2 - 8

SPN: 97

##### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Above target range, excess of maximum permissible water level in fuel filter

##### Take actions for error repair

flush water separator

##### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 3  
Measurement @ errortime: actual value

### 90 / 94 / FIPSCD

#### Error description FUEL PRE PRESS.

Low fuel pressure sensor: the voltage of sensor measured by ECU is out of the target range

##### Error codes

DEUTZ-Errorcode: 90

BlinkCode (short-long-short): 2 - 1 - 6

SPN: 94

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

cable break or short circuit, sensor defective, connection cable damaged

##### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 91 / 94 / FIPSCDSysReac

#### Error description FUEL PRE PRESS.

Low fuel pressure: the low fuel pressure calculated by ECU is underneath the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 91

BlinkCode (short-long-short): 2 - 1 - 6

SPN: 94

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Below target range with system reaction, interruption in cycling process of low fuel pressure (for example, fuel pump defective), sensor defective, connection cable damaged

#### Take actions for error repair

Check low fuel pressure loop system, Check fuel pump, inspect fuel system and if necessary repair it; check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: FLPSCD\_stSysReacReq

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

### 94 / 523239 / FrmMngDecV1

#### Error description CAN ERROR DEC-V1

CAN message DecV1 (Pseudo Pedal): the message can not be received by ECU or the received value is above the target range

#### Error codes

DEUTZ-Errorcode: 94

BlinkCode (short-long-short): 5 - 2 - 6

SPN: 523239

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Defective component
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing or value above target range (message "DecV1" = pseudo pedal), CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to customers configuration.

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: default value

### 95 / 523240 / FrmMngFunModCtl

#### Error description CAN ERROR FUNMODCTL

CAN message FunModCtl (Function Mode Control): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 95

BlinkCode (short-long-short): 5 - 2 - 7

SPN: 523240

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "FunModCtl" = function mode control, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to customers configuration.

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 106 / 523212 / FrmMngTOEngPrt

#### Error description CAN ERROR ENGPRt

CAN message EngPrt (Engine Protection): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 106

BlinkCode (short-long-short): 3 - 3 - 3

SPN: 523212

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "EngPrt" = engine protection, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning. Hold last value.  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

### 110 / 523216 / FrmMngTOPrHtEnCmd

#### Error description CAN ERROR PRHTENCMD

CAN message PrHtEnCmd (Preheat and Engine Command): the message received can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 110

BlinkCode (short-long-short): 3 - 3 - 7

SPN: 523216

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "PrHtEnCmd" = preheat and engine command; CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to customers configuration.  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

### 112 / 523218 / FrmMngTORxCCVS

#### Error description CAN ERROR RXCCVS

CAN message RxCCVS (Cruise Control): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 112

BlinkCode (short-long-short): 1 - 1 - 1

SPN: 523218

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "RxCCVS" = cruise control; CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 113 / 523604 / FrmMngTORxEngTemp

#### Error description CAN ERROR RxEngTemp

CAN message RxEngTemp (Engine Temperature): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 113

BlinkCode (short-long-short): 1 - 1 - 2

SPN: 523604

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "RxEngTemp" = engine temperature, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

### 117 / 523238 / FrmMngTOSwtOut

#### Error description CAN ERROR SWTOUT

CAN message SwtOut (Switching Output): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 117

BlinkCode (short-long-short): 1 - 1 - 5

SPN: 523238

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "SwtOut" = switch outputs, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

### 118 / 523222 / FrmMngTOTCO1

#### Error description CAN ERROR TCO1

CAN message "TCO1" (Speedo Signal): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 118

BlinkCode (short-long-short): 1 - 1 - 6

SPN: 523222

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TCO1" = speedo signal, CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 1  
Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 120 / 523605 / FrmMngTOTSC1AE

#### Error description CAN ERROR TSC1-AE

CAN message TSC1-AE (Torque/Speed Control #1 from Automatic Traction Control to Engine): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 120

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523605

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-AE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

### 121 / 523606 / FrmMngTOTSC1AR

#### Error description CAN ERROR TSC1-AR

CAN message TSC1-AR (Torque/Speed Control #1 from Automatic Traction Control to Retarder): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 121

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 523606

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-AR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

### 122 / 523607 / FrmMngTOTSC1DE

#### Error description CAN ERROR TSC1-DE

CAN message TSC1-DE (Torque/Speed Control #1 from Driveline to Engine): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 122

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523607

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-DE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 123 / 523608 / FrmMngTOTSC1DR

#### Error description CAN ERROR TSC1-DR

CAN message TSC1-DR (Torque/Speed Control #1 from Driveline to Retarder): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 123

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 523608

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-DR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

### 124 / 523609 / FrmMngTOTSC1PE

#### Error description CAN ERROR TSC1-PE

CAN message TSC1-PE (Torque/Speed Control #1 from Power Take Off to Engine): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 124

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523609

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-PE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

### 125 / 898 / FrmMngTOTSC1TE

#### Error description CAN ERROR TSC1-TE

CAN message TSC1-TE (Torque/Speed Control #1 from Traction Control to Engine): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 125

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 898

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-TE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 126 / 520 / FrmMngTOTSC1TR

#### Error description CAN ERROR TSC1-TR

CAN message TSC1-TR (Torque/Speed Control #1 from Traction Control to Retarder): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 126

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 520

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-TR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

### 127 / 523610 / FrmMngTOTSC1VE

#### Error description CAN ERROR TSC1-VE

CAN message TSC1-VE (Torque/Speed Control #1 from Vehicle Control to Engine): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 127

BlinkCode (short-long-short): 1 - 1 - 8

SPN: 523610

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-VE", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value

### 128 / 523611 / FrmMngTOTSC1VR

#### Error description CAN ERROR TSC1-VR

CAN message TSC1-VR (Torque/Speed Control #1 from Vehicle Control to Retarder): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 128

BlinkCode (short-long-short): 1 - 1 - 9

SPN: 523611

#### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Missing message "TSC1-VR", CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, changing to substitute values according to priority chain.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 1

Measurement @ errortime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 131 / 523500 / FrmMngTxTO

#### Error description CAN MESS. TIMEOUT

CAN message: the ECU detects a timeout for one or more posted message

#### Error codes

DEUTZ-Errorcode: 131

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 523500

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12: Defective component
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Timeout for sent messages

#### Take actions for error repair

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: -

### 133 / 174 / FTSCD

#### Error description FUEL TEMP. SENSOR

Fuel temperature sensor: the voltage measured by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 133

BlinkCode (short-long-short): 2 - 2 - 7

SPN: 174

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Fuel temp. sensor: cable break or short circuit, sendor defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

### 134 / 174 / FTSCDSysReac

#### Error description FUEL TEMP. SENSOR

Fuel temperature: the fuel temperature calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 134

BlinkCode (short-long-short): 2 - 3 - 7

SPN: 174

#### possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

#### Possible reason for error

Above target range with system reaction, interruption of fuel loop (for example, rail pressure relief valve defective), sensor defective, connection cable damaged

#### Take actions for error repair

Check fuel system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: FTSCD\_stSysReacReq

Behaviour error lamp: permanent light  
oder  
blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 136 / 523618 / GOTSCD

#### Error description CUSTOMER TEMPSSENS 1

Customer specific temperature sensor 1: the voltage of sensor measured by ECU is out of the target range or the received value of temperature via CAN is defective

##### Error codes

**DEUTZ-Errorcode:** 136

**BlinkCode** (short-long-short): 1 - 3 - 3

**SPN:** 523618

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit (sensor 1), sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

##### Take actions for error repair

Customer specific bugfixing, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus scheduling, polarity, short circuit, power interrupt), test protocol of receiver, check CAN fun

##### other error properties

System reaction: Warning, substitute value (customer specific)

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: default value

### 137 / 523619 / GOTSCDSysReac

#### Error description

Customer specific temperature 1: the temperature calculated by ECU is above the target range; the ECU activates a system reaction

##### Error codes

**DEUTZ-Errorcode:** 137

**BlinkCode** (short-long-short): 1 - 3 - 3

**SPN:** 523619

##### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

##### Possible reason for error

Outside target range with system reaction (temperature 1), dependant on the application

##### Take actions for error repair

Customer specific bugfixing, dependant on application

##### other error properties

System reaction: Advice: GOTSCD\_stSysReacReq

Behaviour error lamp: permanent light  
oder  
blinking

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

### 138 / 29 / HdThrt

#### Error description THROTTLE 2

Hand throttle pedal sensor: the voltage measured by ECU is out of the target range or the calculated pedal position is implausible compared with the position of accelerator pedal 1

##### Error codes

**DEUTZ-Errorcode:** 138

**BlinkCode** (short-long-short): 1 - 2 - 6

**SPN:** 29

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, signal implausible compared to signal of idle sensor, transmitter defective, connection cable damaged

##### Take actions for error repair

Check cabling, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, changing to substitute values according to priority chain or limp home

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300

### 139 / 1638 / HOTSCD

#### Error description CUSTOMER TEMPSSENS 2

Customer specific temperature sensor 2: the voltage of sensor measured by ECU is out of the target range or the received value of temperature via CAN is defective

##### Error codes

DEUTZ-Errorcode: 139

BlinkCode (short-long-short): 3 - 1 - 4

SPN: 1638

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Defective component
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit (sensor 2), sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

##### Take actions for error repair

Customer specific bugfixing, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN fun

##### other error properties

System reaction: Warning, substitute value (customer specific)  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: default value

### 140 / 1638 / HOTSCDSysReac

#### Error description CUSTOMER TEMPSSENS 2

Customer specific temperature 2: the temperature calculated by ECU is above the target range; the ECU activates a system reaction

##### Error codes

DEUTZ-Errorcode: 140

BlinkCode (short-long-short): 3 - 1 - 4

SPN: 1638

##### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

##### Possible reason for error

Outside target range with system reaction (temperature 2), dependant on the application

##### Take actions for error repair

Customer specific bugfixing, dependant on application  
**other error properties**

System reaction: Advice: HOTSCD\_stSysReacReq  
Behaviour error lamp: permanent light  
oder  
blinking  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 141 / 523617 / HWEMonCom

#### Error description INTERNAL COMM. ERROR

Internal hardware monitoring: the ECU detects a communication disturbance

##### Error codes

DEUTZ-Errorcode: 141

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523617

##### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Communication with chip CJ 940 disturbed, ECU defective

##### Take actions for error repair

If cannot delete the error, change ECU

##### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 4  
Measurement @ errortime: -

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 142 / 630 / HWEMonEEPROM

#### Error description EEPROM MEM. ACCESS

Internal hardware monitoring: the ECU finds an error during the access to ist EEPROM memory or works with an alternative value

##### Error codes

DEUTZ-Errorcode: 142

BlinkCode (short-long-short): 2 - 8 - 1

SPN: 630

##### possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 12: Defective component
- 12: Defective component

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Error during EEPROM memory access or EEPROM works with substitute value, programming error. ECU defective

##### Take actions for error repair

If not programmed, EEPROM is defect → ECU is defect, reprogram ECU and if necessary replace it

##### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 4  
Measurement @ errortime: -

### 143 / 523612 / HWEMonRcyLocked

#### Error description INT. RECOVERY

Internal hardware monitoring: the CPU of the ECU is reset and the cause is logged internally; no item will be created in error memory

##### Error codes

DEUTZ-Errorcode: 143

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

##### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 14: Special Instructions

##### Errorredetection

Errorlamp shows blinking. Entry in errormemory.

##### Possible reason for error

A recovery occurred which is stored as protected

##### Take actions for error repair

Recovery occurred which is stored as protected  
With parameter HWEMon\_numRexxxxxx the recovery nummer and the subsequent position can be identified. See especially SW-Doku\_roy\_auto.pdf

##### other error properties

System reaction: Recovery of ECU  
Behaviour error lamp: blinking  
Selfhealing: no  
Signal Priority: 5  
Measurement @ errortime: -

### 144 / 523612 / HWEMonRcySuppressed

#### Error description INT. RECOVERY

Internal hardware monitoring: the CPU of the ECU is reset and the cause is logged internally; no item will be created in error memory

##### Error codes

DEUTZ-Errorcode: 144

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523612

##### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 14: Special Instructions

##### Errorredetection

Errorlamp shows blinking. Entry in errormemory.

##### Possible reason for error

A recovery occurred which is not stored

##### Take actions for error repair

Recovery occurred which is stored as protected  
With parameter HWEMon\_numRexxxxxx the recovery nummer and the subsequent position can be identified. See especially SW-Doku\_roy\_auto.pdf

##### other error properties

System reaction: Warning, shown at error path  
Behaviour error lamp: blinking  
Selfhealing: no  
Signal Priority: 5  
Measurement @ errortime: -

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 145 / 523612 / HWEMonRcyVisible

#### Error description INT. RECOVERY

Internal hardware monitoring: the CPU of the ECU is reset and an item will be created in error memory

#### Error codes

**DEUTZ-Errorcode:** 145  
**BlinkCode** (short-long-short): 5 - 5 - 5  
**SPN:** 523612  
**possible FMI:**  
12. Errormode not identifiable  
12. Errormode not identifiable  
12. Errormode not identifiable  
14: Special Instructions

#### Errordetection

Errorlamp shows blinking. Entry in errormemory.

#### Possible reason for error

A recovery occurred which is visible in the error memory

#### Take actions for error repair

Recovery occurred which is stored as protected  
With parameter HWEMon\_numRexxxxxx the recovery nummer and the subsequent position can be identified. See especially SW-Doku\_rcy\_auto.pdf

#### other error properties

System reaction: Recovery of ECU  
Behaviour error lamp: blinking  
Selfhealing: no  
Signal Priority: 5  
Measurement @ errorime: -

### 146 / 523612 / HWEMonUMaxSupply

#### Error description INT. RECOVERY

Internal hardware monitoring: the ECU detects an excess of the target range for the power supply of 1st communication module

#### Error codes

**DEUTZ-Errorcode:** 146  
**BlinkCode** (short-long-short): 5 - 5 - 5  
**SPN:** 523612  
**possible FMI:**  
3: Voltage to high or short circuit to +Ubatt  
12. Errormode not identifiable  
12. Errormode not identifiable  
12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Overvoltage at CJ940, power supply voltage too high, ECU defective

#### Take actions for error repair

Check working voltage and if necessary correct it, Check ECU and if necessary replace it

#### other error properties

System reaction: Power stage shut off  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 4  
Measurement @ errorime: -

### 147 / 523612 / HWEMonUMinSupply

#### Error description INT. RECOVERY

Internal hardware monitoring: the ECU detects an undershooting of the target range for the power supply of 1st communication module

#### Error codes

**DEUTZ-Errorcode:** 147  
**BlinkCode** (short-long-short): 5 - 5 - 5  
**SPN:** 523612  
**possible FMI:**  
12. Errormode not identifiable  
4: Voltage to low or short circuit to -Ubatt  
12. Errormode not identifiable  
12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Undervoltage at CJ940, power supply voltage too low, ECU defective

#### Take actions for error repair

Check working voltage and if necessary correct it, Check ECU and if necessary replace it

#### other error properties

System reaction: Power stage shut off  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 4  
Measurement @ errorime: -

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300

### 149 / 105 / IATSCD

#### Error description CHARGE AIR TEMP.

Charge air temperature sensor: the voltage of sensor measured by ECU is out of the target range or the received value of temperature via CAN is defective

##### Error codes

**DEUTZ-Errorcode:** 149

**BlinkCode** (short-long-short): 1 - 2 - 8

**SPN:** 105

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

##### Take actions for error repair

Check cabling, LDF6T-sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, c

##### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: default value

### 150 / 105 / IATSCDSysReac

#### Error description CHARGE AIR TEMP.

Charge air temperature: die charge air temperature calculated by ECU is above the target range; the ECU activates a system reaction

##### Error codes

**DEUTZ-Errorcode:** 150

**BlinkCode** (short-long-short): 2 - 3 - 3

**SPN:** 105

##### possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

##### Possible reason for error

Above target range with system reaction, air system damaged, sensor defective, connection cable damaged

##### Take actions for error repair

Check construction of LDF6T , check suction parts, check air system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Advice: IATSCD\_stSysReacReq  
Behaviour error lamp: permanent light  
oder  
blinking  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 153 / 523350 / InjVlvBnk1A

#### Error description INJECTOR BANK A

Injector cylinder bank 1: the current drain measured by ECU is above the target range

##### Error codes

**DEUTZ-Errorcode:** 153

**BlinkCode** (short-long-short): 1 - 5 - 1

**SPN:** 523350

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 13: out of calibrated range
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder bank 1), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, cylinder shut off  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 154 / 523351 / InjVlvBnk1B

#### Error description INJECTOR BANK A

Injector cylinder bank 1: the current drain measured by ECU is underneath the target range

##### Error codes

DEUTZ-Errorcode: 154

BlinkCode (short-long-short): 1 - 5 - 1

SPN: 523351

##### possible FMI:

13: out of calibrated range

13: out of calibrated range

5: current to low or broken wire

13: out of calibrated range

##### Error detection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break (cylinder bank 1), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, cylinder shut off

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 155 / 523352 / InjVlvBnk2A

#### Error description INJECTOR BANK B

Injector cylinder bank 2: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 155

BlinkCode (short-long-short): 1 - 5 - 2

SPN: 523352

##### possible FMI:

3: Voltage to high or short circuit to +Ubatt

4: Voltage to low or short circuit to -Ubatt

13: out of calibrated range

12: Errormode not identifiable

##### Error detection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder bank 2), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, cylinder shut off

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 156 / 523353 / InjVlvBnk2B

#### Error description INJECTOR BANK B

Injector cylinder bank 2: the current drain measured by ECU is underneath the target range

##### Error codes

DEUTZ-Errorcode: 156

BlinkCode (short-long-short): 1 - 5 - 2

SPN: 523353

##### possible FMI:

13: out of calibrated range

13: out of calibrated range

5: current to low or broken wire

13: out of calibrated range

##### Error detection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break (cylinder bank 2), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, cylinder shut off

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 157 / 523354 / InjVlvChipA

#### Error description PWR. INJ. BANK B

Internal hardware monitoring: the ECU detects an error of ist injector high current output

##### Error codes

DEUTZ-Errorcode: 157

BlinkCode (short-long-short): 1 - 5 - 3

SPN: 523354

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 2: data stream is defective
- 14: Special Instructions
- 12: Defective component

##### Errordetection

Errorlamp shows blinking. Entry in errormemory.

##### Possible reason for error

High power stage Injector A, ECU defective

##### Take actions for error repair

If error is not removable, change ECU

##### other error properties

System reaction: Warning, outputs shut off

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: actual value

### 158 / 523355 / InjVlvChipB

#### Error description PWR. INJ. BANK B

Internal hardware monitoring: the ECU detects a disturbance in its injector high current output

##### Error codes

DEUTZ-Errorcode: 158

BlinkCode (short-long-short): 1 - 5 - 3

SPN: 523355

##### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Defective component
- 12: Defective component

##### Errordetection

Errorlamp shows blinking. Entry in errormemory.

##### Possible reason for error

High power stage Injector B, ECU defective

##### Take actions for error repair

If error is not removable, change ECU

##### other error properties

System reaction: Warning, outputs shut off

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: actual value

### 159 / 651 / InjVlvCyl1A

#### Error description INJECTOR 1

Injector 1: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 159

BlinkCode (short-long-short): 1 - 5 - 4

SPN: 651

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errorcode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder 1), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 160 / 651 / InjVlvCyl1B

#### Error description INJECTOR 1

Injector 1: the current drain measured by ECU is underneath the target range

##### Error codes

DEUTZ-Errorcode: 160

BlinkCode (short-long-short): 1 - 5 - 4

SPN: 651

##### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break (cylinder 1), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 161 / 652 / InjVlvCyl2A

#### Error description INJECTOR 2

Injector 2: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 161

BlinkCode (short-long-short): 1 - 5 - 5

SPN: 652

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder 2), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 162 / 652 / InjVlvCyl2B

#### Error description INJECTOR 2

Injector 2: the current drain measured by ECU is underneath the target range

##### Error codes

DEUTZ-Errorcode: 162

BlinkCode (short-long-short): 1 - 5 - 5

SPN: 652

##### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break (cylinder 2), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 163 / 653 / InjVlvCyl3A

#### Error description INJECTOR 3

Injector 3: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 163

BlinkCode (short-long-short): 1 - 5 - 6

SPN: 653

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder 3), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 164 / 653 / InjVlvCyl3B

#### Error description INJECTOR 3

Injector 3: the current drain measured by ECU is underneath the target range

##### Error codes

DEUTZ-Errorcode: 164

BlinkCode (short-long-short): 1 - 5 - 6

SPN: 653

##### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break (cylinder 3), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 165 / 654 / InjVlvCyl4A

#### Error description INJECTOR 4

Injector 4: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 165

BlinkCode (short-long-short): 1 - 6 - 1

SPN: 654

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder 4), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 166 / 654 / InjVlvCyl4B

#### Error description INJECTOR 4

Injector 4: the current drain measured by ECU is underneath the target range

#### Error codes

DEUTZ-Errorcode: 166

BlinkCode (short-long-short): 1 - 6 - 1

SPN: 654

#### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break (cylinder 4), injector defective, connection cable damaged

#### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 167 / 655 / InjVlvCyl5A

#### Error description INJECTOR 5

Injector 5: the current drain measured by ECU is above the target range

#### Error codes

DEUTZ-Errorcode: 167

BlinkCode (short-long-short): 1 - 6 - 2

SPN: 655

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit (cylinder 5), injector defective, connection cable damaged

#### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 168 / 655 / InjVlvCyl5B

#### Error description INJECTOR 5

Injector 5: the current drain measured by ECU is underneath the target range

#### Error codes

DEUTZ-Errorcode: 168

BlinkCode (short-long-short): 1 - 6 - 2

SPN: 655

#### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break (cylinder 5), injector defective, connection cable damaged

#### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 169 / 656 / InjVlvCyl6A

#### Error description INJECTOR 6

Injector 6: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 169

BlinkCode (short-long-short): 1 - 6 - 3

SPN: 656

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder 6), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 170 / 656 / InjVlvCyl6B

#### Error description INJECTOR 6

Injector 6: the current drain measured by ECU is underneath the target range

##### Error codes

DEUTZ-Errorcode: 170

BlinkCode (short-long-short): 1 - 6 - 3

SPN: 656

##### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break (cylinder 6), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 171 / 657 / InjVlvCyl7A

#### Error description INJECTOR 7

Injector 7: the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 171

BlinkCode (short-long-short): 1 - 6 - 4

SPN: 657

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit (cylinder 7), injector defective, connection cable damaged

##### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 172 / 657 / InjVlvCyl7B

#### Error description INJECTOR 7

Injector 7: the current drain measured by ECU is underneath the target range

#### Error codes

DEUTZ-Errorcode: 172

BlinkCode (short-long-short): 1 - 6 - 4

SPN: 657

#### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break (cylinder 7), injector defective, connection cable damaged

#### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 173 / 658 / InjVlvCyl8A

#### Error description INJECTOR 8

Injector 8: the current drain measured by ECU is above the target range

#### Error codes

DEUTZ-Errorcode: 173

BlinkCode (short-long-short): 1 - 6 - 5

SPN: 658

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 13: out of calibrated range
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit (cylinder 8), injector defective, connection cable damaged

#### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 174 / 658 / InjVlvCyl8B

#### Error description INJECTOR 8

Injector 8: the current drain measured by ECU is underneath the target range

#### Error codes

DEUTZ-Errorcode: 174

BlinkCode (short-long-short): 1 - 6 - 5

SPN: 658

#### possible FMI:

- 13: out of calibrated range
- 13: out of calibrated range
- 5: current to low or broken wire
- 13: out of calibrated range

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break (cylinder 8), injector defective, connection cable damaged

#### Take actions for error repair

Check cabling, check injectors and if necessary replace them, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, fuel injection failed, shut off wenn the number of active cylinders below minimum  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 175 / 523370 / InjVlvErrDet

#### Error description RAIL PRESS. MON. DISABLED

Rail pressure monitoring: the monitoring of the rail pressure will be deactivated by ECU because of the activation of the function "compression test" by user

#### Error codes

DEUTZ-Errorcode: 175

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523370

#### possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows . Entry in errormemory.

#### Possible reason for error

Compression test active: rail-pressure monitoring is going to be disabled

#### Take actions for error repair

not correct

#### other error properties

System reaction: Rail pressure monitoring disabled

Behaviour error lamp:

Selfhealing: -

Signal Priority: 1

Measurement @ errortime:

### 176 / 523615 / MeUnCD\_ADC

#### Error description METERING UNIT

Fuel volume flow rate: the fuel volume rate calculated by ECU at outlet of the fuel metering unit is out of the target range

#### Error codes

DEUTZ-Errorcode: 176

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Flow rate outside target range

#### Take actions for error repair

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 177 / 523615 / MeUnCDNoLoad

#### Error description METERING UNIT

Valve at outlet of the fuel metering unit: the ECU detects no load or temperature excess of the ECU component for power supply of the valve

#### Error codes

DEUTZ-Errorcode: 177

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 5: current to low or broken wire
- 12: Defective component

#### Errorredetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

#### Possible reason for error

wiring error or ECU output is switched off because of overtemperature, fuel metering unit defective, connection cable damaged

#### Take actions for error repair

Check cabling , if necessary check FCU, check fuel metering unit and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, max.extraction of FCU --> open rail pressure relief valve --> shut the engine off in about 5 minutes  
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 178 / 523615 / MeUnCDSCBat

#### Error description METERING UNIT

Valve at outlet of the fuel metering unit: the current drain measured by ECU is above the target range

#### Error codes

DEUTZ-Errorcode: 178

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

#### Possible reason for error

Short circuit to Ubatt, fuel metering unit defective, connection cable damaged

#### Take actions for error repair

Check cabling , if necessary check FCU, check fuel metering unit and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, rail pressure relief valve will open  
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 179 / 523615 / MeUnCDSCGnd

#### Error description METERING UNIT

Valve at outlet of the fuel metering unit: the current drain measured by ECU is above the target range

#### Error codes

DEUTZ-Errorcode: 179

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 523615

#### possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

#### Possible reason for error

Short circuit to ground, fuel metering unit defective, connection cable damaged

#### Take actions for error repair

Check cabling , if necessary check FCU, check fuel metering unit and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, rail pressure relief valve will open  
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 182 / 2634 / MnRly1\_SCB

#### Error description MAIN RELAY

Main relay 1: the current drains measured by ECU is above the target range

#### Error codes

DEUTZ-Errorcode: 182

BlinkCode (short-long-short): 1 - 3 - 7

SPN: 2634

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to Ubatt (relay 1), relay defective, connection cable damaged

#### Take actions for error repair

Check cabling, check ECU, check relay and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff the outputs MPROP

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300

### 183 / 2634 / MnRly1\_SCG

#### Error description MAIN RELAY

Main relay 1: the current drains measured by ECU is above the target range

#### Error codes

DEUTZ-Errorcode: 183

BlinkCode (short-long-short): 1 - 3 - 8

SPN: 2634

#### possible FMI:

- 12. Errormode not identifiable
- 4: Voltage to low or short circuit to -Ubatt
- 12. Errormode not identifiable
- 12. Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Short circuit to ground (relay 1), relay defective, connection cable damaged

#### Take actions for error repair

Check cabling, check ECU, check relay and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff the outputs MPROP

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

### 184 / 523420 / Montr

#### Error description WATCHDOG COUNTER

Internal hardware monitoring: the ECU detects an disturbance in ist monitoring module (Watchdog)

#### Error codes

DEUTZ-Errorcode: 184

BlinkCode (short-long-short): 1 - 3 - 9

SPN: 523420

#### possible FMI:

- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 12. Errormode not identifiable
- 14: Special Instructions

#### Errordetection

Errorlamp shows blinking. Entry in errormemory.

#### Possible reason for error

Watchdog counter exceeds maximum, ECU defective

#### Take actions for error repair

If error is not removable, change ECU

#### other error properties

System reaction: Recovery of ECU

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: -

### 186 / 2634 / MRlyCD

#### Error description MAIN RELAY

Main relay: during the switching off, main relay does not switch on within an allowed time

#### Error codes

DEUTZ-Errorcode: 186

BlinkCode (short-long-short): 2 - 6 - 1

SPN: 2634

#### possible FMI:

- 7: Mechanical system not OK
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

EDC16: main relay not open in allowed time or main relay open too early; EDC7: main relay not open in allowed time or short circuit of main relay to ground; EDC16: main relay defective, connection cable damaged; generally: rapid shut-off of the ECU (witho

#### Take actions for error repair

EDC16: check external main relay, check cabling

EDC7: if error is not removable, change ECU, EDC16: Check main relay and if necessary replace it, check connection cable and if necessary repair or replace it; both: if error is not removable, change ECU

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 187 / 563 / MRlyCDMnRly2

#### Error description MAIN RELAY 2

Main relay 2 (in ECU): during the switching off, main relay does not switch on within an allowed time

##### Error codes

DEUTZ-Errorcode: 187

BlinkCode (short-long-short): 2 - 6 - 1

SPN: 563

##### possible FMI:

- 7: Mechanical system not OK
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

rapid shut-off of the ECU (without waiting till the end of the afterrun), ECU defective

##### Take actions for error repair

If error not removable, change ECU

##### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

### 188 / 2634 / MRlyCDMnRly3

#### Error description MAIN RELAY

Main relay 3 (in ECU): during the switching off, main relay does not switch on within an allowed time

##### Error codes

DEUTZ-Errorcode: 188

BlinkCode (short-long-short): 2 - 6 - 1

SPN: 2634

##### possible FMI:

- 7: Mechanical system not OK
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Short circuit to ground or emergency shut-off (relay 3 internal), rapid shut-off of the ECU (without waiting till the end of the afterrun), ECU defective

##### Take actions for error repair

Check cabling, check ECU, if error not removable, change ECU

##### other error properties

System reaction: Warning, shutoff the outputs MPROP (see

BOSCH-Electricity operating plan)

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

### 189 / 523450 / MSSCD1

#### Error description MULTISTATE SWITCH 1

Multi state switch 1: the voltage measured by ECU is out of the target range or the switch setting is not plausible

##### Error codes

DEUTZ-Errorcode: 189

BlinkCode (short-long-short): 1 - 4 - 3

SPN: 523450

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, input voltage outside target range (switch 1), switch defective, connection cable damaged

##### Take actions for error repair

Check cabling and sensor, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: default value

### 190 / 523451 / MSSCD2

#### Error description MULTISTATE SWITCH 2

Multi state switch 2: the voltage measured by ECU is out of the target range or the switch setting is not plausible

#### Error codes

DEUTZ-Errorcode: 190

BlinkCode (short-long-short): 1 - 4 - 3

SPN: 523451

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, input voltage outside target range (switch 2), switch defective, connection cable damaged

#### Take actions for error repair

Check cabling and sensor, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: default value

### 191 / 523452 / MSSCD3

#### Error description MULTISTATE SWITCH 3

Multi state switch 3: the voltage measured by ECU is out of the target range or the switch setting is not plausible

#### Error codes

DEUTZ-Errorcode: 191

BlinkCode (short-long-short): 1 - 4 - 3

SPN: 523452

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, input voltage outside target range (switch 3), switch defective, connection cable damaged

#### Take actions for error repair

Check cabling and sensor, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: default value

### 192 / 639 / NetMngCANAOFF

#### Error description CAN A BUS OFF

CAN bus A: the ECU is not allowed to send messages, because the status "BusOff" is detected

#### Error codes

DEUTZ-Errorcode: 192

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 639

#### possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, off-state (CAN bus A), CAN bus deactivated, connection cable damaged

#### Take actions for error repair

Check cabling of CAN bus and if necessary repair it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime:

### 193 / 1231 / NetMngCANBOff

#### Error description CAN B BUS OFF

CAN bus B: the ECU is not allowed to send messages, because the status "BusOff" is detected

#### Error codes

DEUTZ-Errorcode: 193

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 1231

#### possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, off-state (CAN bus B), CAN bus deactivated, connection cable damaged

#### Take actions for error repair

Check cabling of CAN bus and if necessary repair it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime:

### 194 / 1235 / NetMngCANCOff

#### Error description CAN C BUS OFF

CAN bus C: the ECU is not allowed to send messages, because the status "BusOff" is detected

#### Error codes

DEUTZ-Errorcode: 194

BlinkCode (short-long-short): 2 - 7 - 1

SPN: 1235

#### possible FMI:

- 14: Special Instructions
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, off-state (CAN bus C), CAN bus deactivated, connection cable damaged

#### Take actions for error repair

Check cabling of CAN bus and if necessary repair it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction:  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime:

### 195 / 705 / OPLpCD

#### Error description OIL PRESS LAMP

Warning lamp for oil level: the current drain measured by ECU is out of the target range or the maximum temperature of the ECU component for power supply of the lamp is exceeded

#### Error codes

DEUTZ-Errorcode: 195

BlinkCode (short-long-short): 1 - 3 - 5

SPN: 705

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

#### Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 1  
Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 196 / 100 / OPSCD

#### Error description ENG OIL PRESS.

Oil pressure sensor: the voltage of sensor measured by ECU is out of the target range or the received value of oil pressure via CAN is implausible (Oil pressure is above the target range with higher oil temperature at the same time)

#### Error codes

**DEUTZ-Errorcode:** 196

**BlinkCode** (short-long-short): 2 - 2 - 4

**SPN:** 100

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 0: data valid, but above normal working area

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, chec

#### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: default value

### 197 / 100 / OPSCD1

#### Error description ENG OIL PRESS.

Oil pressure: the oil pressure calculated by ECU is implausibly low

#### Error codes

**DEUTZ-Errorcode:** 197

**BlinkCode** (short-long-short): 2 - 3 - 1

**SPN:** 100

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 1: data valid, but below normal working area

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Oil pressure implausible low, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: actual value

### 198 / 100 / OPSCDSysReacHi

#### Error description ENG OIL PRESS.

Oil pressure: the oil pressure calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

**DEUTZ-Errorcode:** 198

**BlinkCode** (short-long-short): 2 - 3 - 1

**SPN:** 100

#### possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

#### Possible reason for error

Above target range, oil volume too large, sensor defective, oil pump defective, connection cable damaged

#### Take actions for error repair

Check oil level and if necessary correct it, check oil pump and if necessary replace it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: OPSCD\_stSysReacReqHi  
Behaviour error lamp: permanent light  
oder  
blinking  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 199 / 100 / OPSCDSysReacLo

#### Error description ENG OIL PRESS.

Oil pressure: the oil pressure calculated by ECU is underneath the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 199

BlinkCode (short-long-short): 2 - 3 - 1

SPN: 100

#### possible FMI:

- 1: data valid, but below normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

#### Possible reason for error

Below target range, oil volume too small, sensor defective, oil pump defective, connection cable damaged

#### Take actions for error repair

Check oil level and if necessary correct it, check oil pump and if necessary replace it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: OPSCD\_stSysReacReqLo  
Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errorime: actual value

### 200 / 1237 / OSwCD

#### Error description OVERRIDE SWITCH

Bridgeover switch: the ECU receives a permanent signal

#### Error codes

DEUTZ-Errorcode: 200

BlinkCode (short-long-short): 1 - 4 - 5

SPN: 1237

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Switch is blocked, taster locked, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errorime: actual value

### 201 / 175 / OTSCD

#### Error description OIL TEMP. SENSOR

Oil temperature sensor: the voltage of sensor measured by ECU is out of the target range; the oil temperature calculated by ECU is implausible compared with coolant temperature or the received value via CAN is defective

#### Error codes

DEUTZ-Errorcode: 201

BlinkCode (short-long-short): 1 - 4 - 4

SPN: 175

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check switch and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errorime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 203 / 175 / OTSCDSysRead

#### Error description OIL TEMP. SENSOR

Oil temperature: the oil temperature calculated by ECU is above the target range; the ECU activates a system reaction

##### Error codes

DEUTZ-Errorcode: 203

BlinkCode (short-long-short): 1 - 4 - 4

SPN: 175

##### possible FMI:

- 0: data valid, but above normal working area
- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light  
oder

blinking. Entry in errormemory.

##### Possible reason for error

Above target range with system reaction, oil volume too small, oil loop disturbed, sensor defective, connection cable damaged

##### Take actions for error repair

Check cycle cooling system and compressor, check oil level and if necessary correct it, check sensor and if necessary replace it, check oil loop and if necessary repair it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Advice: OTSCD\_stSysReadReq

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 208 / 523470 / PRVMon

#### Error description RAIL PRESS. LIM. VALVE

Rail pressure relief valve: is open, will be forced to open, the forced-open failed

##### Error codes

DEUTZ-Errorcode: 208

BlinkCode (short-long-short): 1 - 4 - 6

SPN: 523470

##### possible FMI:

- 14: Special Instructions
- 2: data stream is defective
- 12: Defective component
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

##### Possible reason for error

Rail pressure relief valve open or forced open abortive (interpretation of the rail pressure gradient), operating voltage too low, rail pressure sensor defective, fuel metering unit defective, rail pressure relief valve defective, air in fuel system

##### Take actions for error repair

Check working voltage and if necessary correct it, check rail-pressure sensor and if necessary replace it, check FCU and if necessary replace it, check rail pressure relief valve and if necessary replace it, bleed the fuel-system

##### other error properties

System reaction: Warning, shut the engine off in about 5 minutes

Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 209 / 157 / RailCD

#### Error description RAIL PRESS. SENSOR

Rail pressure sensor: the voltage of sensor measured by ECU is out of the target range

##### Error codes

DEUTZ-Errorcode: 209

BlinkCode (short-long-short): 1 - 4 - 7

SPN: 157

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

##### Take actions for error repair

Check cabling, check rail pressure sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, max.extraction of FCU -> open rail pressure relief valve -> shut the engine off in about 5 minutes  
Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 210 / 157 / RailCDOfsTst

#### Error description RAIL PRESS. SENSOR

Rail pressure sensor: the change of the voltage measured by ECU during the engine start or the after-run is out of the target range

##### Error codes

DEUTZ-Errorcode: 210

BlinkCode (short-long-short): 1 - 4 - 7

SPN: 157

##### possible FMI:

- 0: data valid, but above normal working area
- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Deviation of signal during start or after-run above target range, sensor defective

##### Take actions for error repair

Replace sensor

##### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 2  
Measurement @ errortime: actual value

### 211 / 523613 / RailMeUn0

#### Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is above the target range which is dependant on the engine speed

##### Error codes

DEUTZ-Errorcode: 211

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

##### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

##### Possible reason for error

- 1) Leakage in high pressure system (external) ,
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamt in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

##### Take actions for error repair

- (A) Check for leakage
- (B) Chek fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

##### other error properties

System reaction: Warning or Warning and power reduction  
Behaviour error lamp: permanent light  
oder  
blinking  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

### 212 / 523613 / RailMeUn1

#### Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is above the target range which is dependant on the volume flow rate

##### Error codes

DEUTZ-Errorcode: 212

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

##### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errorredetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

##### Possible reason for error

- 1) Leakage in high pressure system (external) ,
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamt in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

##### Take actions for error repair

- (A) Check for leakage
- (B) Chek fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

##### other error properties

System reaction: Warning or Warning and power reduction  
Behaviour error lamp: permanent light  
oder  
blinking  
Selfhealing: yes  
Signal Priority: 4  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 213 / 523613 / RailMeUn2

#### Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is underneath the target range which is dependant on the engine speed

#### Error codes

DEUTZ-Errorcode: 213

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

#### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

#### Possible reason for error

- 1) No power supply in FCU,
- 2) ZME clamped in open position,
- 3) Too high pressure nach Nullförderdrossel (FCU),
- 4) Nullförderdrossel clogged,
- 5) Too high primary pressure on low pressure side, sensor defective, fuel system disturbed

#### Take actions for error repair

- (A) Check return-pressure FCU
- (B) Check flow-pressure
- (C) Change FCU, check sensor and if necessary replace it, check fuel system and if necessary repair it

#### other error properties

System reaction: Warning or Warning and power reduction  
Behaviour error lamp: permanent light  
oder  
blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 214 / 523613 / RailMeUn3

#### Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is underneath the target range which is dependant on the volume flow rate

#### Error codes

DEUTZ-Errorcode: 214

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

#### possible FMI:

- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

#### Possible reason for error

- 1) Leakage in high pressure system (external) ,
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamped in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

#### Take actions for error repair

- (A) Check for leakage
- (B) Check fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

#### other error properties

System reaction: Warning or Warning and power reduction  
Behaviour error lamp: permanent light  
oder  
blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 215 / 523613 / RailMeUn4

#### Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is above the absolute target range

#### Error codes

DEUTZ-Errorcode: 215

BlinkCode (short-long-short): 1 - 3 - 4

SPN: 523613

#### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

#### Possible reason for error

- 1) No power supply in FCU,
- 2) ZME clamped in open position,
- 3) Too high pressure nach Nullförderdrossel (FCU),
- 4) Nullförderdrossel clogged,
- 5) Too high primary pressure on low pressure side, sensor defective, fuel system disturbed

#### Take actions for error repair

- (A) Check return-pressure FCU
- (B) Check flow-pressure
- (C) Change FCU, check sensor and if necessary replace it, check fuel system and if necessary repair it

#### other error properties

System reaction: Warning or Warning and power reduction  
Behaviour error lamp: permanent light  
oder  
blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 216 / 523613 / RailMeUn7

#### Error description RAIL PRESSURE

Rail pressure: the fuel pressure in rail calculated by ECU is implausible compared with the setpoint setting of the fuel metering unit

##### Error codes

**DEUTZ-Errorcode:** 216

**BlinkCode** (short-long-short): 1 - 3 - 4

**SPN:** 523613

##### possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light  
oder  
blinking. Entry in errormemory.

##### Possible reason for error

- 1) Leakage in high pressure system (external) ;
- 2) Leakage at rail pressure relief valve (internal),
- 3) Needle clamped in open position,
- 4) Abrasion at injector,
- 5) Abrasion at high pressure pump,
- 6) Too low primary pressure on low pressure side, sensor d

##### Take actions for error repair

- (A) Check for leakage
- (B) Check fuel-primary pressure
- (C) Change components, check sensor and if necessary replace it, check fuel system and if necessary repair it

##### other error properties

System reaction: Warning or Warning and power reduction

Behaviour error lamp: permanent light

oder

blinking

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 218 / 523490 / SOPTst

#### Error description REDUNDANT SHUT OFF DET.

Internal hardware monitoring: the ECU finds an disturbance in the redundant switch off path through a test during the ramp up phase

##### Error codes

**DEUTZ-Errorcode:** 218

**BlinkCode** (short-long-short): 1 - 4 - 9

**SPN:** 523490

##### possible FMI:

- 12: Errormode not identifiable
- 12: Defective component
- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Test of redundant shut-off paths

##### Take actions for error repair

Could be triggered by over/undervoltage or external Watchdog

##### other error properties

System reaction: Test will only be executed with ECU

Initialisation. Warning, dependent upon application.

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: -

### 219 / 1079 / SSpMon1

#### Error description 5V SUPPLY 1 FAIL.

Internal hardware monitoring: the ECU detects a deviation of the target range of the power supply voltage of sensor 1

##### Error codes

**DEUTZ-Errorcode:** 219

**BlinkCode** (short-long-short): 2 - 8 - 2

**SPN:** 1079

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

5V sensor supply voltage 1 outside target range, operating voltage too high or to low, connection cable damaged, ECU defective

##### Take actions for error repair

If error not removable, change ECU, check cabling of external components, check working voltage and if necessary correct it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 221 / 1080 / SSpMon2

#### Error description 5V SUPPLY 2 FAIL.

Internal hardware monitoring: the ECU detects a deviation of the target range of the power supply voltage of sensor 2

##### Error codes

DEUTZ-Errorcode: 221

BlinkCode (short-long-short): 2 - 8 - 2

SPN: 1080

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

5V sensor supply voltage 2 outside target range, operating voltage too high or to low, connection cable damaged, ECU defective

##### Take actions for error repair

If error not removable, change ECU, check cabling of external components, check working voltage and if necessary correct it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 222 / 523601 / SSpMon3

#### Error description 5V SUPPLY 3 FAIL.

Internal hardware monitoring: the ECU detects a deviation of the target range of the power supply voltage of sensor 3

##### Error codes

DEUTZ-Errorcode: 222

BlinkCode (short-long-short): 2 - 8 - 2

SPN: 523601

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Wrong voltage of internal 5V reference source 3, operating voltage too high or too low, connection cable damaged, ECU defective

##### Take actions for error repair

If error not removable, change ECU, check cabling of external components, check working voltage and if necessary correct it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: actual value

### 223 / 677 / StrtCDHS

#### Error description START RELAY

Start relay (high side power stage): the current drain measured by ECU is above the target range

##### Error codes

DEUTZ-Errorcode: 223

BlinkCode (short-long-short): 5 - 1 - 2

SPN: 677

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Start relay (high side): short circuit, relay defective, connection cable defective

##### Take actions for error repair

Check cabling and start relay and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, shutoff output  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 1  
Measurement @ errortime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 224 / 677 / StrtCDLS

#### Error description START RELAY

start relay (low side power stage): the current drain measured by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 224

BlinkCode (short-long-short): 5 - 1 - 2

SPN: 677

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Start relay (low side): cable break or short circuit, disabled by ECU, relay defective, connection cable damaged

#### Take actions for error repair

Check cabling and start relay and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, shutoff output  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 1  
Measurement @ errortime: default value

### 225 / 624 / SysLamp

#### Error description DIAGNOSTIC LAMP

Error lamp (diagnostic lamp): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component for power supply of the lamp is exceeded

#### Error codes

DEUTZ-Errorcode: 225

BlinkCode (short-long-short): 5 - 1 - 3

SPN: 624

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 5: current to low or broken wire
- 2: data stream is defective

#### Errordetection

Errorlamp shows -. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, disabled by ECU, lamp defective, connection cable damaged

#### Take actions for error repair

Check cabling and load, check lamp and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: only error memory item  
Behaviour error lamp: -  
Selfhealing: no  
Signal Priority: 2  
Measurement @ errortime: setpoint Diagnosticlamp

### 226 / 158 / T15CD

#### Error description TERMINAL 15

Terminal 15: ECU receives no signal

#### Error codes

DEUTZ-Errorcode: 226

BlinkCode (short-long-short): 5 - 1 - 4

SPN: 158

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Ignition ON not detected, ignition switch defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check ignition switch and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, engine can not start  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 2  
Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300

### 227 / 523550 / T50CD

#### Error description TERMINAL 50

Terminal 50: ECU receives a permanent signal

#### Error codes

DEUTZ-Errorcode: 227

BlinkCode (short-long-short): 5 - 1 - 5

SPN: 523550

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Engine start switch stuck, start switch clamped, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check start switch and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: no  
Signal Priority: 1  
Measurement @ errortime: actual value

### 228 / 523550 / TPUMon

#### Error description TERMINAL 50

Internal hardware monitoring: ECU detects a deviation between the signal of time module and the system time

#### Error codes

DEUTZ-Errorcode: 228

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523550

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 2: data stream is defective

#### Errordetection

Errorlamp shows blinking. Entry in errormemory.

#### Possible reason for error

Time processing unit (TPU) defective, ECU defective

#### Take actions for error repair

If error not removable, change ECU

#### other error properties

System reaction: Recovery of ECU  
Behaviour error lamp: blinking  
Selfhealing: no  
Signal Priority: 5  
Measurement @ errortime: -

### 232 / 84 / VSSCD1

#### Error description VEHICLE SPEED

Vehicle speed: over the maximum, signal invalid or implausible compared with the injection quantity and the engine speed, offset factors unlearned

#### Error codes

DEUTZ-Errorcode: 232

BlinkCode (short-long-short): 5 - 2 - 1

SPN: 84

#### possible FMI:

- 0: data valid, but above normal working area
- 12: Defective component
- 8: unusual frequency, pulse or period.
- 14: Special Instructions

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Speed above target range, signal invalid or implausible compared to injection volume and engine speed, distance factor not learned, sensor defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 235 / 523600 / WdCom

#### Error description SERIAL INTERFACE DEF.

Internal hardware monitoring: the ECU detects a disturbance in internal communication

##### Error codes

DEUTZ-Errorcode: 235

BlinkCode (short-long-short): 5 - 5 - 5

SPN: 523600

##### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component

##### Errordetection

Errorlamp shows blinking. Entry in errormemory.

##### Possible reason for error

Communication disturbed, ECU defective

##### Take actions for error repair

If error not to removable, change ECU

##### other error properties

System reaction: Recovery of ECU

Behaviour error lamp: blinking

Selfhealing: no

Signal Priority: 5

Measurement @ errortime: -

### 236 / 523470 / PRVMonSysReac

#### Error description RAIL PRESS. LIM. VALVE

Rail pressure relief valve: is open, will be forced to open, the forced-open failed; the ECU activates a system reaction

##### Error codes

DEUTZ-Errorcode: 236

BlinkCode (short-long-short): 1 - 4 - 6

SPN: 523470

##### possible FMI:

- 12: Defective component
- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light, 15s before shut off. Entry in errormemory.

##### Possible reason for error

Rail pressure relief valve open or forced open abortive (interpretation of the rail pressure gradient), power supply voltage too low, rail pressure sensor defective, fuel metering unit defective, rail pressure relief valve defective, air in fuel system

##### Take actions for error repair

Check working voltage and if necessary correct it, check rail-pressure sensor and if necessary replace it, check FCU and if necessary replace it, check rail pressure relief valve and if necessary replace it, bleed the fuel-system

##### other error properties

System reaction: Warning, shut the engine off in about 5 minutes

Behaviour error lamp: permanent light, 15s before shut off

Selfhealing: no

Signal Priority: 4

Measurement @ errortime: actual value

### 237 / 523006 / APPCDSwtnSel

#### Error description CONTR. MODE SWITCH

Controller mode switch: the signal received by ECU is defective or implausible.

##### Error codes

DEUTZ-Errorcode: 237

BlinkCode (short-long-short): 2 - 4 - 2

SPN: 523006

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break, signal implausible, switch defective, connection cable damaged

##### Take actions for error repair

Check switch and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 2

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 238 / 523007 / FrmMng\_TORxEngPress

**Error description CAN ERROR RxEngPress.**

#### Error codes

DEUTZ-Errorcode: 238

BlinkCode (short-long-short): 2 - 1 - 5

SPN: 523007

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

#### Take actions for error repair

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 1

Measurement @ errortime: default value

### 239 / 523008 / MplCtI

**Error description MANIPULATION CONTROL**

Data monitoring: the torque curve does not match the specification

#### Error codes

DEUTZ-Errorcode: 239

BlinkCode (short-long-short): 4 - 2 - 4

SPN: 523008

#### possible FMI:

- 1: data valid, but below normal working area
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errorredetection

Errorlamp shows . Entry in errormemory.

#### Possible reason for error

Manipulation of Topcurve detected, data manipulation, too slow changed curve

#### Take actions for error repair

#### other error properties

System reaction:

Behaviour error lamp:

Selfhealing: -

Signal Priority: 3

Measurement @ errortime:

### 240 / 98 / OLSCD

**Error description OIL LEVEL SWITCH**

Oil level sensor: the voltage of sensor measured by ECU is out of the target range or the received value of oil level via CAN is defective or the signal value is implausible

#### Error codes

DEUTZ-Errorcode: 240

BlinkCode (short-long-short): 2 - 1 - 1

SPN: 98

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 2: data stream is defective
- 2: data stream is defective

#### Errorredetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Voltage outside target range, CAN signal error, signal implausible, sensor defective, connection cable damaged, CAN bus wrong cabled, wiring damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it, Check CAN Bus cabling (Bus shaduling, polarity, short circuit, power interrupt), test protocol of receiver, chec

#### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 241 / 98 / OLSCDSysReacHi

#### Error description OIL LEVEL SWITCH

Oil level: the oil level calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 241

BlinkCode (short-long-short): 2 - 5 - 1

SPN: 98

#### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Oil level too high with system reaction, oil volume too large, sensor defective, connection cable damaged, CAN data error

#### Take actions for error repair

Check oil level and if necessary correct it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: OLSCD\_stSysReacReq

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

### 242 / 107 / ADPSCDana

#### Error description AIR FILTER COND.

Air filter differential pressure sensor: the voltage of sensor measured by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 242

BlinkCode (short-long-short): 1 - 3 - 6

SPN: 107

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Voltage outside target range, sensor defective, connection cable damaged

#### Take actions for error repair

Check cable harness, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

### 243 / 98 / OLSCDSysReacLo

#### Error description OIL LEVEL SWITCH

Oil level: the oil level calculated by ECU is underneath the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 243

BlinkCode (short-long-short): 2 - 5 - 2

SPN: 98

#### possible FMI:

- 1: data valid, but below normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Oil level too low with system reaction, oil volume too small, sensor defective, connection cable damaged, CAN data error

#### Take actions for error repair

Check oil level and if necessary correct it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Advice: OLSCD\_stSysReacReq

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: actual value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 244 / 523009 / PrrMonWear

#### Error description REPL. RAIL PRESS. VALVE

Rail pressure relief valve: is open more frequently or for a longer time than what the technical specification allows

#### Error codes

DEUTZ-Errorcode: 244

BlinkCode (short-long-short): 2 - 5 - 3

SPN: 523009

#### possible FMI:

- 9: Abnormal update rated
- 10: Abnormal rate of change
- 14: Special Instructions
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Rail pressure relief valve open more frequently than the technical specification allowed, rail pressure relief valve open longer than the technical specification allowed, rail pressure relief valve defective

#### Take actions for error repair

Change rail pressure relief valve and remove the error through Serdia command

#### other error properties

System reaction: permanent error message, unerasurable by "Clear EM"

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

### 245 / 523010 / RailMeUn8

#### Error description LEAKAGE DETECTION

Wenn the engine is in idle running, the metering unit compares its output and rail pressure with the default value (Parameter) and calculates a correction factor-it calibrates itself then

#### Error codes

DEUTZ-Errorcode: 245

BlinkCode (short-long-short): 2 - 5 - 4

SPN: 523010

#### possible FMI:

- 0: data valid, but above normal working area
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

#### Take actions for error repair

#### other error properties

System reaction:

Behaviour error lamp: permanent light

Selfhealing: no

Signal Priority: 3

Measurement @ errortime: actual value

### 246 / 523650 / FISys\_FLPFMSysReac

#### Error description

Low fuel pressure Diesel: the low fuel pressure calculated by ECU is underneath the target range; the ECU activates a system reaction

#### Error codes

DEUTZ-Errorcode: 246

BlinkCode (short-long-short): 5 - 4 - 1

SPN: 523650

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Diesel fuel pressure below target range with system reaction, interruption in cycling process of low fuel pressure (for example, fuel pump defective), sensor defective, connection cable damaged

#### Take actions for error repair

Check Diesel low fuel pressure loop system, Check electrical fuel pump, inspect fuel system and if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 4

Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 247 / 523651 / FISys\_FTSFMSysReac

#### Error description

Rape Oil Fuel temperature: the fuel temperature calculated by ECU is above the target range; the ECU activates a system reaction

#### Error codes

**DEUTZ-Errorcode:** 247

**BlinkCode** (short-long-short): 5 - 4 - 2

**SPN:** 523651

#### possible FMI:

- 2: data stream is defective
- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Rape oil fuel temperature above target range with system reaction, interruption of rape oil fuel loop (for example, heat exchanger not working properly), sensor defective, connection cable damaged

#### Take actions for error repair

Check rape oil fuel system as well as heat exchanger and heat exchanger valve, if necessary repair it, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning and switchover to Diesel operation mode

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

### 248 / 523652 / FISys\_FlushStateEngineOff

#### Error description

Engine shut off without flushing or flushing was not already completed. ECU stores every shutoff with uncompleted or missing flushing process

#### Error codes

**DEUTZ-Errorcode:** 248

**BlinkCode** (short-long-short): 5 - 4 - 3

**SPN:** 523652

#### possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Engine shut off without flushing of the fuel system in Diesel operation mode, Shutoff before flushing in Diesel operation mode was finished

#### Take actions for error repair

Awaiting complete flushing of the fuel system everytime before engine shut off

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: -

### 249 / 523653 / FISys\_RapeOilHeatEx

#### Error description RAPEOILSYSTEM

Awaited temperatur rise with opened heat exchanger valve did not occur. Error in fuel heating system.

#### Error codes

**DEUTZ-Errorcode:** 249

**BlinkCode** (short-long-short): 5 - 4 - 4

**SPN:** 523653

#### possible FMI:

- 2: data stream is defective
- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Fuel heating system (heat exchanger) not working correctly

#### Take actions for error repair

Check Heat exchanger and heat exchanger valve, check cooling system going to the heat exchanger, check rape oil system going to the heat exchanger

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: -

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 250 / 523654 / FrmMngDieselLvl

#### Error description RAPEOILSYSTEM

Status DieselLvl (Diesel tank level): the voltage of the sensor measured by ECU is out of the target range

##### Error codes

DEUTZ-Errorcode: 250

BlinkCode (short-long-short): 5 - 4 - 5

SPN: 523654

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, sensor defective, connection cable damaged

##### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value

### 251 / 523655 / FrmMngFuelTemp

#### Error description RAPEOILSYSTEM

Status FuelTemp (Fuel Temperature): the voltage of the sensor measured by ECU is out of the target range

##### Error codes

DEUTZ-Errorcode: 251

BlinkCode (short-long-short): 5 - 4 - 6

SPN: 523655

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

##### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value

### 252 / 523656 / FrmMngLowPressureDiesel

#### Error description RAPEOILSYSTEM

Status LowPressureDiesel (Low fuel pressure diesel): the voltage of the sensor measured by ECU is out of the target range

##### Error codes

DEUTZ-Errorcode: 252

BlinkCode (short-long-short): 5 - 4 - 7

SPN: 523656

##### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

##### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

##### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

##### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

##### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 253 / 523657 / FrmMngRapeOilIn

#### Error description RAPEOILSYSTEM

CAN messageRapeOilIn (Rape oil input): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 253

BlinkCode (short-long-short): 5 - 6 - 1

SPN: 523657

#### possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, substitute values  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value

### 254 / 523658 / FrmMngRapeOilVl

#### Error description RAPEOILSYSTEM

Status RapeOilVl (Rape oil tank level): the voltage of the sensor measured by ECU is out of the target range

#### Error codes

DEUTZ-Errorcode: 254

BlinkCode (short-long-short): 5 - 6 - 2

SPN: 523658

#### possible FMI:

- 3: Voltage to high or short circuit to +Ubatt
- 4: Voltage to low or short circuit to -Ubatt
- 12: Errormode not identifiable
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, lamp defective, connection cable damaged

#### Take actions for error repair

Check cabling, if sensor not working, check sensor and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning, substitute value  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value

### 255 / 523659 / FrmMngRapeOilVlV1

#### Error description RAPEOILSYSTEM

Status RapeOilVlV1 (Valve 1): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

#### Error codes

DEUTZ-Errorcode: 255

BlinkCode (short-long-short): 5 - 6 - 3

SPN: 523659

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

#### Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning and switchover to Diesel operation mode  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value



# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 256 / 523660 / FrmMngRapeOilVlv2

#### Error description RAPEOILSYSTEM

Status RapeOilVlv2 (Valve 2): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

#### Error codes

**DEUTZ-Errorcode:** 256

**BlinkCode** (short-long-short): 5 - 6 - 4

**SPN:** 523660

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

#### Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning and switchover to Diesel operation mode

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

### 257 / 523661 / FrmMngRapeOilVlv3

#### Error description RAPEOILSYSTEM

Status RapeOilVlv3 (Valve 3): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

#### Error codes

**DEUTZ-Errorcode:** 257

**BlinkCode** (short-long-short): 5 - 6 - 5

**SPN:** 523661

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

#### Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning and switchover to Diesel operation mode

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

### 258 / 523662 / FrmMngRapeOilVlv4

#### Error description RAPEOILSYSTEM

Status RapeOilVlv4 (Valve 4): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

#### Error codes

**DEUTZ-Errorcode:** 258

**BlinkCode** (short-long-short): 5 - 6 - 6

**SPN:** 523662

#### possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

#### Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning

Behaviour error lamp: permanent light

Selfhealing: yes

Signal Priority: 3

Measurement @ errortime: default value

# DTC-List

## Diagnosis- and Errorcodes

referenced ECU-Software  
P490\_: 220, 310, 501  
P491\_: 220, 310, 400, 501

P492\_: 213  
P513\_: 214, 300



### 259 / 523663 / FrmMngRapeOilVlv5

#### Error description RAPEOILSYSTEM

Status RapeOilVlv5 (Valve 5): the current drain measured by ECU is out of the target range or the maximum permissible temperature of the ECU component is exceeded

#### Error codes

DEUTZ-Errorcode: 259

BlinkCode (short-long-short): 5 - 6 - 7

SPN: 523663

possible FMI:

- 12: Errormode not identifiable
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

Cable break or short circuit, valve defective, connection cable damaged

#### Take actions for error repair

Check cabling, if valve not working, check valve and if necessary replace it, check connection cable and if necessary repair or replace it

#### other error properties

System reaction: Warning  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value

### 260 / 523664 / FrmMngSTIN1RX

#### Error description RAPEOILSYSTEM

CAN message STIN1 (State Inputs 1): the message can not be received by ECU

#### Error codes

DEUTZ-Errorcode: 260

BlinkCode (short-long-short): 5 - 6 - 8

SPN: 523664

possible FMI:

- 12: Defective component
- 12: Errormode not identifiable
- 12: Defective component
- 12: Errormode not identifiable

#### Errordetection

Errorlamp shows permanent light. Entry in errormemory.

#### Possible reason for error

CAN bus wrong cabled, wiring is damaged, receiver (sender of the message) work inaccurately, parametering inaccurate

#### Take actions for error repair

Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range

#### other error properties

System reaction: Warning, substitute values  
Behaviour error lamp: permanent light  
Selfhealing: yes  
Signal Priority: 3  
Measurement @ errortime: default value



**MECALAC Baumaschinen GmbH**

Am Friedrichsbrunnen 2  
D-24782 Büdelsdorf

Tel: +49 (0)4331 351 325  
Fax: +49 (0)4331 351 491

E-Mail: [info@mecalac.com](mailto:info@mecalac.com)  
Web: [www.mecalac.com](http://www.mecalac.com)