

4.5 Instrument panel




Figure 4-10

- 1 - Toggle switch for work lights
- 2 - Pushbutton for releasing the quick-change device
- 3 - Toggle switch for interval wiper, front
- 4 - Toggle switch for windshield washer, front
- 5 - Toggle switch for windshield wiper/washer, rear
- 6 - Toggle switch for rear window heater
- 7 - Fuel gauge
- 8 - Engine oil temperature display
- 9 - Operating hour meter
- 10 - Toggle switch for hazard flasher system
- 11 - Toggle switch for beacon light (option)
- 12 - Toggle switch for driving lights
- 13 - Transmission switch (only for fast loaders - 30 km/h)
UP: transmission step II; DOWN: transmission step I
- 14 - Not assigned
- 15 - Toggle switch for lifting device suspension (option)
- 16 - Socket
- 17 - Fuse box
- 18 - Rotary switch for ventilation/fan
- 19 - Starter switch

