

P R E F A C E

This manual contains operating and servicing instructions and preventive maintenance procedures as well as a general technical description of the loader

Please read this manual carefully and adhere to the instructions. Important repair work should be done by properly trained service personnel.

An engine manual with maintenance instructions is also supplied with each machine. Please observe these instructions exactly.

It is further recommended that you read the accident prevention instructions for excavators and loaders prepared by the German construction association (Tiefbau Berufsgenossenschaft).

Ahlmann-Maschinenbau GmbH

Am Friedrichsbrunnen 2

D-2370 Büdelsdorf

Telephone: (4331)3510

Teletex: 433 111

Issue: 10/1985 - starting with chassis-no. 47105100